OCAS-DRI-CIB-19-11 NEW CAR ASSESSMENT PROGRAM CRASH IMMINENT BRAKE SYSTEM CONFIRMATION TEST

2019 Honda Pilot

DYNAMIC RESEARCH, INC.

355 Van Ness Avenue, STE 200 Torrance, California 90501



28 August 2019

Final Report

Prepared Under Contract No.: DTNH22-14-D-00333

U. S. DEPARTMENT OF TRANSPORTATION
National Highway Traffic Safety Administration
Office of Crash Avoidance Standards
1200 New Jersey Avenue, SE
West Building, 4th Floor (NRM-200)
Washington, DC 20590

Prepared for the Department of Transportation, National Highway Traffic Safety Administration, under Contract No. DTNH22-14-D-00333.

This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings, and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturer's names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products of manufacturers.

Prepared By:	J. Lenkeit	J. Robel
	Program Manager	Test Engineer
Date:	28 August 2019	

1. Report No.		2. Government Accession No.	3.	Recipient's Catalog No.	
OCAS-DRI-C	IB-19-11				
4. Title and Su	otitle		5.	Report Date	
Final Report of C Honda Pilot.	rash Imminent Brake	System Confirmation Testing of a 2019	28 /	August 2019	
			6.	Performing Organization Code	
				DRI	
7. Author(s)			8.	Performing Organization Report	rt No.
J. Lenkeit, F	rogram Manager			DRI-TM-18-104	
J. Robel, Te	st Engineer				
9. Performing (Organization Name ar	nd Address	10.	Work Unit No.	
Dynamic Re	search Inc				
355 Van Ne	ss Ave, STE 200		11.	Contract or Grant No.	
Torrance, C	A 90501			DTNH22-14-D-00333	
12. Sponsoring	Agency Name and A	ddress	13.	Type of Report and Period Co	vered
U.S. Department of Transportation National Highway Traffic Safety Administration Office of Crash Avoidance Standards 1200 New Jersey Avenue, SE, West Building, 4th Floor (NRM-200)			Final Test Report February - August 2019		
wasningtoi	, D.C. 20590		14.	Sponsoring Agency Code	
				NRM-200	
15. Supplement	ary Notes				
16. Abstract					
Standards most	current Test Procedu	ubject 2019 Honda Pilot in accordance wir re in docket NHTSA-2015-0006-0025; CF SSESSMENT PROGRAM, October 2015.		•	
The vehicle pa	ssed the requirement	s of the test for all four CIB test scenarios	and a	all speeds.	
17. Key Words			18.	Distribution Statement	
Crash Imminent Brake,			Copies of this report are available from the following:		
CIB, AEB, New Car Assessment Program, NCAP				NHTSA Technical Reference D National Highway Traffic Safe 1200 New Jersey Avenue, SE	ty Administration
10 0- 11 01	:	100 County Clas 'C (C)'		Washington, D.C. 20590	00 D.:
	ssif. (of this report)	20. Security Classif. (of this page)		No. of Pages	22. Price
Unclassified		Unclassified		138	

TABLE OF CONTENTS

SEC	TION			<u>PAGE</u>
I.	OVE	RV	IEW AND TEST SUMMARY	1
П.	DAT	Α 9	SHEETS	2
	A.	Da	ta Sheet 1: Test Summary	3
	B.	Da	ta Sheet 2: Vehicle Data	4
	C.	Da	ta Sheet 3: Test Conditions	6
	D.	Da	ta Sheet 4: Crash Imminent Brake System Operation	8
III.	TES	ΤP	ROCEDURES	12
	A.	Te	st Procedure Overview	12
	B.	Ge	eneral Information	18
	C.	Pri	ncipal Other Vehicle	22
	D.	Αι	Itomatic Braking System	23
	E.	Ins	strumentation	23
Appe	endix	Α	Photographs	A-1
Appe	endix	В	Excerpts from Owner's Manual	B-1
Appe	endix	С	Run Logs	C-1
Appe	endix	D	Time Histories	D-1

Section I OVERVIEW AND TEST SUMMARY

Crash Imminent Brake (CIB) systems are a subset of Automatic Emergency Braking (AEB) systems. CIB systems are designed to avoid, or mitigate rear-end crashes, by automatically applying subject vehicle brakes when the system determines that, without intervention, a rear-end crash will occur. CIB systems typically work as an extension of Forward Collision Warning (FCW) systems, which alert the driver to the possibility of a collision unless driver action is taken. CIB systems employ sensors capable of detecting vehicles in the forward path. Current CIB technology typically involves RADAR, LIDAR, or vision-based (camera) sensors, and measurement of vehicle operating conditions such as speed, driver steering and brake application, etc. Algorithms in the system's Central Processing Unit (CPU) use this information to continuously monitor the likelihood of a rear-end crash and command a brake actuator to apply the brakes when necessary.

The method prescribed by the National Highway Traffic Safety Administration (NHTSA) to evaluate CIB performance on the test track¹ involves three rear-end type crash configurations and a "false positive" test. In the rear-end scenarios, a subject vehicle (SV) approaches a stopped, slower-moving, or decelerating principal other vehicle (POV) in the same lane of travel. For these tests, the POV is a strikeable object with the characteristics of a compact passenger car. The false positive scenarios are used to evaluate the propensity of a CIB system to inappropriately activate in a non-critical driving scenario that does not involve a forward vehicle or present a safety risk to the SV occupant(s).

The purpose of the testing reported herein was to objectively quantify the performance of a Crash Imminent Brake system installed on a 2019 Honda Pilot. This test is part of the New Car Assessment Program to assess Crash Imminent Brake Systems sponsored by the National Highway Traffic Safety Administration under Contract No. DTNH22-14-D-00333.

1

¹ NHTSA-2015-0006-0025; Crash Imminent Brake System Performance Evaluation for the New Car Assessment Program, October 2015.

Section II DATA SHEETS

DATA SHEET 1: TEST RESULTS

(Page 1 of 1)

2019 Honda Pilot

SUMMARY RESULTS

VIN: <u>5FNYF5H95KB0xxxx</u>

Test Date: 2/12/2019

Test 1 - Subject Vehicle Encounters
Stopped Principal Other Vehicle

SV 25 mph: Pass

Test 2 - Subject Vehicle Encounters
Slower Principal Other Vehicle

SV 25 mph POV 10 mph: Pass

SV 45 mph POV 20 mph: Pass

Test 3 - Subject Vehicle Encounters
Decelerating Principal Other Vehicle

SV 35 mph POV 35 mph: Pass

Test 4 - Subject Vehicle Encounters Steel Trench Plate

SV 25 mph: Pass

SV 45 mph: Pass

Overall: Pass

Notes:

DATA SHEET 2: VEHICLE DATA

(Page 1 of 2)

2019 Honda Pilot

TEST VEHICLE INFORMATION

VIN: 5FNYF5H95KB0xxxx Body Style: (MPV) SUV Color: *Modern Steel* Date Received: 1/30/2019 Odometer Reading: 13 mi Engine: 3.5 L V-6 Transmission: Automatic Final Drive: FWD (2WD) Is the vehicle equipped with: ABS X Yes No Adaptive Cruise Control X Yes No

DATA FROM VEHICLE'S CERTIFICATON LABEL

Collision Mitigating Brake System X Yes

Vehicle manufactured by: <u>Honda Mfg. of Alabama, LLC</u>

Date of manufacture: <u>11/2018</u>

DATA FROM TIRE PLACARD:

Tires size as stated on Tire Placard: Front: 245/50R20

Rear: 245/50R20

Recommended cold tire pressure: Front: 240 kPa (35 psi)

Rear: 240 kPa (35 psi)

No

DATA SHEET 2: VEHICLE DATA

(Page 2 of 2) 2019 Honda Pilot

TIRES

Tire manufacturer and model: Continental Cross Contact LX Sport

Front tire size: <u>245/50R20</u>

Rear tire size: <u>245/50R20</u>

VEHICLE ACCEPTANCE

Verify the following before accepting the vehicle:

- X All options listed on the "window sticker" are present on the test vehicle
- X Tires and wheel rims are the same as listed.
- X There are no dents or other interior or exterior flaws.
- X The vehicle has been properly prepared and is in running condition.
- X Verify that spare tire, jack, lug wrench, and tool kit (if applicable) is located in the vehicle cargo area.

DATA SHEET 3: TEST CONDITIONS

(Page 1 of 2)

2019 Honda Pilot

GENERAL INFORMATION

Test date: <u>2/12/2019</u>

AMBIENT CONDITIONS

Air temperature: 7.2 C (45 F)

Wind speed: 1.5 m/s (3.5 mph)

- X Windspeed ≤ 10 m/s (22 mph)
- X Tests were not performed during periods of inclement weather. This includes, but is not limited to, rain, snow, hail, fog, smoke, or ash.
- X Tests were conducted during daylight hours with good atmospheric visibility (defined as an absence of fog and the ability to see clearly for more than 5000 meters). The tests were not conducted with the vehicle oriented into the sun during very low sun angle conditions, where the sun is oriented 15 degrees or less from horizontal, and camera "washout" or system inoperability results.

VEHICLE PREPARATION

Verify the following:

All non consumable fluids at 100 % capacity : X

Fuel tank is full: X

Tire pressures are set to manufacturer's recommended cold tire pressure:

Front: 240 kPa (35 psi)

Rear: 240 kPa (35 psi)

DATA SHEET 3: TEST CONDITIONS

(Page 2 of 2)

2019 Honda Pilot

WEIGHT

Weight of vehicle as tested including driver and instrumentation

Left Front: 598.3 kg (1319 lb) Right Front 553.4 kg (1220 lb)

Left Rear 428.2 kg (944 lb) Right Rear 437.7 kg (965 lb)

Total: <u>2017.6 kg (4448 lb)</u>

DATA SHEET 4: CRASH IMMINENT BRAKE SYSTEM OPERATION

(Page 1 of 4)

2019 Honda Pilot

Name of the CIB option, option package, etc.

Collision Mitigation Braking System (CMBS)

System setting used for test (if applicable): Normal

What is the minimum vehicle speed at which the CIB system becomes active?

5 km/h (Per manufacturer supplied information)

What is the maximum vehicle speed at which the CIB system functions?

No limitations (Per manufacturer supplied information)

Does the vehicle system require an initialization sequence/procedure? *Yes.*

Will the system deactivate due to repeated AEB activations, impacts or nearmisses?

Yes, CMBS indicator in Multi-Information Display comes on if it deactivates.

How is the Forward Collision Warning presented to the driver?		0 0
		Buzzer or audible alarm
	X	Vibration
		Other

Describe the method by which the driver is alerted. For example, if the warning is a light, where is it located, its color, size, words or symbol, does it flash on and off, etc. If it is a sound, describe if it is a constant beep or a repeated beep. If it is a vibration, describe where it is felt (e.g., pedals, steering wheel), the dominant frequency (and possibly magnitude), the type of warning (light, audible, vibration, or combination), etc.

The driver is alerted by a visual alert of the word "BRAKE" with an orange color on the Multi-information Display in the instrument panel. The driver is also alerted by sound with a repeated beep and steering wheel vibration for oncoming detected vehicles.

DATA SHEET 4: CRASH IMMINENT BRAKE SYSTEM OPERATION

(Page 2 of 4)

2019 Honda Pilot

Is there a way to deactivate the system?	X Yes
	No
If yes, please provide a full description including the method of operation, any associated instrument pa	
There is a button on the bottom left of the ins driver's side, below the steering wheel that the	e driver can press to switch
the system off. The upper button from the sec the right is pressed until the beeper sounds to off.	
Is the vehicle equipped with a control whose purpo the range setting or otherwise influence the operati	_
If yes, please provide a full description.	
Controls on the left side of the steering wheel settings. The "home" button is used to start a down arrow are used to scroll through selection used to select an option. The sequence is: -System -Driver Assist System Setup -Forward Collision Warning Distance -Select: Long, Normal or Short	the process. The up and
Are there other driving modes or conditions that reinoperable or reduce its effectiveness?	nder CIB X Yes

DATA SHEET 4: CRASH IMMINENT BRAKE SYSTEM OPERATION

(Page 3 of 4)

2019 Honda Pilot

If yes, please provide a full description.

- Driving in bad weather (rain, fog snow, etc.)
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- Little light contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of tress, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.
- Driving on a snowy or wet roadway (obstructed lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on curvy, winding or undulating roads.
- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
- Driving with the parking brake applied.
- When the radar sensor behind the emblem gets dirty.
- The vehicle is towing a trailer.
- When a vehicle or pedestrian suddenly crosses in front of you.
- When the distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- When a vehicle cuts in front of you at slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.

(Continued next page)

DATA SHEET 4: CRASH IMMINENT BRAKE SYSTEM OPERATION

(Page 4 of 4)

2019 Honda Pilot

- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- <u>The speed difference between your vehicle and a vehicle or pedestrian</u> in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.
- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
 When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

Notes:

Section III

TEST PROCEDURES

A. Test Procedure Overview

Four test scenarios were used, as follows:

- Test 1. Subject Vehicle (SV) Encounters Stopped Principal Other Vehicle (POV)
- Test 2. Subject Vehicle Encounters Slower Principal Other Vehicle
- Test 3. Subject Vehicle Encounters Decelerating Principal Other Vehicle
- Test 4. Subject Vehicle Encounters Steel Trench Plate

An overview of each of the test procedures follows.

TEST 1 - SUBJECT VEHICLE ENCOUNTERS STOPPED PRINCIPAL OTHER VEHICLE ON A STRAIGHT ROAD

This test evaluates the ability of the CIB system to detect and respond to a stopped lead vehicle in the immediate forward path of the SV, as depicted in Figure 1.




Figure 1. Depiction of Test 1

a. Procedure

The POV was parked in the center of a travel lane, with its longitudinal axis oriented parallel to the roadway edge and facing the same direction as the SV so that the SV approached the rear of the POV.

The SV ignition was cycled prior to each test run. The SV was driven at a nominal speed of 25 mph (40.2 kph) in the center of the lane of travel, toward the parked POV. The SV throttle pedal was released within 500 ms after t_{FCW}, i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- The SV came to a stop before making contact with the POV.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

The SV speed could not deviate from the nominal speed by more than 1.0 mph (1.6 kph) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to t_{FCW}. For this test, TTC = 5.1 seconds is taken to occur at an SV-to-POV distance of 187 ft (57 m).

b. Criteria

In order to pass the test, the magnitude of the SV speed reduction attributable to CIB intervention must have been \geq 9.8 mph (15.8 km/h) for at least five of seven valid test trials.

The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from t_{FCW}-100 ms to t_{FCW}.
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevented the crash), the SV speed at a time of SV-to-POV contact was taken to be zero. The speed reduction is therefore equal to the SV speed at t_{FCW}.

2. TEST 2 – SUBJECT VEHICLE ENCOUNTERS SLOWER PRINCIPAL OTHER VEHICLE

This test evaluates the ability of the CIB system to detect and respond to a slower-moving lead vehicle traveling at a constant speed in the immediate forward path of the SV, as depicted in Figure 2.




Figure 2. Depiction of Test 2

a. Procedure

The SV ignition was cycled prior to each test run. The tests were conducted two ways. In the first, the POV was driven at a constant 10.0 mph (16.1 kph) in the center of the lane of travel while the SV was driven at 25.0 mph (40.2kph), in the center lane of travel, toward the slower-moving POV. In the second, the POV was driven at a constant 20.0 mph (32.2 kph) in the center of the lane of travel while the SV was driven at 45.0 mph (74.4 kph), in the center lane of travel, toward the slower-moving POV. In both cases, the SV throttle pedal was released within 500 ms after t_{FCW} , i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- 1 second after the speed of the SV becomes less than or equal to that of the POV.

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the POV and the center of the travel lane could not deviate more than ± 1 ft (0.3 m) during the validity period.
- The lateral distance between the centerline of the SV and the center of the travel lane could not deviate more than ± 1 ft (0.3 m) during the validity period.

- The SV speed could not deviate more than ± 1.0 mph (± 1.6 km/h) during an interval defined by TTC = 5.0 seconds to t_{FCW}.
- The POV speed could not deviate more than ± 1.0 mph (± 1.6 km/h) during the validity period.

b. Criteria

For the test series in which the initial SV speed was 25 mph, the condition for passing was that there be no SV-POV impact for at least five of the seven valid test trials.

In order to pass the test series for which the initial speed of the SV was 45 mph, the magnitude of the SV speed reduction attributable to CIB intervention must have been ≥ 9.8 mph (15.8 km/h) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- 1. If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from t_{FCW}-100 ms to t_{FCW}.
- 2. If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevented the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-POV range during the validity period from the SV speed at tFCW.

TEST 3 – SUBJECT VEHICLE ENCOUNTERS DECELERATING PRINCIPAL OTHER VEHICLE

This test evaluates the ability of the CIB system to detect and respond to a lead vehicle slowing with a constant deceleration in the immediate forward path of the SV, as depicted in Figure 3.




Figure 3. Depiction of Test 3 with POV Decelerating

a. Procedure

The SV ignition was cycled prior to each test run. For this test scenario, both the POV and SV were driven at a constant 35.0 mph (56.3 kph) in the center of the lane, with a headway of 45.3 ft (13.8 m) \pm 8 ft (2.4 m). Once these conditions were met, the POV tow vehicle brakes were applied to achieve 0.3 \pm 0.03 g of deceleration. The test concluded when either:

- The SV came into contact with the POV or
- For the decelerating POV, 1 second after minimal longitudinal SV-POV distance occurred or
- For the POV decelerating to stop case, 1 second after the velocity of the SV became less than or equal to that of the POV.

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the POV and the center of the travel lane could not deviate more than ± 1 ft (0.3 m) during the validity period.
- The lateral distance between the centerline of the SV and the center of the travel lane could not deviate more than ± 1 ft (0.3 m) during the validity period.
- The headway between the SV and POV must have been constant from the onset of the applicable validity period to the onset of POV braking.
- The SV and POV speed could not deviate more than ± 1.0 mph (1.6 km/h) during an interval defined by the onset of the validity period to the onset of

POV braking.

- The SV- POV headway distance could not deviate more than ±8 ft (2.4 m) during an interval defined by the onset of the validity period to the onset of POV braking.
- The average POV deceleration could not deviate by more than ±0.03 g from the nominal 0.3 g deceleration during the interval beginning at 1.5 seconds after the onset of POV braking and ending either 250 ms prior to the POV coming to a stop or the SV coming into contact with the POV.

b. Criteria

In order to pass the decelerating POV test series, the magnitude of the SV speed reduction attributable to CIB intervention must have been ≥ 10.5 mph (16.9 kph) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- 1. If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range becomes zero) from the average SV speed calculated from t_{FCW} 100 ms to t_{FCW}.
- 2. If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevents the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-to-POV range during the applicable validity period from the SV speed at trcw.

4. TEST 4 - FALSE POSITIVE SUPPRESSION

The false positive suppression test series evaluates the ability of a CIB system to differentiate a steel trench plate (STP) from an object presenting a genuine safety risk to the SV. Although the STP is large and metallic, it is designed to be driven over without risk of injury to the driver or damage to the SV. Therefore, in this scenario, the automatic braking available from CIB is not necessary and should be suppressed. The test condition is nearly equivalent to that previously defined for Test 1, the stopped POV condition, but with an STP in the SV forward path in lieu of a POV.

a. Procedure

This test was conducted at two speeds, 25 mph (40.2 km/h) and 45 mph (72.4 km/h). The SV was driven directly towards, and over, the STP, which was positioned in the center of a travel lane, with its longest sides parallel to the road edge.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The SV speed could not deviate from the nominal speed by more than 1.0 mph (1.6 kph) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to trew where:
 - For SV test speed of 25 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 187 ft (57 m).
 - For SV test speed of 45 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 337 ft (106 m).
- If the SV did not present an FCW alert before the end of the validity period,
 SV speed could not deviate more than ±1.0 mph (±1.6 km/h) from TTC =
 5.1 s to the end of the validity period.

If an FCW alert was presented, the driver released the throttle pedal within 500 ms of the alert. If no alert was presented, the driver did not release the throttle pedal until the end of the validity period. The SV driver then braked to a stop.

b. Criteria

In order to pass the False Positive test series, the magnitude of the SV deceleration reduction attributable to CIB intervention must have been ≤ 0.50 g for at least five of seven valid test trials.

B. General Information

1. trcw

The time at which the Forward Collision Warning (FCW) activation flag indicates that the system has issued an alert to the SV driver is designated as tecw. FCW alerts are typically either haptic or audible, and the onset of the alert was determined by post-processing the test data.

For systems that implement audible or haptic alerts, part of the pre-test instrumentation verification process was to determine the tonal frequency of the

audible warning or the vibration frequency of the tactile warning through use of the PSD (Power Spectral Density) function in Matlab. This was accomplished in order to identify the center frequency around which a band-pass filter was applied to subsequent audible or tactile warning data so that the beginning of such warnings can be programmatically determined. The bandpass filter used for these warning signal types was a phaseless, forward-reverse pass, elliptical (Cauer) digital filter, with filter parameters as listed in Table 1.

Table 1. Audible and Tactile Warning Filter Parameters

Warning Type	Filter Order	Peak-to- Peak Ripple	Minimum Stop Band Attenuation	Pass-Band Frequency Range
Audible	5 th	3 dB	60 dB	Identified Center Frequency ± 5%
Tactile	5 th	3 dB	60 dB	Identified Center Frequency ± 20%

2. General Validity Criteria

In addition to any validity criteria described above for the individual test scenarios, for an individual trial to be valid, it must have met the following criteria throughout the test:

- The SV driver seatbelt was latched.
- If any load had been placed on the SV front passenger seat (e.g., for instrumentation), the vehicle's front passenger seatbelt was latched.
- The SV was driven at the nominal speed in the center of the travel lane, toward the POV or STP.
- The driver used the least amount of steering input necessary to maintain SV position in the center of the travel lane during the validity period; use of abrupt steering inputs or corrections was avoided.
- The yaw rate of the SV did not exceed ±1.0 deg/s from the onset of the validity period to the instant SV deceleration exceeded 0.25g.
- The SV driver did not apply any force to the brake pedal during the applicable validity period.
- The lateral distance between the centerline of the SV and the centerline of the POV or STP did not deviate more than ±1 ft (0.3 m) during the applicable validity period.

3. Validity Period

The valid test interval began:

Test 1: When the SV-to-POV TTC = 5.1 seconds

Test 2: When the SV-to-POV TTC = 5.0 seconds

Test 3: 3 seconds before the onset of POV braking

Test 4: When the SV-to-STP TTC = 5.1 seconds

The valid test interval ended:

Test 1: When either of the following occurred:

- The SV came into contact with the POV (SV-to-POV contact was assessed by using GPS-based range data or by measurement of direct contact sensor output); or
- The SV came to a stop before making contact with the POV.

Tests 2 and 3: When either of the following occurred:

- The SV came into contact with the POV;
 or
- 1 second after the velocity of the SV became less than or equal to that of the POV.
- 1 second after minimal longitudinal SV-POV distance occurred.

Test 4: At the instant the front most part of SV reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it was driven onto the STP).

4. Static Instrumentation Calibration

To assist in resolving uncertain test data, static calibration data was collected prior to each of the test series.

For Tests 1, 2, and 3, the SV, POV, and POV moving platform and tow vehicle were centered in the same travel lane with the same orientation (i.e., facing

the same direction). For Test 4, the SV and STP were centered in the same travel lane.

For Tests 1, 2, and 3, the SV was positioned such that it just contacted a vertical plane that defines the rearmost location of the POV. For Test 4, the front-most location of the SV was positioned such that it just reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it is driven onto the STP). This is the "zero position."

The zero position was documented prior to, and immediately after, conduct of each test series.

If the zero position reported by the data acquisition system was found to differ by more than ± 2 in (± 5 cm) from that measured during collection of the pretest static calibration data file, the pre-test longitudinal offset was adjusted to output zero and another pre-test static calibration data file was collected. If the zero position reported by the data acquisition system was found to differ by more than ± 2 in (± 5 cm) from that measured during collection of the post-test static calibration data file, the test trials performed between collection of that post-test static calibration data file and the last valid pre-test static calibration data file were repeated.

Static data files were collected prior to, and immediately after, conduct each of the test series. The pre-test static files were reviewed prior to test conduct to confirm that all data channels were operational and were properly configured.

5. Number of Trials

A target total of seven (7) valid trials were performed for each scenario. In cases where the test driver performed more than seven trials, the first seven trials satisfying all test tolerances were used to assess the SV performance.

6. Transmission

All trials were performed with SV automatic transmissions in "Drive" or with manual transmissions in the highest gear capable of sustaining the desired test speed. Manual transmission clutches remained engaged during all maneuvers. The brake lights of the POV were not illuminated.

C. Principal Other Vehicle

CIB testing requires a POV that realistically represents typical vehicles, does not suffer damage or cause damage to a test vehicle in the event of collision, and can be accurately positioned and moved during the tests. The tests reported herein made use of the NHTSA developed Strikeable Surrogate Vehicle (SSV).

The SSV system was designed specifically for common rear-end crash scenarios which AEB systems address. The key elements of the SSV system are:

- POV element, whose requirements are to:
 - Provide an accurate representation of a real vehicle to CIB sensors, including cameras, radar and lidar.
 - Be resistant to damage and inflict little or no damage to the SV as a result of repeated SV-to-POV impacts.
- POV delivery system whose requirements are to:
 - Accurately control the nominal POV speed up to 35 mph (56 km/h).
 - Accurately control the lateral position of the POV within the travel lane.
 - Allow the POV to move away from the SV after an impact occurs.

The key components of the SSV system are:

- A POV shell which is a visually and dimensionally accurate representation of a passenger car
- A slider and load frame assembly to which the shell is attached
- A two-rail track on which the slider operates
- A road-based lateral restraint track
- A tow vehicle

Operationally, the POV shell is attached to the slider and load frame which includes rollers that allows the entire assembly to move longitudinally along the guide rail. The guide rail is coupled to a tow vehicle and guided by the lateral restraint track secured to the test track surface. The rail includes a provision for restraining the shell and roller assembly in the ward direction. In operation, the shell and roller assembly engage the rail assembly through detents to prevent relative motion during run-up to test speeds and deceleration of the tow vehicle. The combination of rearward stops and forward motion detents allows the test conditions, such as relative POV-SV headway distance, speed, etc., to be achieved and adjusted as needed in the preliminary part of a test. If during the test, the SV strikes the rear of the POV shell, the detents are overcome and the entire shell/roller assembly moves forward in a two-stage manner along the rail and away

from the SV. The forward end of the rail has a cushioned stop to restrain forward motion of the shell/roller assembly. After impacting the SSV, the SV driver uses the steering wheel to maintain SV position in the center of the travel lane, thereby straddling the two-rail track. The SV driver must manually apply the SV brakes after impact. The SSV system is shown in Figures A6 through A8 and a detailed description can be found in the NHTSA report: NHTSA'S STRIKEABLE SURROGATE VEHICLE PRELIMINARY DESIGN + OVERVIEW, May 2013.

D. Automatic Braking System

The POV was equipped with an automatic braking system, which was used in Test 3. The braking system consisted of the following components:

- Electronically controlled linear actuator, mounted on the seat rail and attached to the brake pedal. The actuator can be programmed for control of stroke and rate.
- PC module programmed for control of the stroke and rate of the linear actuator.
- Switch to activate actuator.

In some cases, the subject vehicle is also equipped with an automatic braking system (E-brake) for the purpose of slowing the subject vehicle before impact with the SSV in cases where the subject vehicle is likely to fail a test. The system fires when TTC is below 0.7 sec. It is typically enabled when an SV has already impacted the SSV one or two times.

E. Instrumentation

Table 2 lists the sensors, signal conditioning, and data acquisition equipment used for these tests.

TABLE 2. TEST INSTRUMENTATION AND EQUIPMENT

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Tire Pressure Gauge	Vehicle Tire Pressure	0-100 psi 0-690 kPa	< 1% error between 20 and	Omega DPG8001	17042707002	By: DRI Date: 6/21/2018 Due: 6/21/2019
Platform Scales	Vehicle Total, Wheel, and Axle Load	1200 lb/platform 5338 N/	0.5% of applied load	Intercomp SWI	1110M206352	By: DRI Date: 1/3/2019 Due: 1/3/2020
Linear (string) encoder	Throttle pedal travel	10 in 254 mm	0.1 in 2.54 mm	UniMeasure LX-EP	45050092	By: DRI Date: 5/1/2018 Due: 5/1/2019
Differential Global Positioning System	Position, Velocity	Latitude: ±90 deg Longitude: ±180 deg Altitude: 0-18 km Velocity: 0-1000 knots	Horizontal Position: ±1 cm Vertical Position: ±2 cm Velocity: 0.05 km/h	Trimble GPS Receiver, 5700 (base station and in-vehicle)	00440100989	NA
Multi-Axis Inertial Sensing System	Position; Longitudinal, Lateral, and Vertical Accels; Lateral, Longitudinal and Vertical Velocities;	Accels ± 10g, Angular Rat	Accels .01g, Angular Rate	Oxford Inertial +	2182	By: Oxford Technical Solutions Date: 10/16/2017 Due: 10/16/2019

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
	Roll, Pitch, Yaw Rates; Roll, Pitch, Yaw Angles				2176	Date: 4/11/2018 Due: 4/11/2020

TABLE 2. TEST INSTRUMENTATION AND EQUIPMENT

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Real-Time Calculation of Position and Velocity Relative to Lane Markings (LDW) and POV (FCW)	Distance and Velocity to lane markings (LDW) and POV (FCW)	Lateral Lane Dist: ±30 m Lateral Lane Velocity: ±20 m/sec Longitudinal Range to POV: ±200 m Longitudinal Range Rate: ±50 m/sec	Lateral Distance to Lane Marking: ±2 cm Lateral Velocity to Lane Marking: ±0.02m/sec Longitudinal Range: ±3 cm Longitudinal Range Rate: ±0.02 m/sec	Oxford Technical Solutions (OXTS), RT-Range	97	NA
Microphone	Sound (to measure time at alert)	Frequency Response: 80 Hz – 20 kHz	Signal-to-noise: 64 dB, 1 kHz at 1 Pa	Audio-Technica AT899	NA	NA
Light Sensor	Light intensity (to measure time at alert)	Spectral Bandwidth: 440-800 nm	Rise time < 10 msec	DRI designed and developed Light Sensor	NA	NA
Accelerometer	Acceleration (to measure time at alert)	±5g	≤ 3% of full range	Silicon Designs, 2210-005	NA	NA

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Coordinate Measurement Machine	Inertial Sensing System Coordinates	0-8 ft 0-2.4 m	±.0020 in. ±.051 mm (Single point articulation accuracy)	Faro Arm, Fusion	UO8-05-08- 06636	By: DRI Date: 1/2/2019 Due: 1/2/2020
Туре	Data acquisition is achieved using a dSPACE MicroAutoBox II.		Mfr, Mo	Serial Number		
			D-Space Micro-Autobox II 1401/1513			
Data Acquisition System	Data from the Oxford IMU, including Longitudinal, Lateral, and Vertical Acceleration, Roll, Yaw, and Pitch Rate, Forward and Lateral Velocity, Roll and Pitch Angle are sent over Ethernet to the MicroAutoBox. The Oxford IMUs are calibrated per the manufacturer's recommended schedule (listed above).			Base Board		549068
				I/O Board	588523	

APPENDIX A

Photographs

LIST OF FIGURES

		Page
Figure A1.	Front View of Subject Vehicle	A-3
Figure A2.	Rear View of Subject Vehicle	A-4
Figure A3.	Window Sticker (Monroney Label)	A-5
Figure A4.	Vehicle Certification Label	A-6
Figure A5.	Tire Placard	A-7
Figure A6.	Rear View of Principal Other Vehicle (SSV)	A-8
Figure A7.	Load Frame/Slider of SSV	A-9
Figure A8.	Two-Rail Track and Road-Based Lateral Restraint Track	A-10
Figure A9.	Steel Trench Plate	A-11
Figure A10.	DGPS, Inertial Measurement Unit and MicroAutoBox Installed in Subject Vehicle	A-12
Figure A11.	Sensors for Detecting Visual and Auditory Alerts	A-13
Figure A12.	Computer Installed in Subject Vehicle	A-14
Figure A13.	Brake Actuator Installed in POV System	A-15
Figure A14.	Visual Alert	A-16
Figure A15.	AEB Setup Menus	A-17
Figure A16.	Steering Wheel Mounted Controls	A-18
Figure A17.	AEB on Off Switch	A-19



Figure A1. Front View of Subject Vehicle



Figure A2. Rear View of Subject Vehicle




Figure A3. Window Sticker (Monroney Label)



Figure A4. Vehicle Certification Label



Figure A5. Tire Placard



Figure A6. Rear View of Principal Other Vehicle (SSV)



Figure A7. Load Frame/Slider of SSV






Figure A9. Steel Trench Plate



Figure A10. DGPS, Inertial Measurement Unit and MicroAutoBox Installed in Subject Vehicle



Figure A11. Sensors for Detecting Visual and Auditory Alerts




Figure A12. Computer Installed in Subject Vehicle



Figure A13. Brake Actuator Installed in POV System



Figure A14. Visual Alert




Figure A15. AEB Setup Menus



Figure A16. Steering Wheel Mounted Controls





Figure A17. AEB on Off Switch

APPENDIX B

Excerpts from Owner's Manual

Visual Index






* Not available on all models

Instrument Panel

Gauges (CRITTO) Driver Information Interface (CRITTO) System Indicators (CRITTO) Privalent (CRITTO) (C



VSA[®] On and Off **◯**₹554

- The Vehicle Stability Assist® (VSA®) system helps stabilize the vehicle during cornering, and helps maintain traction while accelerating on loose or slippery road surfaces.
- VSA® comes on automatically every time you start the engine.
- To partially disable or fully restore VSA® function, press and hold the button until you hear a beep.

CMBS™ On and Off

- When a possible collision is likely unavoidable, the CMBS™ can help you to reduce the vehicle speed and the severity
- of the collision.

 The CMBS™ is turned on every time you start the engine.
- To turn the CMBS™ on or off, press and hold the button until you hear a beep.

Tire Pressure Monitoring System (TPMS) with Tire Fill Assist R 562,710

- The TPMS monitors tire pressure.
 TPMS is turned on automatically every time you start the engine.
- TPMS fill assist provides audible and visual guidance during tire pressure adjustment.

Refueling Refueling

Fuel recommendation: Unleaded gasoline, pump octane number 87 or higher

Fuel tank capacity: 19.5 US gal (73.8 L)

Press the fuel fill door release button.




After refueling, wait for about five seconds before removing the filler nozzle.



Honda Sensing®

Honda Sensing® is a driver support system which employs the use of two distinctly different kinds of sensors, a radar sensor located behind the emblem and a front sensor camera mounted to the interior side of the windshield, behind the rear view mirror.

The camera is located behind the rearview mirror.



The radar sensor is behind the emblem.

Collision Mitigation Braking System™ (CMBS™) →R569

Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS™ is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

Adaptive Cruise Control (ACC)

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours, without you having to keep your foot on the brake or the accelerator.

Lane Keeping Assist System (LKAS) (CRES)

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

Road Departure Mitigation (RDM) System

→P 603

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

Indicator	Name	On/Blinking	Explanation	Message
ACC	Adaptive Cruise Control (ACC) Indicator (Amber)	 Comes on for a few seconds when you set the power mode to ON, then goes off. Comes on if there is a problem with ACC. 	Comes on while driving - Have your vehicle checked by a dealer.	Adadore Craise Control phopsess
ACC	Adaptive Cruise Control (ACC) Indicator (Green)	Comes on when you press the MAIN button.	☑ Adaptive Cruise Control (ACC) P. 581	-
*	Collision Mitigation Braking System™ (CMBS™) Indicator	 Comes on for a few seconds when you change the power mode to ON, then goes off. Comes on when you deactivate the CMBSTM. A driver information interface message appears for five seconds. Comes on if there is a problem with the CMBSTM. 	Stays on constantly without the CMBS™ off - Have your vehicle checked by a dealer. Collision Mitigation Braking System™ (CMBS™) P. 569	College Missalson System Missalson System Missalson Stream Missalson Stream System CPT

Indicator	Name	On/Blinking	Explanation	Message
****	Collision Mitigation Braking System™ (CMBS™) Indicator	Comes on when the CMBS™ system shuts itself off.	Stays on - The temperature inside the camera is too high. Use the heating and cooling system '/climate control system' to cool down the camera. The system activates when the temperature inside the camera cools down. Front Sensor Camera P. 608	Some Driver Autost Synthesis Current Operator States Tendenmentario Top States
			 Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. Front Sensor Camera P. 608 	Come Driver Assist. Systems Common Operation Clean Front Weedshield
			 When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. Have your vehicle checked by a dealer if the indicator does not go off even after you clean the sensor cover. Radar Sensor P. 610 	Some briess Autol Some Orders (Secretar Bridge Orders (Secretar

94 * Not available on all models

Message	Condition	Explanation
BRAKE	Flashes when the system senses a likely collision with a vehicle in front of you.	Take the appropriate means to prevent a collision (apply the brakes, change lanes, etc.) Collision Mitigation Braking System™ (CMBS™) P. 569 Adaptive Cruise Control (ACC) P. 581
ACC OFF	 Appears when ACC has been automatically canceled. 	You can resume the set speed after the condition that caused ACC to cancel improves. Press the RES/+ button. Adaptive Cruise Control (ACC) P. 581
Cernol Set Crake: Brace Pedal Is Applied	Appears when pressing the –/SET button while the vehicle is moving and the brake pedal is depressed.	ACC cannot be set. Adaptive Cruise Control (ACC) P. 581
Cruise Cancelline. Loss Of Traction	 Appears if the VSA® or traction control function operates while ACC is in operation. 	ACC has been automatically canceled. ■ Adaptive Cruise Control (ACC) P. 581
Carnol Set Orales: Secol Loo High	 Appears when the speed of the vehicle is too high for you to set ACC. 	Reduce the speed, then set ACC. Adaptive Cruise Control (ACC) P. 581
Craise Cancelline. Speed Too High	 Appears when ACC is canceled due to excessive vehicle speed. 	Reduce the speed, then reset ACC. Adaptive Cruise Control (ACC) P. 581
Cannot Set Crute: Speed Too Low	Appears when the speed of the vehicle is too low for you to set ACC.	 Raise the speed, then set ACC. Adaptive Cruise Control (ACC) P. 581

■ List of customizable options

Setup Group	Customizable Features	Description	Selectable settings	
Meter Setup	Language Selection	Changes the displayed language.	English*¹/Français/Español	
	"Trip A" Reset Timing	Changes the setting of how the distance and average fuel economy of trip computer A is reset.	When Fully Refueled/IGN OFF/ Manually Reset*1	
	"Trip B" Reset Timing	Changes the setting of how the distance and average fuel economy of trip computer B is reset.	When Fully Refueled/IGN OFF/ Manually Reset*1	
	Adjust Alarm Volume	Changes the volume setting for buzzers, warnings, turn signals, and other alerting systems.	High/Mid*1/Low	
	Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	ON*1/OFF	
Driver Assist System Setup	Forward Collision Warning Distance	Changes the distance at which CMBS™ alerts.	Long/Normal*1/Short	
	ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of ACC range.	ON/OFF*1	
	Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal*1/Wide/Warning Only	
	Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	ON/OFF*1	

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Kaylass Assass	Remote Start System On/Off	Turns the remote engine start feature on and off.	ON*1/OFF
	Keyless Access Setup	Walk Away Auto Lock	Changes the settings for the automatic locking the doors when you walk away from the vehicle while carrying the remote.	Enable/Disable*1
	Driver Assist System Setup	Forward Collision Warning Distance	Changes at which distance CMBS™ alerts.	Long/Normal*1/ Short
		ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC range.	ON/OFF*1
		Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal*1/Wide/ Warning Only
		Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	ON/OFF*1
		Blind Spot Information	Changes the setting for the blind spot information.	Audible and Visual Alert*1/Visual Alert/ OFF


^{*1:}Default Setting

* Not available on all models Continued 445

Collision Mitigation Braking System™ (CMBS™)

Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS™ is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

■ How the system works



The system starts monitoring the roadway ahead when your vehicle speed is about 3 mph (5 km/h) and there is a vehicle in front of you.

The CMBS™ activates when:

- The speed difference between your vehicle and a vehicle or pedestrian detected in front of you becomes about 3 mph (5 km/h) and over with a chance of a collision.
- Your vehicle speed is about 62 mph (100 km/h) or less and there is a chance of a collision with an oncoming detected vehicle or a pedestrian in front of you.

■Collision Mitigation Braking System™ (CMBS™)

Important Safety Reminder

The CMBS™ is designed to reduce the severity of an unavoidable collision. It does not prevent a collision nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS™ may not activate or may not detect a vehicle in front of your vehicle under certain conditions:

► CMBS™ Conditions and Limitations P. 573

For directions on the proper handling of the radar sensor, refer to the following page. Radar Sensor P. 610

You can read about handling information for the camera equipped with this system.

Front Sensor Camera P. 608

Mow the system works

Rapid vibrations on the steering wheel alert you when the your vehicle speed is between 19 and 62 mph (30 and 100 km/h) with an oncoming vehicle detected in front of you.

When the CMBS™ activates, it may automatically apply the brake. It will be canceled when your vehicle stops or a potential collision is not determined.

■ When the system activates

The system provides visual, audible and tactile alerts of a possible collision, and stops if the collision is avoided.

▶ Take appropriate action to prevent a collision (apply the brakes, change



At system's earliest collision alert stage, you can change the distance (Long/ Normal/Short) between vehicles at which alerts will come on through the driver information interface or the audio/information screen setting options.

■ Customized Features P. 125, 432

■ Vibration alert on the steering wheel

When a potential collision to an oncoming detected vehicle is determined, the system alerts you with rapid vibration on the steering wheel, in addition to visual and audible alerts.

Take appropriate action to prevent a collision (apply the brakes, operate the steering wheel, etc.).

₩When the system activates

The camera in the CMBS™ is also designed to detect

However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions.

Refer to the ones indicating the pedestrian detection limitations from the list.

■ CMBS[™] Conditions and Limitations P. 573

Vibration alert function is disabled when the electric power steering (EPS) system indicator comes on.

Driver Information Interface Warning and Information Messages P. 96

■ Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS $^{\text{TM}}$ may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS™				
		The sensors detect a vehicle	Audible & Visual WARNINGS	Steering Wheel	Braking	
Stage one	Normal Vehicle Long Short Ahead Your Vehicle	There is a risk of a collision with the vehicle ahead of you.	When in Long , visual and audible alerts come on at a longer distance from a vehicle ahead than in Normal setting, and in Short , at a shorter distance than in Normal .	In case of an oncoming vehicle detected, rapid vibration is provided.	-	
Stage two	Your Vehicle Ahead	The risk of a collision has increased, time to respond is reduced.	Visual and audible alerts.	-	Lightly applied	
Stage three	Your Vehicle Ahead	The CMBS™ determines that a collision is unavoidable.	visuai ariu audibie aleris.	-	Forcefully applied	

■ CMBS[™] On and Off



Press and hold the button until the beeper sounds to switch the system on or off.

When the CMBS™ is off:

- The CMBS™ indicator in the instrument panel comes on.
- A message on the driver information interface reminds you that the system is off.

The CMBS $^{\text{TM}}$ is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

™Collision Mitigation Braking System™ (CMBS™)

The CMBS™ may automatically shut off, and the CMBS™ indicator will come and stay on under certain

Driving

■ CMBS™ Conditions and Limitations

The system may automatically shut off and the CMBS $^{\text{IM}}$ indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the CMBS $^{\text{IM}}$ functions.

Front Sensor Camera P. 608

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- · Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on curvy, winding, or undulating roads.

574

■ Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
 The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
 Driving with the parking brake applied.
- When the radar sensor behind the emblem gets dirty.
- The vehicle is towing a trailer.

■ Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.

Limitations applicable to pedestrian detection only

- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
- When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

577

■ Automatic shutoff

 $\mathsf{CMBS^{TM}}\ \mathsf{may}\ \mathsf{automatically}\ \mathsf{shut}\ \mathsf{itself}\ \mathsf{off}\ \mathsf{and}\ \mathsf{the}\ \mathsf{CMBS^{TM}}\ \mathsf{indicator}\ \mathsf{comes}\ \mathsf{and}\ \mathsf{stays}$

- The temperature inside the system is high.
 You drive off-road or on a mountain road, or curved and winding road for an extended period.
- An abnormal tire condition is detected (wrong tire size, flat tire, etc.).
 The camera behind the rearview mirror, or the area around the camera, including

the windshield, gets dirty.

Once the conditions that caused CMBS™ to shut off improve or are addressed (e.g., cleaning), the system comes back on.

■ With Little Chance of a Collision


The CMBS $^{\text{IM}}$ may activate even when you are aware of a vehicle ahead of you, or when there is no vehicle ahead. Some examples of this are:

■ When Passing

Your vehicle approaches another vehicle ahead of you and you change lanes to pass.

■ At an intersection

Your vehicle approaches or passes another vehicle that is making a left or right turn.




™Collision Mitigation Braking System™ (CMBS™)

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

■ On a curve


When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.



■ Through a low bridge at high speed
You drive under a low or narrow bridge at high speed.



■ Speed bumps, road work sites, train tracks, roadside objects, etc.
You drive over speed bumps, steel road plates, etc., or your vehicle approaches train tracks or roadside objects [such as a traffic sign and guard rail] on a curve or, when parking, stationary vehicles and walls.



■ How to activate the system



MAdaptive Cruise Control (ACC)

Adaptive Cruise Control (ACC)

MADE CRUISE CONTROL

ACC

MADE CRUISE CONTROL

ACC

MADE CRUISE CONTROL

ACC

MADE CRUISE CONTROL

ACC

MADE CRUISE CONTROL

MADE CRUISE CRUISE

MADE CRUISE CRUISE

MADE CRUISE CRUISE

MADE CRUISE CRUISE

MADE CRUISE

MAD

Important Reminder

As with any system, there are limits to ACC. Use the brake pedal whenever necessary, and always keep a safe interval between your vehicle and other vehicles.

You can read about handling information for the camera equipped with this system.

Front Sensor Camera P. 608

The radar sensor for ACC is shared with the Collision Mitigation Braking System™ (CMBS™).

Collision Mitigation Braking System™ (CMBS™) P. 569

Front Sensor Camera

The camera, used in systems such as LKAS, RDM, ACC, and CMBSTM, is designed to detect an object that triggers any of the systems to operate its functions.

■ Camera Location and Handling Tips



This camera is located behind the rearview mirror.

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

Never apply a film or attach any objects to the windshield, the hood, or the front grill that could obstruct the camera's field of vision and cause the system to operate abnormally. Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Honda replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

riving

608

The radar sensor is behind the emblem.

■ Radar Sensor

Avoid strong impacts to the radar sensor cover.

For the CMBS $^{\text{TM}}$ to work properly:

Always keep the radar sensor cover clean.

Never use chemical solvents or polishing powder for cleaning the sensor cover. Clean it with water or a mild detergent.

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by using the safety support switch and take your vehicle to a dealer. **■ CMBS™ On and Off** P. 572

If the vehicle is involved in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- Your vehicle is involved in a frontal collision
 Your vehicle drives through deep water or is submerged in deep water
 Your vehicle strongly strikes a bump, curb, chock, or embankment that could jar the radar sensor

610

APPENDIX C

Run Log

Subject Vehicle: 2019 Honda Pilot Test Date: 2/12/2019

Principal Other Vehicle: **SSV**

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
1	Static Run								
2	Stopped POV	N							Throttle Release
3		Υ	2.01	5.61	24.2	0.93	1.30	Pass	
4		Υ	1.98	6.18	24.5	0.94	1.35	Pass	
5		Υ	2.05	7.28	24.3	0.95	1.36	Pass	
6		Υ	2.00	6.19	24.3	0.89	1.33	Pass	
7		N							SV Speed
8		N							GPS-Fixed Error
9		Υ	2.00	2.03	24.0	0.90	0.83	Pass	
10		Υ	2.09	6.44	24.3	0.95	1.35	Pass	
11	Static Run								
12	Slower POV, 25 vs 10	Υ	1.90	3.49	14.5	0.87	1.10	Pass	
13		N							SV Speed
14		N							Lateral Offset
15		N							SV Speed

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
16		N							SV Speed
17		Y	1.82	9.21	14.0	0.90	1.11	Pass	
18		Υ	1.85	4.62	14.4	0.93	1.15	Pass	
19		Υ	1.85	4.66	14.6	0.90	1.15	Pass	
20		Υ	1.78	10.21	14.2	0.89	1.12	Pass	
21		Υ	1.92	4.86	14.7	0.91	1.14	Pass	
22		Υ	1.87	4.73	13.7	0.91	1.11	Pass	
23	Static Run								
24	Slower POV, 45 vs 20	N							SV Speed
25		N							Lat Offset, SV Speed, Yaw Rate
26		N							Lat Offset, SV Speed, Yaw Rate
27		Ν							Throttle Release
28		N							SV Speed, Throttle Release
29		Υ	2.00	18.71	24.5	0.95	1.41	Pass	
30		Y	1.96	16.80	25.1	0.96	1.30	Pass	
31		Υ	1.93	11.80	24.8	0.93	1.45	Pass	
32		Υ	1.91	6.86	24.7	0.99	1.20	Pass	
33		Y	1.91	13.06	24.5	0.96	1.25	Pass	
34		N							Throttle Release
35		Y	1.99	15.69	25.0	0.96	1.31	Pass	

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
36	Static run								
37	STP False Positive, 25	N							Throttle Release
38		Υ	1.99			0.02		Pass	
39		Υ	2.08			0.02		Pass	
40		Υ	1.86			0.03		Pass	
41		Υ	2.14			0.02		Pass	
42		Υ	1.81			0.03		Pass	
43		Υ	2.04			0.01		Pass	
44		Υ	2.13			0.02		Pass	
45	STP - Static Run								
46	STP - Static Run								
47	STP False Positive, 45	N							SV Speed
48		Υ	2.42			0.03		Pass	
49		N							Throttle Release
50		N							SV Speed, Yaw Rate, Lat Offset
51		N							SV Speed

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
52		N							SV Speed
53		Υ	1.56			0.03		Pass	
54		Υ	1.22			0.07		Pass	
55		Υ	1.53			0.05		Pass	
56		Υ	1.58			0.05		Pass	
57		Υ	1.33			0.06		Pass	
58		Υ	0.72			0.06		Pass	
59	STP - Static Run								
60	Static Run								
61	Braking POV, 35	N							Lat Offset
62		N							SV Speed
63		Υ	1.87	3.50	21.7	1.03	0.85	Pass	
64		N							Lat Offset
65		N							Lat Offset
66		Υ	1.76	4.04	21.8	1.06	0.82	Pass	
67		N							Throttle Release
68		Υ	1.85	4.37	23.0	1.07	0.80	Pass	
69		N							SV Speed
70		Υ	2.04	3.89	23.5	1.07	0.82	Pass	
71		Y	1.84	2.47	34.6	1.06	0.81	Pass	

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
72		Υ	1.72	3.20	21.5	1.03	0.84	Pass	
73		Υ	2.06	3.63	21.1	1.02	0.81	Pass	
74	Static Run								

APPENDIX D

Time History Plots

LIST OF FIGURES

				Pa	age
Figure	D1.	Example Time	History	for Stopped POV, Passing	9
Figure	D2.	Example Time	History	for Slower POV 25 vs. 10, Passing	10
Figure	D3.	Example Time	History	for Slower POV 45 vs. 20, Passing	11
Figure	D4.	Example Time	History	for Braking POV 35, Passing	12
Figure	D5.	Example Time	History	for False Positive STP 25, Passing	13
Figure	D6.	Example Time	History	for False Positive STP 45, Passing	14
Figure	D7.	Example Time	History	Displaying Various Invalid Criteria	15
Figure	D8.	Example Time	History	Displaying Various Invalid Criteria	16
Figure	D9.	Example Time	History	for a Failed Run	17
Figure	D10.	Time History	for CIB	Run 3, SV Encounters Stopped POV	18
Figure	D11.	Time History	for CIB	Run 4, SV Encounters Stopped POV	19
Figure	D12.	Time History	for CIB	Run 5, SV Encounters Stopped POV	20
Figure	D13.	Time History	for CIB	Run 6, SV Encounters Stopped POV	21
Figure	D14.	Time History	for CIB	Run 9, SV Encounters Stopped POV	22
Figure	D15.	Time History	for CIB	Run 10, SV Encounters Stopped POV	23
Figure	D16.	,		Run 12, SV Encounters Slower POV, SV 25	24
Figure	D17.	-		Run 17, SV Encounters Slower POV, SV 25	25
Figure	D18.	Time History	for CIB	Run 18, SV Encounters Slower POV, SV 25	
Figure	D19.	Time History	for CIB	Run 19, SV Encounters Slower POV, SV 25	
Figure	D20.			Run 20, SV Encounters Slower POV, SV 25	28
Figure	D21.	-		Run 21, SV Encounters Slower POV, SV 25	29
Figure	D22.			Run 22, SV Encounters Slower POV, SV 25	30
Figure	D23.			Run 29, SV Encounters Slower POV, SV 45	31
Figure	D24.			Run 30, SV Encounters Slower POV, SV 45	32
Figure	D25.	-		Run 31, SV Encounters Slower POV, SV 45	33
Figure	D26.			Run 32, SV Encounters Slower POV, SV 45	34
Figure	D27.	•		Run 33, SV Encounters Slower POV, SV 45	35

Figure D28.							Slower POV	, SV 45) 	36
Figure D29.		•					Decelerating			37
Figure D30.	Time	History for	CIB Run	66,	SV	Encounters		POV,	SV	38
Figure D31.	Time	History for	CIB Run	68,	SV	Encounters		POV,	SV	39
Figure D32.		-					Decelerating			40
Figure D33.							Decelerating			41
Figure D34.		•					Decelerating			42
Figure D35.							Decelerating			43
Figure D36.		•					Steel Trench			44
Figure D37.		•					Steel Trench			45
Figure D38.		-					Steel Trench		SV	46
Figure D39.		•					Steel Trench			47
Figure D40.		•					Steel Trench			48
Figure D41.		•		-			Steel Trench	-		49
Figure D42.	Time	History for	CIB Run	44,	sv	Encounters		n Plate,	SV	50
Figure D43.		•					Steel Trench			51
Figure D44.	Time	History for	CIB Run	53,	sv	Encounters		n Plate,	SV	
Figure D45.	Time	History for	CIB Run	54,	SV	Encounters		n Plate,	SV	
Figure D46.	Time	History for	CIB Run	55,	SV	Encounters		n Plate,	SV	
Figure D47.	Time	History for	CIB Run	56,	sv	Encounters		n Plate,	SV	
Figure D48.	Time	History for	CIB Run	57,	sv	Encounters		n Plate,	SV	
Figure D49.	Time	History for	CIB Run	58,	SV	Encounters		n Plate,	SV	

Description of Time History Plots

A set of time history plots is provided for each valid run in the test series. Each set of plots comprises time varying data from both the Subject Vehicle (SV) and the Principal Other Vehicle (POV), as well as pass/fail envelopes and thresholds. The following is a description of data types shown in the time history plots, as well as a description of the color codes indicating to which vehicle the data pertain.

Time History Plot Description

Each time history plot consists of data relevant to the test type under consideration, and therefore the data channels plotted vary according to test type. The test types (shown in the plot titles) include:

- Stopped POV (SV at 25 mph)
- Slower POV, 25/10 (SV at 25 mph, POV at 10 mph)
- Slower POV, 45/20 (SV at 45 mph, POV at 20 mph)
- Braking POV 35 mph (Both vehicles at 35 mph with 13.8 m gap, POV brakes at 0.3 g)
- False Positive STP 25 mph (Steel trench plate run over at 25 mph)
- False Positive STP 45 mph (Steel trench plate run over at 45 mph)

Time history figures include the following sub-plots:

- FCW Warning displays the Forward Collision Warning alert (which can be audible, visual, or haptic). Depending on the type of FCW alert or instrumentation used to measure the alert, this can be any combination of the following:
 - o Filtered, rectified, and normalized sound signal. The vertical scale is 0 to 1.
 - Filtered, rectified, and normalized acceleration (i.e., haptic alert, such as steering wheel vibration).
 The vertical scale is 0 to 1.
 - Normalized light sensor signal. The vertical scale is 0 to 1.

As only the audible or haptic alert is perceptible by the driver during a test run, the earliest of either of these alerts is used to define the onset of the FCW alert. A vertical black bar on the plot indicates the TTC (sec) at the first moment of the warning issued by the FCW system. The FCW TTC is displayed to

the right of the subplot in green. For False Positive tests, when the FCW presents a warning "FCW" is shown in red at the right edge of the FCW plot.

- Headway (ft) longitudinal separation (gap) between the frontmost point of the Subject Vehicle and the rearmost point of the Strikeable Surrogate Vehicle (SSV) towed by the Principal Other Vehicle. The minimum headway during the run is displayed to the right of the subplot.
- SV/POV Speed (mph) speed of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the speed reduction experienced by the Subject Vehicle is displayed to the right of the subplot.
- Yaw Rate (deg/sec) yaw rate of the Subject Vehicle and Principal Other Vehicle (if any).
- Lateral Offset (ft) lateral offset within the lane of the Subject Vehicle to the center of the lane of travel. Note that for tests involving the Strikeable Surrogate Vehicle (SSV), the associated lateral restraint track is defined to be the center of the lane of travel. If testing is done with a different POV which does not have a lateral restraint track, lateral offset is defined to be the lateral offset between the SV and POV.
- Ax (g) longitudinal acceleration of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the TTC (sec) at the moment of first CIB activation is displayed to the right of the subplot in green. Also, the peak value of Ax for the SV is shown on the subplot.
- Accelerator Pedal Position (0-1) normalized position of the accelerator pedal. A green dot is displayed if the accelerator pedal was released within 0.5 seconds of the onset of the FCW warning.

Note that the minimum (worst) GPS fix type is displayed in the lower right corner of each page. The only valid fix type is RTK fixed (displayed in green). If the fix type during any portion of the test was anything other than RTK fixed, then "RTK Fixed OR LESS!!" is displayed in red.

Envelopes and Thresholds

Some of the time history plot figures contain either green or yellow envelopes and/or black threshold lines. These envelopes and thresholds are used to programmatically and visually determine the validity of a given test

run. Envelope and threshold exceedances are indicated with either red shading or red asterisks, and red text is placed to the right side of the plot indicating the type of exceedance. Such exceedances indicate either that the test was invalid or that the requirements of the test were not met (i.e., failure of the AEB system).

For plots with green envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope boundaries at any time. Exceedances of a green envelope are indicated by red shading in the area between the measured time-varying data and the envelope boundaries.

For plots with yellow envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope at the beginning (left edge of the boundary) and/or end (right edge), but may exceed the boundary during the time between the left and right edges. Exceedances at the left or right extent of a yellow envelope are indicated by red asterisks.

For the headway plot, a dashed black threshold line indicating a relative headway of zero is displayed. If no impact occurs, a green circle is displayed at the moment of minimum distance. If impact occurs, a red asterisk is displayed at the moment of impact.

For the Ax plot, if the scenario is an AEB brake to stop scenario, a vertical dashed black line is displayed for all plots indicating the moment of first POV braking. The yellow envelope in this case is relevant to the POV braking only. The left edge of the envelope is at 1.5 seconds after the first POV braking. A solid black threshold line extends horizontally 0.5 seconds to the left of the envelope. This threshold line represents the time during which the Ax of the Principal Other Vehicle must first achieve 0.27 g (the upper edge of the envelope). A green circle or red asterisk is displayed at the moment the POV brake level achieves 0.27 g. A green circle indicates that the test was valid (the threshold was crossed during the appropriate interval) and a red asterisk indicates that the test was invalid (the threshold was crossed outside of the appropriate interval). Additionally, for the CIB tests, a dashed black threshold line indicating an Ax of -0.15 g is given to define the onset of CIB activation. When the Subject Vehicle's Ax crosses this threshold, the CIB TTC is calculated and displayed.

Color Codes

Color codes have been adopted to easily identify which data correspond to which vehicle, as well as to indicate the types of envelopes and thresholds used in the plots.

Color codes can be broken into four categories:

- 1. Time-varying data
- 2. Validation envelopes and thresholds
- 3. Individual data points
- 4. Text
- 1. Time-varying data color codes:
 - Blue = Subject Vehicle data
 - Magenta = Principal Other Vehicle data
 - Brown = Relative data between SV and POV (i.e., TTC, lateral offset and headway distance)
- 2. Validation envelope and threshold color codes:
 - Green envelope = time varying data must be within the envelope at all times in order to be valid
 - Yellow envelope = time varying data must be within limits at left and/or right ends
 - Black threshold (Solid) = time varying data must cross this threshold in the time period shown in order to be valid
 - Black threshold (Dashed) = for reference only this can include warning level thresholds, TTC thresholds, and acceleration thresholds
- 3. Individual data point color codes:
 - Green circle = passing or valid value at a given moment in time
 - Red asterisk = failing or invalid value at a given moment in time
- 4. Text color codes:
 - Green = passing or valid value
 - Red = failing or invalid value

Examples of time history plots for each test type (including passing, failing and invalid runs) are shown in Figure 1 through Figure 9. Figures 1 through 6 show passing runs for each of the 6 test types. Figures 7 and 8 show examples of invalid runs. Figure 9 shows an example of a valid test that failed the CIB requirements.

Time history data plots for the tests of the vehicle under consideration herein are provided beginning with Figure 10.




Figure D1. Example Time History for Stopped POV, Passing

CIB Test: Slower POV 25/10 mph




Figure D2. Example Time History for Slower POV 25 vs. 10, Passing

CIB Test: Slower POV 45/20 mph




Figure D3. Example Time History for Slower POV 45 vs. 20, Passing

CIB Test: Braking POV 35 mph




Figure D4. Example Time History for Braking POV 35, Passing

CIB Test: False Positive STP 25 mph




Figure D5. Example Time History for False Positive STP 25, Passing

CIB Test: False Positive STP 45 mph




Figure D6. Example Time History for False Positive STP 45, Passing

CIB Test: Braking POV 35 mph




Figure D7. Example Time History Displaying Various Invalid Criteria

CIB Test: Stopped POV




Figure D8. Example Time History Displaying Various Invalid Criteria

CIB Test: Slower POV 45/20 mph




Figure D9. Example Time History for a Failed Run




Figure D10. Time History for CIB Run 3, SV Encounters Stopped POV




Figure D11. Time History for CIB Run 4, SV Encounters Stopped POV




Figure D12. Time History for CIB Run 5, SV Encounters Stopped POV




Figure D13. Time History for CIB Run 6, SV Encounters Stopped POV




Figure D14. Time History for CIB Run 9, SV Encounters Stopped POV




Figure D15. Time History for CIB Run 10, SV Encounters Stopped POV




Figure D16. Time History for CIB Run 12, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D17. Time History for CIB Run 17, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D18. Time History for CIB Run 18, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D19. Time History for CIB Run 19, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D20. Time History for CIB Run 20, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D21. Time History for CIB Run 21, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D22. Time History for CIB Run 22, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D23. Time History for CIB Run 29, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D24. Time History for CIB Run 30, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D25. Time History for CIB Run 31, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D26. Time History for CIB Run 32, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D27. Time History for CIB Run 33, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D28. Time History for CIB Run 35, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D29. Time History for CIB Run 63, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D30. Time History for CIB Run 66, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D31. Time History for CIB Run 68, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D32. Time History for CIB Run 70, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D33. Time History for CIB Run 71, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D34. Time History for CIB Run 72, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D35. Time History for CIB Run 73, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D36. Time History for CIB Run 38, SV Encounters Steel Trench Plate, SV 25 mph




Figure D37. Time History for CIB Run 39, SV Encounters Steel Trench Plate, SV 25 mph




Figure D38. Time History for CIB Run 40, SV Encounters Steel Trench Plate, SV 25 mph




Figure D39. Time History for CIB Run 41, SV Encounters Steel Trench Plate, SV 25 mph




Figure D40. Time History for CIB Run 42, SV Encounters Steel Trench Plate, SV 25 mph




Figure D41. Time History for CIB Run 43, SV Encounters Steel Trench Plate, SV 25 mph




Figure D42. Time History for CIB Run 44, SV Encounters Steel Trench Plate, SV 25 mph




Figure D43. Time History for CIB Run 48, SV Encounters Steel Trench Plate, SV 45 mph




Figure D44. Time History for CIB Run 53, SV Encounters Steel Trench Plate, SV 45 mph




Figure D45. Time History for CIB Run 54, SV Encounters Steel Trench Plate, SV 45 mph




Figure D46. Time History for CIB Run 55, SV Encounters Steel Trench Plate, SV 45 mph




Figure D47. Time History for CIB Run 56, SV Encounters Steel Trench Plate, SV 45 mph




Figure D48. Time History for CIB Run 57, SV Encounters Steel Trench Plate, SV 45 mph




Figure D49. Time History for CIB Run 58, SV Encounters Steel Trench Plate, SV 45 mph