## NEW CAR ASSESSMENT PROGRAM LANE DEPARTURE WARNING CONFIRMATION TEST NCAP-DRI-LDW-22-14

2022 Volkswagen Taos

## DYNAMIC RESEARCH, INC.

355 Van Ness Avenue, STE 200 Torrance, California 90501



6 May 2022

**Final Report** 

Prepared Under Contract No. DTNH22-14-D-00333

U.S. DEPARTMENT OF TRANSPORTATION
National Highway Traffic Safety Administration
New Car Assessment Program
1200 New Jersey Avenue, SE
West Building, 4<sup>th</sup> Floor (NRM-110)
Washington, DC 20590

Prepared for the Department of Transportation, National Highway Traffic Safety Administration, under Contract No. DTNH22-14-D-00333.

This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings, and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturer's names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products of manufacturers.

Prepared By:	Stephen Rhim	and	Andrew Saldana
	Senior Engineer		Staff Engineer
Date:	6 May 2022		

1. Report No.	Government Accession No.	Recipient's Catalog No.		
NCAP-DRI-LDW-22-14				
4. Title and Subtitle		5. Report Date		
Final Report of Lane Departure Warr Volkswagen Taos.	ning Confirmation Test of a 2022	6 May 2022		
volkswagen raos.		6. Performing Organization Code		
		DRI		
7. Author(s)		8. Performing Organization Report	No.	
Stephen Rhim, Senior Engineer Andrew Saldana, Staff Engineer		DRI-TM-21-139		
9. Performing Organization Name and A	Address	10. Work Unit No.		
Dynamic Research, Inc.				
355 Van Ness Ave, STE 200 Torrance, CA 90501		11. Contract or Grant No.		
Tollando, O/CoooT		DTNH22-14-D-00333		
12. Sponsoring Agency Name and Add	ress	13. Type of Report and Period Cove	ered	
U.S. Department of Transportation National Highway Traffic Safety Ad New Car Assessment Program 1200 New Jersey Avenue, SE, West Building, 4th Floor (NRM-110	Iministration	Final Test Report May 2022		
Washington, DC 20590		14. Sponsoring Agency Code		
		NRM-110		
15. Supplementary Notes				
16. Abstract				
Program's (NCAP's) most current Test P	ect 2022 Volkswagen Taos in accordance v Procedure in docket NHTSA-2006-26555-01 e requirements of the test for all three lane	35 to confirm the performance of a La		
17. Key Words		18. Distribution Statement		
Lane Departure Warning, LDW,		Copies of this report are available from the following:		
New Car Assessment Program, NCAP		NHTSA Technical Reference Di National Highway Traffic Safety 1200 New Jersey Avenue, SE Washington, DC 20590		
19. Security Classif. (of this report)	20. Security Classif. (of this page)	21. No. of Pages	22. Price	
Unclassified	Unclassified	95		

## **TABLE OF CONTENTS**

SEC	CTIO	<u>N</u>	<u>PAGE</u>
١.	INT	RODUCTION	1
II.	DAT	ΓA SHEETS	2
		Data Sheet 1: Test Results Summary	3
		Data Sheet 2: Vehicle Data	4
		Data Sheet 3: Test Conditions	5
		Data Sheet 4: Lane Departure Warning System Operation	7
III.	TES	ST PROCEDURES	10
	A.	Test Procedure Overview	10
	B.	Lane Delineation Markings	11
	C.	Test Validity	13
	D.	Pass/Fail Criteria	14
	E.	Instrumentation	14
APF	PEND	DIX A Photographs	A-1
		DIX B Excerpts from Owner's Manual	
APF	PEND	DIX C Run Log	C-1
APF	PEND	DIX D Time Histories	D-1

#### Section I

#### INTRODUCTION

The test procedure is described in detail in the National Highway Traffic Safety Administration (NHTSA) document "LANE DEPARTURE WARNING SYSTEM CONFIRMATION TEST" dated February of 2013 (Docket No. NHTSA-2006-26555-0135). Its purpose is to confirm the performance of LDW systems installed on light vehicles with gross vehicle weight ratings (GVWR) of up to 10,000 lbs. Current LDW technology relies on sensors to recognize a lane delimiting edge line. As such, the test procedures described in the document rely on painted lines, taped lines, or Botts Dots being present on the test course to emulate those found on public roadways. Although it is impossible to predict what technologies could be used by future LDW systems (e.g., magnetic markers, RADAR reflective striping, ultraviolet paint, infrared, etc.), it is believed that minor modifications to these procedures, when deemed appropriate, could be used to accommodate the evaluation of alternative or more advanced LDW systems.

The purpose of the testing reported herein was to objectively quantify the performance of a Lane Departure Warning system installed on a 2022 Volkswagen Taos. This test is part of the New Car Assessment Program to assess Lane Departure Warning Systems sponsored by the National Highway Traffic Safety Administration under Contract No. DTNH22-14-D-00333.

## Section II

## **DATA SHEETS**

## LANE DEPARTURE WARNING

## **DATA SHEET 1: TEST RESULTS SUMMARY**

# (Page 1 of 1)

## 2022 Volkswagen Taos

VIN: <u>3VVSX7B23NM05xxxx</u>					
Test start date: <u>5/3/2022</u>					
Test end date: <u>5/3/2022</u>					
Lane Departure Warning setting:	<u>N/A</u>				
Test 1 – Continuous White Line		Left:	<u>Pass</u>	Right:	<u>Pass</u>
Test 2 – Dashed Yellow Line		Left:	<u>Pass</u>	Right:	<u>Pass</u>
Test 3 – Botts Dots		Left:	<u>Pass</u>	Right:	<u>Pass</u>
				Overall:	Pass
				<b>C</b> ( <b>C</b> ( <b>C</b> )	
Notes:					

# LANE DEPARTURE WARNING DATA SHEET 2: VEHICLE DATA

(Page 1 of 1)

## 2022 Volkswagen Taos

#### **TEST VEHICLE INFORMATION**

VIN: <u>3VVSX7B23NM05xxxx</u>

Body Style: <u>SUV</u> Color: <u>Platinum Gray Metallic</u>

Date Received: 4/25/2022 Odometer Reading: 54 mi

### DATA FROM VEHICLE'S CERTIFICATON LABEL

<u>VOLKSWAGEN DE MEXICO S.A. DE</u>

Vehicle manufactured by: <u>C.V. MEXICO</u>

Date of manufacture: 03/22

Vehicle Type: MPV

#### **DATA FROM TIRE PLACARD**

Tires size as stated on Tire Placard: Front: 215/50R18

Rear: <u>215/50R18</u>

Recommended cold tire pressure: Front: 250 kPa (36 psi)

Rear: 250 kPa (36 psi)

#### **TIRES**

Tire manufacturer and model: Bridgestone Turanza LS100

Front tire size: 215/50R18 92H

Rear tire size: <u>215/50R18 92H</u>

Front tire DOT prefix: <u>DOT 1V6 YKL10A</u>

Rear tire DOT prefix: <u>DOT 1V6 YKL10A</u>

# LANE DEPARTURE WARNING DATA SHEET 3: TEST CONDITIONS

(Page 1 of 2)

#### 2022 Volkswagen Taos

#### **GENERAL INFORMATION**

Test start date: <u>5/3/2022</u>

Test end date: <u>5/3/2022</u>

#### **AMBIENT CONDITIONS**

Air temperature: <u>18.3 C (65 F)</u>

Wind speed: <u>2.1 m/s (4.6 mph)</u>

- X Wind speed ≤10 m/s (22 mph)
- X Tests were not performed during periods of inclement weather. This includes, but is not limited to, rain, snow, hail, fog, smoke, or ash.
- X Tests were conducted during daylight hours with good atmospheric visibility (defined as an absence of fog and the ability to see clearly for more than 5000 meters). The tests were not conducted with the vehicle oriented into the sun during very low sun angle conditions, where the sun is oriented 15 degrees or less from horizontal, and camera "washout" or system inoperability results.

#### **VEHICLE PREPARATION**

## Verify the following:

All non-consumable fluids at 100% capacity:	X	
Fuel tank is full:	Х	
Tire pressures are set to manufacturer's	X	
recommended cold tire pressure:		

Front: <u>250 kPa (36 psi)</u>

Rear: 250 kPa (36 psi)

## **LANE DEPARTURE WARNING**

## **DATA SHEET 3: TEST CONDITIONS**

(Page 2 of 2)

## 2022 Volkswagen Taos

## **WEIGHT**

Weight of vehicle as tested including driver and instrumentation

Left Front: 486.7 kg (1073 lb) Right Front: 449.5 kg (991 lb)

Left Rear: 329.8 kg (727 lb) Right Rear: 328.4 kg (724 lb)

Total: <u>1594.4 kg (3515 lb)</u>

# LANE DEPARTURE WARNING DATA SHEET 4: LANE DEPARTURE WARNING SYSTEM OPERATION

(Page 1 of 3)

## 2022 Volkswagen Taos

Name of the LDW option, option package, etc.		
Lane Assist		
Type and location of sensor(s) used:		
The LDW system uses a camera located as	t the top c	enter of the windshield.
Lane Departure Warning Setting used in test:		
<u>N/A</u>		
How is the Lane Departure Warning _ presented to the driver?	X Wa	arning light
· _	Bu	zzer or auditory alarm
(Check all that apply)	X Vik	oration
	Ot	her

Describe the method by which the driver is alerted. For example, if the warning is a light, where is it located, its color, size, words or symbol, does it flash on and off, etc. If it is a sound, describe if it is a constant beep or a repeated beep. If it is a vibration, describe where it is felt (e.g., pedals, steering wheel), the dominant frequency, (and possibly magnitude), the type of warning (light, auditory, vibration, or combination), etc.

The LDW system alerts the driver with a visual and haptic alert. The visual alert consists of two gray lane lines. When LDW activates, the lane line corresponding to the side that triggered the warning turns white. Additionally, there is vehicle icon that turns from green to yellow that is associated with the activation of the LKS system. The haptic alert is provided by a vibration in the steering wheel.

## **LANE DEPARTURE WARNING**

## **DATA SHEET 4: LANE DEPARTURE WARNING SYSTEM OPERATION**

(Page 2 of 3)

2022 Volkswagen Taos
Is the vehicle equipped with a switch whose purpose is to render LDW inoperable?  X Yes No
If yes, please provide a full description including the switch location and method of operation, any associated instrument panel indicator, etc.
The LDW system can be turned on/off using the touch screen display on the center dash using the following procedure:  1. Select "Menu" to bring up the setup menu.
2. Select "Assistance Systems". 3. Select "Lane Keep. Syst. (Lane Assist)" to turn the LDW system on/off.
Additionally, the LDW system can be turned on/off using the button located on the turn signal lever to access the "Assist Systems" menu in the instrument panel. Use the multi-function controls on the right side of the steering wheel to select "Lane Assist" and select the "OK" button to turn the system on/off.
Is the vehicle equipped with a control whose Yes purpose is to adjust the range setting or otherwise influence the operation of LDW? X No

If yes, please provide a full description.

## LANE DEPARTURE WARNING

# **DATA SHEET 4: LANE DEPARTURE WARNING SYSTEM OPERATION**

(Page 3 of 3)

## 2022 Volkswagen Taos

LOLL VOINSWAGEN 1405	
Are there other driving modes or conditions that render LDW inoperable or reduce its effectiveness? No	_
If yes, please provide a full description.	
Refer to the owner's manual page 138 shown in Appendix B pages B-3.	
Notes:	

#### Section III

#### **TEST PROCEDURES**

#### A. Test Procedure Overview

Each LDW test involved one of three lane marking types: solid white lines, dashed yellow lines, or Botts Dots. Lane departures were done both to the left and to the right, and each test condition was repeated five times, as shown in Table 1.

**Table 1. LDW Test Matrix** 

Lane Geometry	Line Type	Departure Direction	Number of Trials
	Collid	L	5
Straight	Solid	R	5
	Dashed	L	5
		R	5
		L	5
	Botts Dots	R	5

Prior to the start of a test series involving a given lane marking type and departure direction combination, the accuracy of the distance to lane marking measurement was verified. This was accomplished by driving the vehicle to the approximate location at which the lane departure would occur and placing the tire at the lane marking edge of interest (i.e., distance to lane marking = 0). The real-time display of distance to the lane marking was then observed to verify that the measured distance was within the tolerance (5 cm). If the measured distance was found to be greater than the tolerance, the instrumentation setup was checked and corrected, if necessary. If the measured distance was found to be within the tolerance, the instrumentation setup was considered appropriate and the test series was begun.

To begin the maneuver, the vehicle was accelerated from rest to a test speed of 72.4 km/h (45 mph), while being driven in a straight line parallel to the lane marking of interest, with the centerline of the vehicle approximately 1.83 m (6.0 ft) from the lane edge (i.e., such that the vehicle would pass through the center of the start gate). The test speed was achieved at least 60 m (200 ft) before the start gate was reached. Striking any start gate cones was not permitted, and any run in which a cone was struck was considered to be invalid. Also, during the initialization and test phases, the test driver avoided using turn signals and avoided applying any sudden acceleration, sudden steering, or sudden braking, and any use of the turn signals, sudden acceleration, sudden steering, or sudden braking invalidated the test trial.

Data collection began with the vehicle at least 60 m (200 ft) from the start gate, which was configured using a pair of non-reflective, low-contrast color traffic cones. A second set of cones, placed 6 m (20 ft) longitudinally before the start gate, was used to guide the driver into the start gate. The lateral width between the cone pairs was 20 cm (8 in) greater than the width of the vehicle, and the centerline of each pair was laterally offset from the lane marking by 1.8 m (6 ft).

Once the driver passed the gate, the driver manually input sufficient steering to achieve a lane departure with a target lateral velocity of 0.5 m/s with respect to the lane line. As shown in Figure 1, two additional non-reflective cones were used to guide the driver in making this steering maneuver. Throughout the maneuver, the driver modulated the throttle or used cruise control, as appropriate, such that vehicle speed remained at constant speed. The test was considered complete when the vehicle crossed at least 1 m (3.3 ft) over the lane edge boundary.




Figure 1. Position of Cones Used to Assist Driver

Data collected included vehicle speed, position, and yaw rate. In addition to cone strikes, vehicle speed and yaw rate data were used to identify invalid runs as described in Section C below. Data from trials where speed or yaw rate were outside of the performance specification were not considered valid.

## B. Lane Delineation Markings

The New Car Assessment Program's Test Procedure for the confirmation of a Lane Departure Warning system contains a requirement that all lane markings meet United States Department of Transportation (USDOT) specifications as described in the Manual on Uniform Traffic Control Devices (MUTCD) and be considered in "very good condition".

#### 1. Lane Marker Width

The width of the edge line marker was 10 to 15 cm (4 to 6 in). This is considered to be a normal width for longitudinal pavement markings under Section 3A.05 of the MUTCD.

#### Line Marking Color and Reflectivity

Lane marker color and reflectivity met all applicable standards. These standards include those from the International Commission of Illumination (CIE) for color and the American Society for Testing and Materials (ASTM) on lane marker reflectance.

#### 3. Line Styles

The tests described in this document required the use of three lane line configurations: continuous solid white, discontinuous dashed yellow, and discontinuous with raised pavement markers.

#### Continuous White Line

A continuous white line is defined as a white line that runs for the entire length of the test course.

#### Dashed Yellow Line

As stated in the MUTCD, and as shown in Figure 2, a discontinuous dashed yellow line is defined as by a series of 3 m (10 ft) broken (dashed) yellow line segments, spaced 9.1 m (30 ft) apart.

#### Raised Pavement Marker Line (Botts Dots)

California Standard Plans indicates raised pavement markers are commonly used in lieu of painted strips for marking roads in California. Other states, mainly in the southern part of the United States, rely on them as well. These markers may be white or yellow, depending on the specific application, following the same basic colors of their analogous white and yellow painted lines. Following the California 2006 Standard Plans, three types of raised pavement markings are used to form roadway lines. It is believed that these types of roadway markings are the hardest for an LDW sensor system to process. Type A and Type AY are non-reflective circular domes that are approximately 10 cm (4 in) in diameter and approximately 1.8 cm (0.7 in) high. Type C and D are square markings that are retro reflective in two directions measuring approximately 10 x 10 x 5 cm (4 x 4 x 0.5 in), and Type G and H that are the same as C and D only retro reflective in a single direction.

For the tests described in this document, raised pavement markers were set up following California Standard Plan A20A, Detail 4, as shown in Figure 3. Note that in this figure, the squares are Type D yellow reflectors and the circles are yellow Type AY discs.




Figure 2. MUTCD Discontinuous Dashed Line Specifications




Figure 3. California Standard Plan A20A, Detail 4

## C. Test Validity

#### 1. Speed

All LDW tests were conducted at 72.4 km/h (45 mph). Test speed was monitored and a test was considered valid if the test speed remained within  $\pm$  2 km/h ( $\pm$  1.2 mph) of the 72.4 km/h (45 mph) target speed. It was required that the speed must remain within this window from the start of the test until any part of the vehicle crossed a lane line by 1 m (3.3 ft) or more.

#### 2. Lateral Velocity

All tests were conducted with a lateral velocity of 0.1 to 0.6 m/s (0.3 to 2.0 ft/s), measured with respect to the lane line at the time of the alert. To assist the test driver in being able to efficiently establish the target lateral velocity, cones were positioned in the manner shown in Figure 1.

#### 3. Yaw Rate

It was required that the magnitude of the vehicle's yaw rate could not exceed 1.0 deg/sec at any time during lane departure maneuver, from the time the vehicle passes through the start gate to the instant the vehicle has crossed a lane line by 1 m (3.3 ft).

#### D. Pass/Fail Criteria

The measured test data were used to determine the pass/fail outcome for each trial. The outcome was based on whether the LDW produced an appropriate alert during the maneuver. In the context of this test procedure, a lane departure is said to occur when any part of the two-dimensional polygon used to represent the test vehicle breaches the inboard lane line edge (i.e., the edge of the line close to the vehicle before the departure occurs). In the case of tests performed in this procedure, the front corner of the polygon, defined as the intersection of the center of the front wheels (longitudinally) with the outboard edge of the front tire (laterally), crossed the line edge first. So, for example, if the vehicle departed its lane to the left, the left front corner of the polygon would first breach the lane line edge.

For an individual trial to be considered a "pass":

- Test speed, lateral velocity, and yaw rate validity conditions must be satisfied.
- The LDW alert must <u>not</u> occur when the lateral position of the vehicle is greater than 0.75 m (2.5 ft) from the lane line edge (i.e., prior to the lane departure).
- The LDW alert must occur before the lane departure exceeds 0.3 m (1.0 ft).

For an overall, "Pass" the LDW system must satisfy the pass criteria for 3 of 5 individual trials for each combination of departure direction and lane line type (60%), and pass 20 of the 30 trials overall (66%).

#### E. Instrumentation

Table 2 lists the sensors, signal conditioning, and data acquisition equipment used for these tests.

Table 2. Test Instrumentation and Equipment

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Tire Pressure Gauge	Vehicle Tire Pressure	0-100 psi 0-690 kPa	< 1% error between 20 and 100 psi	Omega DPG8001	17042707002	By: DRI Date: 10/5/2021 Due: 10/5/2022
Platform Scales	Vehicle Total, Wheel, and Axle Load	2200 lb/platform 5338 N/	0.1% of applied load	Intercomp SWI	1110M206352	By: DRI Date: 2/11/2022 Due: 2/11/2023
Differential Global Positioning System	Position, Velocity	Latitude: ±90 deg Longitude: ±180 deg Altitude: 0-18 km Velocity: 0-1000 knots	Horizontal Position: ±1 cm Vertical Position: ±2 cm Velocity: 0.05 km/h	Trimble GPS Receiver, 5700 (base station and in-vehicle)	00440100989	N/A
Multi-Axis Inertial Sensing System	Position: Longitudinal, Lateral, and Vertical Accels: Lateral, Longitudinal and Vertical Velocities: Roll, Pitch, Yaw Rates: Roll, Pitch, Yaw Angles	Accels ± 10g, Angular Rate ±100 deg/s, Angle >45 deg, Velocity >200 km/h	Accels .01g, Angular Rate 0.05 deg/s, Angle 0.05 deg, Velocity 0.1 km/h	Oxford Inertial +	2176	By: Oxford Technical Solutions <sup>1</sup> Date: 6/26/2020 Due: 6/26/2022
Real-Time Calculation of Position and Velocity Relative to Lane Markings	Distance and velocity to lane markings	Lateral Lane Dist: ±30 m Lateral Lane Velocity: ±20 m/sec	Lateral Distance to Lane Marking: ±2 cm Lateral Velocity to Lane Marking: ±0.02m/sec	Oxford Technical Solutions (OXTS), RT-Range	97	N/A

\_

<sup>&</sup>lt;sup>1</sup> Oxford Technical Solutions recommends calibration every two years.

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Microphone	Sound (to measure time at alert)	Frequency Response: 80 Hz – 20 kHz	Signal-to-noise: 64 dB, 1 kHz at 1 Pa	Audio-Technica AT899	N/A	N/A
Light Sensor	Light intensity (to measure time at alert)	Spectral Bandwidth: 440-800 nm	Rise time < 10 msec	DRI designed and developed Light Sensor	N/A	N/A
Coordinate Measurement Machine	Inertial Sensing System Coordinates	0-8 ft 0-2.4 m	±.0020 in. ±.051 mm (Single point articulation accuracy)	Faro Arm, Fusion	UO8-05-08- 06636	By: DRI Date: 1/6/2022 Due: 1/6/2023
Туре	Description		Mfr, Mo	del	Serial Number	
Data Association	Oxford IMUs are calibrated per the manufacturer's recommended		D-Space Micro-Autobo	x II 1401/1513		
System			ard and Lateral Velocity, the MicroAutoBox. The	Base Board		549068
	schedule (listed above	<del>;</del> ).		I/O Board		588523

For systems that implement auditory or haptic alerts, part of the pre-test instrumentation verification process is to determine the tonal frequency of the auditory warning or the vibration frequency of the tactile warning through use of the PSD (Power Spectral Density) function in Matlab. This is accomplished in order to identify the center frequency around which a band-pass filter is applied to subsequent auditory or tactile warning data so that the beginning of such warnings can be programmatically determined. The band-pass filter used for these warning signal types is a phaseless, forward-reverse pass, elliptical (Cauer) digital filter, with filter parameters as listed in Table 3.

**Table 3. Auditory and Tactile Warning Filter Parameters** 

Warning Type	Filter Order	Peak-to- Peak Ripple	Minimum Stop Band Attenuation	Passband Frequency Range
Auditory	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency ± 5%
Tactile	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency ± 20%

## APPENDIX A

Photographs

## LIST OF FIGURES

		Page
Figure A1.	Front View of Subject Vehicle	A-3
Figure A2.	Rear View of Subject Vehicle	A-4
Figure A3.	Window Sticker (Monroney Label)	A-5
Figure A4.	Vehicle Certification Label	A-6
Figure A5.	Tire Placard	A-7
Figure A6.	DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle	A-8
Figure A7.	Sensor for Detecting Visual Alert	A-9
Figure A8.	Computer Installed in Subject Vehicle	A-10
Figure A9.	LDW System On/Off Menu	A-11
Figure A10.	LDW System Instrument Panel On/Off Menu	A-12
Figure A11.	Turn Signal Lever Button	A-13
Figure A12.	Steering Wheel Buttons	A-14
Figure A13.	Visual Alert	A-15



Figure A1. Front View of Subject Vehicle



Figure A2. Rear View of Subject Vehicle



Figure A3. Window Sticker (Monroney Label)




Figure A4. Vehicle Certification Label




Figure A5. Tire Placard




Figure A6. DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle




Figure A7. Sensor for Detecting Visual Alert




Figure A8. Computer Installed in Subject Vehicle




Figure A9. LDW System On/Off Menu



Figure A10. LDW System Instrument Panel On/Off Menu



Figure A11. Turn Signal Lever Button




Figure A12. Steering Wheel Buttons



Figure A13. Visual Alert

# APPENDIX B

Excerpts from Owner's Manual

#### **Using Front Assist**

☐ Please read the introductory information and heed the Warnings and Notice ▲ on page 134.

When you switch on the ignition, Front Assist and the advance warning (depending on the country) are automatically switched on.



However, Front Assist is not available or its availability is restricted while the indicator light is turned on.

Volkswagen recommends always leaving Front Assist, distance warning, and advance warning switched on. For exceptions to this, see → page 136.

#### Switching on and off

 Switch Front Assist on or off in the Assistance systems menu in the Infotainment system → page 28.

OR: switch the Front Assist on or off in the instrument cluster menu → page 26.



If you switch off Front Assist, the advance warning and distance warning will also be switched off. The yellow indicator light turns on in the instrument cluster display.

#### Adjusting the distance and advance warning setting

If Front Assist is switched on, you can adjust the distance and advance warning setting as follows:

 Switch the function you require on or off in the Assistance systems menu in the Infotainment system → page 28.

Depending on the equipment, you can also adjust the warning time setting for the advance warning.

#### Troubleshooting

☐ Please read the introductory information and heed the Warnings and Notice ▲ on page 134.

#### Autonomous Emergency Braking starts

The white indicator light comes on.

 Autonomous Emergency Braking (Front Assist) is temporarily not available or has limited availability. After driving straight for a short distance, Autonomous Emergency Braking is available again and the indicator light goes out. If the vehicle does not drive, the indicator light stays on.

# Front Assist is not available, and the radar sensor does not have sufficient visibility

- The radar sensor is dirty. Clean the radar sensor
   ⇒ page 270.
- The visibility of the radar sensor is limited due to weather conditions, such as snow, or from soap residue or coatings. Clean the radar sensor → page 270.
- Radar sensor visibility is limited by attachments, decorative frames on license plate holders, or stickers. Clear the area around the radar sensor.
- The radar sensor is misaligned or damaged, for example as a result of damage to the front of the vehicle. Check if there is noticeable damage
   → page 275.
- Painting work was carried out on or structural modifications were made to the front of the vehicle.
- The original Volkswagen emblem is not used.
- If the problem persists, turn off the Front Assist and contact an authorized Volkswagen dealer or authorized Volkswagen Service Facility.

# Front Assist is not functioning as expected or has been triggered multiple times unnecessarily

- The radar sensor is dirty. Clean the radar sensor
   → page 270.
- The system limitations are not adhered to → page 136.
- If the problem persists, turn off the Front Assist and contact an authorized Volkswagen dealer or authorized Volkswagen Service Facility.

# Lane Keeping System (Lane Assist)

#### ☐ Introduction

Lane Assist helps the driver to stay in a lane, within the system limitations. This function is not suitable for, and not designed for, autonomously keeping your vehicle in a lane.

Lane Assist detects the lane markers using a camera on the windshield. If the system detects that the vehicle is coming too close to a lane marker, the system warns the driver with corrective steering. The driver can override the corrective steering at any time.

GJ012723SA

#### System limitations

Only use Lane Assist on expressways and well-developed roads.

The system is not ready to regulate on both sides under the following conditions (inactive system status):

- The vehicle speed is less than around 55 km/h (around 30 mph).
- Lane Assist has not detected a road lane marking on either side.
- In tight curves.
- Temporarily, when the driving style is very dynamic.
- When the turn signals are switched on before a manual lane change.
- Heavy oversteering by the driver during a system intervention.
- Driving over a lane marking despite system intervention.
- No reaction from the driver to a driver intervention prompt.

#### **MARNING**

The intelligent technology of Lane Assist cannot overcome the natural laws of physics and it can only operate within the limits of the system. Careless or unintended use of Lane Assist can cause accidents and serious injuries. The system cannot replace the driver's attention and steering.

- Always adapt your speed and remain a safe distance to vehicles driving ahead according to the visual, weather, road, and traffic conditions.
- Always keep your hands on the steering wheel so that you are prepared to steer at any time.
   The driver is always responsible for keeping the vehicle within the lane.
- Lane Assist does not detect all lane markings.
   Under certain circumstances, Lane Assist may incorrectly detect poor road surfaces, road structures, or objects as lane markings. Override immediately if the system intervenes when it should not.
- Pay attention to indicators in the instrument cluster display and respond to the prompts accordingly when the traffic situation allows.
- In the following situations, the Lane Assist may intervene when not desired or may fail to intervene when it should. Therefore, the driver's attention is especially important in these scenarios and you may have to switch off Lane Assist temporarily.
  - When driving with a very sporty driving style

- When weather or road conditions are poor
- In construction zones
- In front of bumps or dips in the road
- Always pay attention to the area around your vehicle and drive with anticipation.
- If the camera lens is dirty, covered, or damaged, Lane Assist may be limited.

1

#### **Driving with Lane Assist**

☐ Please read the introductory information and heed the Warnings and Notice ▲ on page 137.

#### Switching on and off

You can view the switched on condition of the Lane Assist in the instrument cluster display and in the Infotainment system. You can also switch Lane Assist on and off there.

In the instrument cluster display → page 24:

- 1. Press the 📵 button.
- 2. Switch Lane Assist on or off.

Depending on the vehicle equipment, the button is located either on the multi-function steering wheel or the turn signal and high beam lever.

In the Infotainment system → page 28:

- 1. Open the Assistance systems menu.
- Switch Lane Assist on or off in the corresponding submenu.

When the Travel Assist is switched on, also Lane Assist is switched on.

If there is a system malfunction, Lane Assist can turn off automatically.

#### Speed range

Lane Assist is ready to take control (active system status) when a lane marking is detected within the system limits above approximately 35 mph (60 km/h).

#### Displays




Fig. 106 In the instrument cluster display: Lane Assist indicators.

- ① Lane marking detected. The system is ready to monitor on the indicated side.
- Lane marking detected. The system is monitoring on the indicated side.
- The system is not ready to monitor on the indicated side.

One of the following indicator lights may come on, depending on the driving situation and the instrument cluster version:



System active and ready to control.



System in operation (corrective steering intervention).

If the indicator light does not light up, the system is not ready for operation on both sides (inactive system status) or is switched off.

If Travel Assist is actively regulating, there will be no steering intervention and no Lane Keeping System (Lane Assist) display.

#### Driver intervention request

If there is no steering activity, the system prompts you to drive in the center of your lane with an indicator in the instrument cluster display and warning chimes.

If you do not respond accordingly, the system becomes inactive.

Depending on the vehicle equipment, semi-automatic vehicle control in a medical emergency (Emergency Assist) is activated.

Independently of steering activity, you are also prompted by an indicator on the instrument cluster display and by a warning chime to drive in the mid-

dle of the lane if the corrective steering intervention takes a long time.

#### Steering wheel vibration

The following situations may cause the steering wheel to vibrate:

 A lane is no longer detected during a sharp corrective steering intervention by the system.

In addition, you can select the Vibration or Steering wheel vibration option in the Assistance systems menu in the Infotainment system. If you select this option, the steering wheel will vibrate if Lane Assist is active and you drift onto a road lane marking that the system has detected.

#### **Troubleshooting**

 $\square$  Please read the introductory information and heed the Warnings and Notice  $\triangle$  on page 137.

#### Malfunction message, Lane Assist is not available

An indicator light comes on in the instrument cluster. In addition, a message is shown in the instrument cluster display.

- The camera field of view is dirty. Clean the windshield → page 270.
- The camera's view is limited due to weather conditions, such as snow, or from soap residue or coatings. Clean the windshield → page 270.
- The camera's view is limited by attachments or stickers. Keep the area around the camera field of view clear.
- The camera is misaligned or damaged, for example as a result of damage to the windshield. Check if there is noticeable damage → page 275.
- Malfunction or fault. Stop the engine and restart.
- If the problem persists, contact an authorized Volkswagen dealer or authorized Volkswagen Service Facility.

It can take a few seconds once the ignition has been switched on for a system fault to be recognized.

If Lane Assist is not available, Emergency Assist is not available either.

If Lane Assist is not available, Travel Assist is not available either.

#### The system is functioning differently than expected

- Do not mount any objects on the steering wheel.  $\, riangle \,$ 

2GJ012723SA

# APPENDIX C Run Log

Subject Vehicle: 2022 Volkswagen Taos Test start date: 5/3/2022

Test end date: <u>5/3/2022</u>

Driver: Andrew Saldana Note: For Distance at Warning, positive values indicate inside the lane

Run	Lane Marking Type	Departure Direction	Valid Run?	Distance at Visual Alert (ft)	Pass/Fail	Notes
1	Botts	Left	Υ	0.96	Pass	
2			Y	0.84	Pass	
3			Υ	0.90	Pass	
4			Υ	0.92	Pass	
5			Υ	0.82	Pass	
6			Υ	0.84	Pass	
7			Υ	0.89	Pass	
8		Right	Υ	0.68	Pass	
9	Botts		Υ	0.68	Pass	
10			Υ	0.77	Pass	
11			Υ	0.68	Pass	
12			Υ	0.88	Pass	
13			Υ	0.86	Pass	
14			Υ	0.75	Pass	

Run	Lane Marking Type	Departure Direction	Valid Run?	Distance at Visual Alert (ft)	Pass/Fail	Notes
15		Right	Υ	0.74	Pass	
16			Υ	0.74	Pass	
17			Υ	1.26	Pass	
18	Solid		Υ	0.72	Pass	
19	Solid		Υ	0.93	Pass	
20			Υ	0.90	Pass	
21			Ν			Bad GPS
22			Υ	0.99	Pass	
23		Left	Υ	0.64	Pass	
24	Dashed		Υ	0.82	Pass	
25			Υ	0.82	Pass	
26			Υ	0.69	Pass	
27			Υ	0.64	Pass	
28			Υ	0.81	Pass	
29			Υ	0.83	Pass	
30	Solid	Left	Υ	1.02	Pass	
31			Υ	1.04	Pass	
32			Υ	0.84	Pass	
33			Y	1.01	Pass	
34			Υ	0.85	Pass	

Run	Lane Marking Type	Departure Direction	Valid Run?	Distance at Visual Alert (ft)	Pass/Fail	Notes
35			Υ	0.81	Pass	
36			Y	0.76	Pass	
37			Υ	0.67	Pass	
38			Υ	0.59	Pass	
39			Y	0.55	Pass	
40	Dashed	Right	Υ	0.56	Pass	
41			Y	0.66	Pass	
42			Y	0.85	Pass	
43			Υ	0.70	Pass	

## APPENDIX D

Time History Plots

## LIST OF FIGURES

	Page
Figure D1. Example Time History for Lane Departure Warning Test, Passing	D-7
Figure D2. Example Time History for Lane Departure Warning Test, Failing, No Warning Issued	D-8
Figure D3. Example Time History for Lane Departure Warning Test, Invalid Run Due to	
Subject Vehicle Yaw Rate	D-9
Figure D4. Time History for Run 01, Botts Dots, Left Departure, Visual Warning	D-10
Figure D5. Time History for Run 02, Botts Dots, Left Departure, Visual Warning	D-11
Figure D6. Time History for Run 03, Botts Dots, Left Departure, Visual Warning	D-12
Figure D7. Time History for Run 04, Botts Dots, Left Departure, Visual Warning	D-13
Figure D8. Time History for Run 05, Botts Dots, Left Departure, Visual Warning	D-14
Figure D9. Time History for Run 06, Botts Dots, Left Departure, Visual Warning	D-15
Figure D10. Time History for Run 07, Botts Dots, Left Departure, Visual Warning	D-16
Figure D11. Time History for Run 08, Botts Dots, Right Departure, Visual Warning	D-17
Figure D12. Time History for Run 09, Botts Dots, Right Departure, Visual Warning	D-18
Figure D13. Time History for Run 10, Botts Dots, Right Departure, Visual Warning	D-19
Figure D14. Time History for Run 11, Botts Dots, Right Departure, Visual Warning	D-20
Figure D15. Time History for Run 12, Botts Dots, Right Departure, Visual Warning	D-21
Figure D16. Time History for Run 13, Botts Dots, Right Departure, Visual Warning	D-22
Figure D17. Time History for Run 14, Botts Dots, Right Departure, Visual Warning	D-23
Figure D18. Time History for Run 15, Solid Line, Right Departure, Visual Warning	D-24
Figure D19. Time History for Run 16, Solid Line, Right Departure, Visual Warning	D-25
Figure D20. Time History for Run 17, Solid Line, Right Departure, Visual Warning	D-26
Figure D21. Time History for Run 18, Solid Line, Right Departure, Visual Warning	D-27
Figure D22. Time History for Run 19, Solid Line, Right Departure, Visual Warning	D-28
Figure D23. Time History for Run 20, Solid Line, Right Departure, Visual Warning	D-29
Figure D24. Time History for Run 22, Solid Line, Right Departure, Visual Warning	D-30
Figure D26. Time History for Run 23, Dashed Line, Left Departure, Visual Warning	D-31
Figure D27. Time History for Run 24, Dashed Line, Left Departure, Visual Warning	D-32
Figure D28. Time History for Run 25, Dashed Line, Left Departure, Visual Warning	D-33
Figure D29. Time History for Run 26, Dashed Line, Left Departure, Visual Warning	D-34
Figure D30. Time History for Run 27, Dashed Line, Left Departure, Visual Warning	D-35
Figure D31. Time History for Run 28, Dashed Line, Left Departure, Visual Warning	D-36
Figure D32. Time History for Run 29, Dashed Line, Left Departure, Visual Warning	D-37
Figure D33. Time History for Run 30, Solid Line, Left Departure, Visual Warning	D-38
Figure D34. Time History for Run 31, Solid Line, Left Departure, Visual Warning	D-39
Figure D35. Time History for Run 32, Solid Line, Left Departure, Visual Warning	D-40
Figure D36. Time History for Run 33, Solid Line, Left Departure, Visual Warning	D-41
Figure D37. Time History for Run 34, Solid Line, Left Departure, Visual Warning	D-42
Figure D38. Time History for Run 35, Solid Line, Left Departure, Visual Warning	D-43
Figure D39. Time History for Run 36, Solid Line, Left Departure, Visual Warning	D-44

Figure D40.	Time History for Run 37, Dashed Line, Right Departure, Visual Warning D-45
Figure D41.	Time History for Run 38, Dashed Line, Right Departure, Visual Warning D-46
Figure D42.	Time History for Run 39, Dashed Line, Right Departure, Visual Warning D-47
Figure D43.	Time History for Run 40, Dashed Line, Right Departure, Visual Warning D-48
Figure D44.	Time History for Run 41, Dashed Line, Right Departure, Visual Warning D-49
Figure D45.	Time History for Run 42, Dashed Line, Right Departure, Visual Warning D-50
Figure D46.	Time History for Run 43, Dashed Line, Right Departure, Visual Warning D-51

#### **Description of Time History Plots**

A set of time history plots is provided for each valid run in the test series. Each set of plots comprises time varying data from the Subject Vehicle, as well as pass/fail envelopes and thresholds. The following is a description of data types shown in the time history plots, as well as a description of the color code for data envelopes.

#### **Time History Plot Description**

Time history figures include the following sub-plots:

- Warning Indicates timing of warning issued by LDW system. Depending on the type of LDW alert or instrumentation used to measure the alert, this can be any of the following:
  - Filtered and rectified sound signal
  - o Filtered and rectified acceleration (e.g., steering wheel vibration)
  - Light sensor signal
  - Discrete on/off value
- Speed (mph) Speed of the Subject Vehicle
- Yaw Rate (deg/sec) Yaw rate of the Subject Vehicle
- Distance to Lane Edge (ft) Lateral distance (in lane coordinates) from the outer front tire bulge to the inside
  edge of the lane marking of interest for a given test (a positive value indicates the vehicle is completely within
  the lane while a negative value indicates that the outer front tire bulge has crossed over the inner lane marking
  edge). The distance to the lane edge at the moment the LDW alert is issued, is displayed to the right of subplot.
- Lateral Lane Velocity (ft/sec) Lateral velocity (in lane coordinates) of the outer front tire bulge
- Bird's Eye View Indicates the position of the Subject Vehicle with respect to the lane marking of interest for a
  given test. Green rectangles represent the Subject Vehicle's position at approximately 2 second intervals, while
  the yellow rectangle indicates the position of the Subject Vehicle at the time of LDW warning issuance.

#### **Envelopes and Thresholds**

Each of the time history plot figures can contain either green or yellow envelopes and/or black threshold lines. These envelopes and thresholds are used to programmatically and visually determine the validity of a given test run. Envelope and threshold exceedances are indicated with either red shading or red asterisks, and red text is placed to the right side of the plot indicating the type of exceedance.

Green envelopes indicate that the time-varying data should not exceed the envelope boundaries at any time within the envelope. Exceedances of a green envelope are indicated by red shading in the area between the measured time-varying data and the envelope boundaries.

Yellow envelopes indicate that the time-varying data should not exceed the envelope only at the right end. Exceedances at the right extent of a yellow envelope are indicated by red asterisks. Data within the boundaries at the right extent of a yellow envelope are indicated by green circles.

For the warning plot, a dashed black threshold line indicates the threshold used to determine the onset of the LDW alert. The alert is considered on the first time the alert signal crosses this threshold line.

#### **Color Codes**

Color codes have been adopted to easily identify the types of data, envelopes, and thresholds used in the plots.

Color codes can be broken into three categories:

- 1. Validation envelopes and thresholds
- 2. Instantaneous samplings
- 3. Text
- 1. Validation envelope and threshold color codes:
  - Green envelope = time varying data must be within the envelope at all times in order to be valid
  - Yellow envelope = time varying data must be within limits at right end
  - Black threshold (Solid) = time varying data must not exceed this threshold in order to be valid
  - Black threshold (Dashed) = for reference only this can include warning level thresholds which are used to determine the timing of the alert
- 2. Instantaneous sampling color codes:
  - Green circle = passing or valid value at a given moment in time
  - Red asterisk = failing or invalid value at a given moment in time

- 3. Text color codes:
  - Green = passing or valid value
  - Red = failing or invalid value

#### **Other Notations**

- NG Indicates that the value for that variable was outside of bounds and therefore "No Good".
- No Wng No warning was detected.

The minimum (worst) GPS fix type is displayed in the lower right corner of each page. The only valid fix type is RTK fixed (displayed in green). If the fix type during any portion of the test was anything other than RTK fixed, then "RTK Fixed OR LESS!" is displayed in red.

Examples of time history plots (including passing, failing and invalid runs) are shown in Figure D1 through Figure D3. Actual time history data plots for the vehicle under consideration are provided subsequently.




Figure D1. Example Time History for Lane Departure Warning Test, Passing




Figure D2. Example Time History for Lane Departure Warning Test, Failing, No Warning Issued




Figure D3. Example Time History for Lane Departure Warning Test, Invalid Run Due to Subject Vehicle Yaw Rate




Figure D4. Time History for Run 01, Botts Dots, Left Departure, Visual Warning




Figure D5. Time History for Run 02, Botts Dots, Left Departure, Visual Warning




Figure D6. Time History for Run 03, Botts Dots, Left Departure, Visual Warning




Figure D7. Time History for Run 04, Botts Dots, Left Departure, Visual Warning




Figure D8. Time History for Run 05, Botts Dots, Left Departure, Visual Warning




Figure D9. Time History for Run 06, Botts Dots, Left Departure, Visual Warning




Figure D10. Time History for Run 07, Botts Dots, Left Departure, Visual Warning




Figure D11. Time History for Run 08, Botts Dots, Right Departure, Visual Warning




Figure D12. Time History for Run 09, Botts Dots, Right Departure, Visual Warning




Figure D13. Time History for Run 10, Botts Dots, Right Departure, Visual Warning




Figure D14. Time History for Run 11, Botts Dots, Right Departure, Visual Warning




Figure D15. Time History for Run 12, Botts Dots, Right Departure, Visual Warning




Figure D16. Time History for Run 13, Botts Dots, Right Departure, Visual Warning




Figure D17. Time History for Run 14, Botts Dots, Right Departure, Visual Warning




Figure D18. Time History for Run 15, Solid Line, Right Departure, Visual Warning




Figure D19. Time History for Run 16, Solid Line, Right Departure, Visual Warning




Figure D20. Time History for Run 17, Solid Line, Right Departure, Visual Warning




Figure D21. Time History for Run 18, Solid Line, Right Departure, Visual Warning




Figure D22. Time History for Run 19, Solid Line, Right Departure, Visual Warning




Figure D23. Time History for Run 20, Solid Line, Right Departure, Visual Warning




Figure D24. Time History for Run 22, Solid Line, Right Departure, Visual Warning




Figure D25. Time History for Run 23, Dashed Line, Left Departure, Visual Warning




Figure D26. Time History for Run 24, Dashed Line, Left Departure, Visual Warning




Figure D27. Time History for Run 25, Dashed Line, Left Departure, Visual Warning




Figure D28. Time History for Run 26, Dashed Line, Left Departure, Visual Warning




Figure D29. Time History for Run 27, Dashed Line, Left Departure, Visual Warning




Figure D30. Time History for Run 28, Dashed Line, Left Departure, Visual Warning




Figure D31. Time History for Run 29, Dashed Line, Left Departure, Visual Warning




Figure D32. Time History for Run 30, Solid Line, Left Departure, Visual Warning




Figure D33. Time History for Run 31, Solid Line, Left Departure, Visual Warning




Figure D34. Time History for Run 32, Solid Line, Left Departure, Visual Warning




Figure D35. Time History for Run 33, Solid Line, Left Departure, Visual Warning




Figure D36. Time History for Run 34, Solid Line, Left Departure, Visual Warning




Figure D37. Time History for Run 35, Solid Line, Left Departure, Visual Warning




Figure D38. Time History for Run 36, Solid Line, Left Departure, Visual Warning




Figure D39. Time History for Run 37, Dashed Line, Right Departure, Visual Warning




Figure D40. Time History for Run 38, Dashed Line, Right Departure, Visual Warning




Figure D41. Time History for Run 39, Dashed Line, Right Departure, Visual Warning




Figure D42. Time History for Run 40, Dashed Line, Right Departure, Visual Warning




Figure D43. Time History for Run 41, Dashed Line, Right Departure, Visual Warning




Figure D44. Time History for Run 42, Dashed Line, Right Departure, Visual Warning




Figure D45. Time History for Run 43, Dashed Line, Right Departure, Visual Warning