




Biofidelity Evaluation of WorldSID-05F with Mod Kit and SID-IIs BLD

*Heather Rhule, NHTSA
Jim Stricklin, Transportation Research Center Inc*

*SAE Government Industry Meeting
January 20, 2022*


Biofidelity Using ISO 9790 Ranking System



Higher
score
is
better

Biofidelity Score	ISO Biofidelity Rating
$8.6 \leq B \leq 10$	Excellent
$6.5 \leq B < 8.6$	Good
$4.4 < B < 6.5$	Fair
$2.6 \leq B < 4.4$	Marginal
$0.0 \leq B < 2.6$	Unacceptable

Overall score	
WS-05F	SID-IIs
6.2	6.2



WorldSID-05F with Mod Kit biofidelity needed to be improved

- WorldSID-05F scores ref: WorldSID 5th Biofidelity Improvement Task Group meeting, 10/18/2016, attachment "ISO WS 5th Biofidelity Testing OSRP Update Plots and Scores 2NOV2016.pdf"
- SID-IIs scores ref: minutes of OSRP SID-IIs Upgrade Task Group meeting, 5/25/2006

NHTSA Biofidelity Evaluation Methods

NHTSA Biofidelity Evaluation Methods

3 tests in each test condition

- WorldSID-05F Mod Kit
- SID-II's BLD

Scaled from 50th male to 5th female:

- Impactor mass & size
- Sled walls



New side impact biofidelity targets for small female

- New normalization methods
- New response scaling methods

Body Region	Test Condition
Shoulder	4.4 m/s Bolte Lateral Impact
	2.5 m/s Shaw Lateral Impact
Thorax	2.5 m/s Shaw Oblique Impact
	4.5 m/s Rhule Lateral Impact
	4.5 m/s Rhule Oblique Impact
	6.7 m/s Rigid-Wall Sled Test
	6.7 m/s Padded-Wall Sled Test
	8.9 m/s Padded-Wall Sled Test
	6.7 m/s Rigid-Wall Sled
Abdomen	6.7 m/s Padded-Wall Sled
	8.9 m/s Padded-Wall Sled
	6.7 m/s Abdomen-Offset Sled
	6.7 m/s Rigid-Wall Sled
Pelvis	6.7 m/s Padded-Wall Sled
	8.9 m/s Padded-Wall Sled
	6.7 m/s Pelvis-Offset Sled
	6.7 m/s Rigid-Wall Sled

NHTSA Biofidelity Evaluation Methods

$$BRS \text{ score} = \frac{DCAD}{CCSD} = \frac{\text{Dummy Cumulative Absolute Difference}}{\text{Cadaver Cumulative Standard Deviation}}$$



Lower BRS score means better biofidelity

NHTSA Biofidelity Evaluation Methods

$$\text{BRS score} = \frac{DCAD}{CCSD} = \frac{\text{Dummy Cumulative Absolute Difference}}{\text{Cadaver Cumulative Standard Deviation}}$$


- BRS calculation period = t_0 → time of the cadaver mean peak
- Dummy curve phase aligned
- If dummy curve peak was not included → calculation period was increased
- BRS score calculated
- Supplemental information → dummy phase shift, cadaver max & avg phase shifts

$$\text{Peak only score} = \frac{\text{Abs}(\text{Dummy Response Peak} - \text{Cadaver Mean Peak})}{\text{Cadaver Std.Dev.}_{\text{Avg upper 80\% of Cadaver Mean}}}$$

- No phase alignment of dummy curve
- Supplemental information → difference between cadaver and dummy peak times

NHTSA Biofidelity Evaluation Results

NHTSA Biofidelity Evaluation Results





WorldSID-05F thorax needs improved biofidelity

Thorax Biofidelity Results

Thorax Biofidelity Results




Lower
score
is
better




Overall Thorax Body Region scores

BRS score		Peak Only	
WS-05F	SID-IIs	WS-05F	SID-IIs
3.0	2.0	6.8	4.2


2.5 m/s Shaw Lateral Thorax Impact Test




2.5 m/s Shaw Lateral Thorax Impact Test




2.5 m/s Shaw Lateral Thorax Impact Test




2.5 m/s Shaw Lateral Thorax Impact Test



2.5 m/s Shaw Lateral Thorax Impact Test




4.5 m/s Rhule Lateral Thorax Impact Test




BRS score calculation
Range
↔

2.5 m/s Shaw Oblique Thorax Impact Test




4.5 m/s Rhule Oblique Thorax Impact Test




WorldSID-05F thorax is too stiff


2.5 m/s Shaw Lateral Thorax Impact Test




4.5 m/s Rhule Lateral Thorax Impact Test



2.5 m/s Shaw Oblique Thorax Impact Test



4.5 m/s Rhule Oblique Thorax Impact Test




WorldSID-05F thorax is too stiff in oblique tests

Thorax Qualification Response Over Time and Corridor Comparisons


Test	Mass (kg)	Face (mm)	Impact speed (m/s)
Thorax without arm qualification test	13.97 +/- .023	120.7 ± 0.25	4.2-4.4
ISO 9790 Thorax Test 1 biofidelity test	14.0	125	4.3
Rhule lateral thorax impact biofidelity test	13.8	125 high x 305 wide	4.5


NHTSA & ISO Lateral Thorax Impactor Biofidelity Tests

4.5 m/s Rhule Lateral Impact Test




4.3 m/s ISO 9790 Thorax Test 1 Lateral Impact Test







Thorax Without Arm Qualification Comparison with Biofidelity Corridors




Thorax Without Arm Qualification Comparison with Biofidelity Corridors




Thorax Without Arm Qualification Comparison with Biofidelity Corridors




Thorax Without Arm Qualification Comparison with Biofidelity Corridors



Thorax Without Arm Qualification Comparison with Biofidelity Corridors



Thorax Without Arm Qualification Comparison with Biofidelity Corridors



Summary

- Overall biofidelity results
 - WorldSID-05F with Mod Kit is equivalent to the SID-IIs BLD
 - Using both ISO 9790 and updated NHTSA BRS

Summary

- Overall biofidelity results
 - WorldSID-05F with Mod Kit is equivalent to the SID-IIs BLD
 - Using both ISO 9790 and updated NHTSA BRS
- WorldSID-05F needs improved biofidelity
 - ISO results → shoulder, thorax, abdomen, and pelvis
 - NHTSA results → thorax
 - Thorax too stiff, especially in impactor tests

Summary

- Overall biofidelity results
 - WorldSID-05F with Mod Kit is equivalent to the SID-IIs BLD
 - Using both ISO 9790 and updated NHTSA BRS
- WorldSID-05F needs improved biofidelity
 - ISO results → shoulder, thorax, abdomen, and pelvis
 - NHTSA results → thorax
 - Thorax too stiff, especially in impactor tests
- WorldSID-05F qualification corridor is too stiff

Summary

- Overall biofidelity results
 - WorldSID-05F with Mod Kit is equivalent to the SID-IIs BLD
 - Using both ISO 9790 and updated NHTSA BRS
- WorldSID-05F needs improved biofidelity
 - ISO results → shoulder, thorax, abdomen, and pelvis
 - NHTSA results → thorax
 - Thorax too stiff, especially in impactor tests
- WorldSID-05F qualification corridor is too stiff
- WorldSID-05F qualification responses have been getting stiffer over time



Biofidelity Evaluation of WorldSID-05F with Mod Kit and SID-IIs BLD

Heather Rhule

Research Engineer

Applied Biomechanics Division at NHTSA's Vehicle Research and Test Center

heather.rhule@dot.gov

937-666-3320