# NEW CAR ASSESSMENT PROGRAM CRASH IMMINENT BRAKING SYSTEM CONFIRMATION TEST NCAP-DRI-CIB-21-02

2021 Chevrolet Tahoe 2WD High Country

## DYNAMIC RESEARCH, INC.

355 Van Ness Avenue, STE 200 Torrance, California 90501



12 March 2021

## **Final Report**

Prepared Under Contract No. DTNH22-14-D-00333

U.S. DEPARTMENT OF TRANSPORTATION
National Highway Traffic Safety Administration
New Car Assessment Program
1200 New Jersey Avenue, SE
West Building, 4<sup>th</sup> Floor (NRM-110)
Washington, DC 20590

Prepared for the Department of Transportation, National Highway Traffic Safety Administration, under Contract No. DTNH22-14-D-00333.

This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings, and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturer's names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products of manufacturers.

Prepared By:	J. Lenkeit	A. Ricci	
	Program Manager	Test Engineer	
Date:	12 March 2021		

1. Report No.	2. Government Accession No.	Recipient's Catalog No.		
NCAP-DRI-CIB-21-02				
4. Title and Subtitle		5. Report Date		
Final Report of Crash Imminent Braking Chevrolet Tahoe 2WD High Country.	System Confirmation Test of a 2021	12 March 2021		
		6. Performing Organization Code		
		DRI		
7. Author(s)		8. Performing Organization Report	No.	
J. Lenkeit, Program Manager		DRI-TM-20-188		
A. Ricci, Test Engineer		21.11.11.20 100		
9. Performing Organization Name and	Address	10. Work Unit No.		
Dynamic Research, Inc.				
355 Van Ness Ave, STE 200		11. Contract or Grant No.		
Torrance, CA 90501		DTNH22-14-D-00333		
12. Sponsoring Agency Name and Add	Iress	13. Type of Report and Period Cove	ered	
U.S. Department of Transportation National Highway Traffic Safety Administration New Car Assessment Program 1200 New Jersey Avenue, SE, West Building, 4th Floor (NRM-110)		Final Test Report February 2021		
Washington, DC 20590		14. Sponsoring Agency Code		
		NRM-110		
15. Supplementary Notes				
16. Abstract				
Assessment program's most current Te	ject 2021 Chevrolet Tahoe 2WD High Count st Procedure in docket NHTSA-2015-0006-0 THE NEW CAR ASSESSMENT PROGRAM,	0025; CRASH IMMINENT BRAKE SYS		
The vehicle passed the requirements of	the test for all four CIB test scenarios and a	ll speeds.		
17. Key Words		18. Distribution Statement		
Crash Imminent Braking,		Copies of this report are availab	le from the following:	
CIB, AEB, New Car Assessment Program, NCAP		NHTSA Technical Reference Division National Highway Traffic Safety Administration 1200 New Jersey Avenue, SE Washington, DC 20590		
19. Security Classif. (of this report)	20. Security Classif. (of this page)	21. No. of Pages	22. Price	
Unclassified Unclassified 119				

## **TABLE OF CONTENTS**

SEC.	TION	<u>l</u>		<u>PAGE</u>		
l.	INTRODUCTION					
II.	DAT	A SH	EETS	2		
		Data	Sheet 1: Test Results Summary	3		
		Data	Sheet 2: Vehicle Data	4		
		Data	Sheet 3: Test Conditions	5		
		Data	Sheet 4: Crash Imminent Braking System Operation	7		
III.	TES	T PR	OCEDURES	10		
	A.	Test	Procedure Overview	10		
	B.	Gene	eral Information	15		
	C.	Princ	cipal Other Vehicle	18		
	D.	Auto	matic Braking System	19		
	E.	Instr	umentation	20		
APP	END	IX A	Photographs	A-1		
APP	END	IX B	Excerpts from Owner's Manual	B-1		
APP	END	IX C	Run Log	C-1		
APP	FND	ח או	Time Histories	D-1		

#### Section I

#### INTRODUCTION

Crash Imminent Braking (CIB) systems are a subset of Automatic Emergency Braking (AEB) systems. CIB systems are designed to avoid, or mitigate rear-end crashes, by automatically applying subject vehicle brakes when the system determines that, without intervention, a rear-end crash will occur. CIB systems typically work as an extension of Forward Collision Warning (FCW) systems, which alert the driver to the possibility of a collision unless driver action is taken. CIB systems employ sensors capable of detecting vehicles in the forward path. Current CIB technology typically involves RADAR, LIDAR, or vision-based (camera) sensors, and measurement of vehicle operating conditions such as speed, driver steering and brake application, etc. Algorithms in the system's Central Processing Unit (CPU) use this information to continuously monitor the likelihood of a rear-end crash and command a brake actuator to apply the brakes when necessary.

The method prescribed by the National Highway Traffic Safety Administration (NHTSA) to evaluate CIB performance on the test track<sup>1</sup> involves three rear-end type crash configurations and a "false positive" test. In the rear-end scenarios, a subject vehicle (SV) approaches a stopped, slower-moving, or decelerating principal other vehicle (POV) in the same lane of travel. For these tests, the POV is a strikeable object with the characteristics of a compact passenger car. The false positive scenarios are used to evaluate the propensity of a CIB system to inappropriately activate in a non-critical driving scenario that does not involve a forward vehicle or present a safety risk to the SV occupant(s).

The purpose of the testing reported herein was to objectively quantify the performance of a Crash Imminent Braking system installed on a 2021 Chevrolet Tahoe 2WD High Country. This test is part of the New Car Assessment Program to assess Crash Imminent Braking Systems sponsored by the National Highway Traffic Safety Administration under Contract No. DTNH22-14-D-00333.

1

<sup>&</sup>lt;sup>1</sup> NHTSA-2015-0006-0025; Crash Imminent Brake System Performance Evaluation for the New Car Assessment Program, October 2015.

## Section II

## **DATA SHEETS**

## **CRASH IMMINENT BRAKING**

## **DATA SHEET 1: TEST RESULTS SUMMARY**

(Page 1 of 1)

## 2021 Chevrolet Tahoe 2WD High Country

VIN: <u>1GNSCTKL9MR11xxxx</u>

Test Date: <u>2/10/2021</u>

Crash Imminent Braking System setting: Alert and Brake

Test 1 – Subject Vehicle Encounters
Stopped Principal Other Vehicle

SV 25 mph: Pass

Test 2 – Subject Vehicle Encounters Slower Principal Other Vehicle

> SV 25 mph POV 10 mph: <u>Pass</u> SV 45 mph POV 20 mph: <u>Pass</u>

Test 3 – Subject Vehicle Encounters
Decelerating Principal Other Vehicle

SV 35 mph POV 35 mph: Pass

Test 4 – Subject Vehicle Encounters Steel Trench Plate

> SV 25 mph: <u>Pass</u> SV 45 mph: <u>Pass</u>

> > Overall: Pass

Notes:

## CRASH IMMINENT BRAKING DATA SHEET 2: VEHICLE DATA

(Page 1 of 1)

## 2021 Chevrolet Tahoe 2WD High Country

## **TEST VEHICLE INFORMATION**

VIN: 1GNSCTKL9MR11xxxx

Body Style: <u>SUV</u> Color: <u>Graywood Metallic</u>

Date Received: <u>2/1/2021</u> Odometer Reading: <u>207 mi</u>

## DATA FROM VEHICLE'S CERTIFICATION LABEL

Vehicle manufactured by: General Motors LLC

Date of manufacture: 07/20

Vehicle Type: MPV

## **DATA FROM TIRE PLACARD**

Tires size as stated on Tire Placard: Front: <u>275/50R22 H</u>

Rear: 275/50R22 H

Recommended cold tire pressure: Front: <u>250 kPa (36 psi)</u>

Rear: 250 kPa (36 psi)

#### **TIRES**

Tire manufacturer and model: Bridgestone Alenza A/S 02

Front tire designation: 275/50R22 111H

Rear tire designation: 275/50R22 111H

Front tire DOT prefix: 1W2RHAA21

Rear tire DOT prefix: 1W2RHAA21

## **CRASH IMMINENT BRAKING**

## **DATA SHEET 3: TEST CONDITIONS**

(Page 1 of 2)

## 2021 Chevrolet Tahoe 2WD High Country

## **GENERAL INFORMATION**

Test date: <u>2/10/2021</u>

## **AMBIENT CONDITIONS**

Air temperature: <u>18.9 C (66 F)</u>

Wind speed: 2.6 m/s (5.8 mph)

- **X** Windspeed  $\leq$  10 m/s (22 mph)
- X Tests were not performed during periods of inclement weather. This includes, but is not limited to, rain, snow, hail, fog, smoke, or ash.
- X Tests were conducted during daylight hours with good atmospheric visibility (defined as an absence of fog and the ability to see clearly for more than 5000 meters). The tests were not conducted with the vehicle oriented into the sun during very low sun angle conditions, where the sun is oriented 15 degrees or less from horizontal, and camera "washout" or system inoperability results.

### VEHICLE PREPARATION

## Verify the following:

All non-consumable fluids at 100% capacity: X

Fuel tank is full: X

Tire pressures are set to manufacturer's recommended cold tire pressure:

Front: <u>250 kPa (36 psi)</u>

Rear: 250 kPa (36 psi)

## CRASH IMMINENT BRAKING DATA SHEET 3: TEST CONDITIONS

(Page 2 of 2)

## 2021 Chevrolet Tahoe 2WD High Country

## **WEIGHT**

Weight of vehicle as tested including driver and instrumentation

Left Front: <u>684.0 kg (1508 lb)</u> Right Front: <u>660.9 kg (1457 lb)</u>

Left Rear: 691.3 kg (1524 lb) Right Rear: 679.5 kg (1498 lb)

Total: <u>2715.7 kg (5987 lb)</u>

## CRASH IMMINENT BRAKING DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION

(Page 1 of 3)

## 2021 Chevrolet Tahoe 2WD High Country

Name of the CIB option, option package, etc.:

<u>Enhanced Automatic Emergency Braking. AEB is standard, but the sensor fusion version is only available on Premier or High Country trims.</u>

Type and location of sensors the system uses:

<u>Fusion (camera and mono radar). The camera is located at the top center of windshield. The radar is located behind the lower grille on the passenger side of the vehicle.</u>

System setting used for test (if applicable):

### Alert and Brake

What is the minimum vehicle speed at which the CIB system becomes active?

4 km/h (2.5 mph) (Per manufacturer supplied information)

What is the maximum vehicle speed at which the CIB system functions?

Maximum vehicle speed (Per manufacturer supplied information)

Does the vehicle system require an initialization sequence/procedure?		Yes
	X	No
If yes, please provide a full description.		
Will the system deactivate due to repeated CIB activations, impacts, or near-misses?		Yes
neal-misses:	X	No

If yes, please provide a full description.

## **CRASH IMMINENT BRAKING**

## **DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION**

## (Page 2 of 3) 2021 Chevrolet Tahoe 2WD High Country

How is the Forward Collision Warning system alert presented to the driver?	X Warning light X Buzzer or audible alarm
(Check all that apply)	Vibration
	Other
Describe the method by which the driver is alerted. If light, where is it located, its color, size, words or syntistic a sound, describe if it is a constant beep or a repedescribe where it is felt (e.g., pedals, steering wheel possibly magnitude), the type of warning (light, audit the visual alert is presented in the heads-up describes with a broken star above. See An	nbol, does it flash on and off, etc. If it eated beep. If it is a vibration, l), the dominant frequency (and ble, vibration, or combination), etc. isplay and depicts profile views of
two vehicles with a broken star above. See Ap	<del>-</del>
In addition, either a haptic or auditory alert can The auditory alert is a repeated set of beeps th	-
seat bottom vibrates as the haptic alert. Note to	that it is not possible to select both
haptic and auditory secondary alerts.	
Is there a way to deactivate the system?	X Yes
	No
If yes, please provide a full description including the operation, any associated instrument panel indicator System menus are used to interact with the ser	r, etc.
<u>Settings</u>	
<u>Vehicle</u>	
Collision/Detection Systems	
Forward Collision System	
Select from: Off, Ale	ert, Alert and Brake

See Appendix A, Figures A14 and A15.

## **CRASH IMMINENT BRAKING**

## **DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION**

(Page 3 of 3)

## 2021 Chevrolet Tahoe 2WD High Country

Is the vehicle equipped with a control whose purpose is to adjust the range setting or otherwise influence the operation of CIB?  No	
If yes, please provide a full description.  The secondary alert can be switched between haptic or auditory. The menu hierarchy is:  Settings	<u>!</u>
<u>Vehicle</u> <u>Collision/Detection System</u> <u>Alert Type</u> <u>Select from: Beeps and Safety Alert Seat</u>	
Are there other driving modes or conditions that render CIB inoperable or reduce its effectiveness?  X Yes No	
If yes, please provide a full description.  System limitations are described on pages 269 and 270 of the Owner's Management in Appendix B, pages B-11 and B-12.	ual <u>,</u>
Notes:	

#### Section III

### **TEST PROCEDURES**

## A. Test Procedure Overview

Four test scenarios were used, as follows:

- Test 1. Subject Vehicle (SV) Encounters Stopped Principal Other Vehicle (POV)
- Test 2. Subject Vehicle Encounters Slower Principal Other Vehicle
- Test 3. Subject Vehicle Encounters Decelerating Principal Other Vehicle
- Test 4. Subject Vehicle Encounters Steel Trench Plate

An overview of each of the test procedures follows.

## 1. <u>TEST 1 – SUBJECT VEHICLE ENCOUNTERS STOPPED PRINCIPAL OTHER VEHICLE ON A STRAIGHT ROAD</u>

This test evaluates the ability of the CIB system to detect and respond to a stopped lead vehicle in the immediate forward path of the SV, as depicted in Figure 1.




Figure 1. Depiction of Test 1

#### a. Procedure

The POV was parked in the center of a travel lane, with its longitudinal axis oriented parallel to the roadway edge and facing the same direction as the SV so that the SV approached the rear of the POV.

The SV ignition was cycled prior to each test run. The SV was driven at a nominal speed of 25 mph (40.2 km/h) in the center of the lane of travel, toward the parked POV. The SV throttle pedal was released within 500 ms after  $t_{FCW}$ , i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- The SV came to a stop before making contact with the POV.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

 The SV speed could not deviate from the nominal speed by more than 1.0 mph (1.6 km/h) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to t<sub>FCW</sub>. For this test, TTC = 5.1 seconds is taken to occur at an SV-to-POV distance of 187 ft (57 m).

#### b. Criteria

In order to pass the test, the magnitude of the SV speed reduction attributable to CIB intervention must have been  $\geq$  9.8 mph (15.8 km/h) for at least five of seven valid test trials.

The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from t<sub>FCW</sub>-100 ms to t<sub>FCW</sub>.
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevented the crash), the SV speed at a time of SV-to-POV contact was taken to be zero. The speed reduction is therefore equal to the SV speed at tFCW.

## 2. TEST 2 – SUBJECT VEHICLE ENCOUNTERS SLOWER PRINCIPAL OTHER VEHICLE

• This test evaluates the ability of the CIB system to detect and respond to a slower-moving lead vehicle traveling at a constant speed in the immediate forward path of the SV, as depicted in Figure 2.




Figure 2. Depiction of Test 2

#### a. Procedure

The SV ignition was cycled prior to each test run. The tests were conducted two ways. In the first, the POV was driven at a constant 10.0 mph (16.1 km/h) in the center of the lane of travel while the SV was driven at 25.0 mph (40.2 km/h), in the center lane of travel, toward the slower-moving POV. In the second, the POV was driven at a constant 20.0 mph (32.2 km/h) in the center of the lane of travel while the SV was driven at 45.0 mph (72.4 km/h), in the center lane of travel, toward the slower-moving POV. In both cases, the SV throttle pedal was released within 500 ms after t<sub>FCW</sub>, i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- 1 second after the speed of the SV becomes less than or equal to that of the POV

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the POV and the center of the travel lane could not deviate more than ±1 ft (0.3 m) during the validity period.
- The lateral distance between the centerline of the SV and the center of the travel lane could not deviate more than ±1 ft (0.3 m) during the validity period.
- The SV speed could not deviate more than ±1.0 mph (±1.6 km/h) during an interval defined by TTC = 5.0 seconds to t<sub>FCW</sub>.
- The POV speed could not deviate more than ±1.0 mph (±1.6 km/h) during the validity period.

#### b. Criteria

For the test series in which the initial SV speed was 25 mph, the condition for passing was that there be no SV-to-POV impact for at least five of the seven valid test trials.

In order to pass the test series for which the initial speed of the SV was 45 mph, the magnitude of the SV speed reduction attributable to CIB intervention must have been  $\geq$  9.8 mph (15.8 km/h) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from tFCW-100 ms to t<sub>FCW</sub>.
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention

prevented the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-to-POV range during the validity period from the SV speed at trow.

## 3. <u>TEST 3 – SUBJECT VEHICLE ENCOUNTERS DECELERATING PRINCIPAL</u> OTHER VEHICLE

This test evaluates the ability of the CIB system to detect and respond to a lead vehicle slowing with a constant deceleration in the immediate forward path of the SV, as depicted in Figure 3.




Figure 3. Depiction of Test 3

#### a. Procedure

The SV ignition was cycled prior to each test run. For this test scenario, both the POV and SV were driven at a constant 35.0 mph (56.3 km/h) in the center of the lane, with a headway of 45.3 ft (13.8 m)  $\pm$  8 ft (2.4 m). Once these conditions were met, the POV tow vehicle brakes were applied to achieve 0.3  $\pm$  0.03 g of deceleration. The test concluded when either:

- The SV came into contact with the POV or
- For the decelerating POV, 1 second after minimal longitudinal SV-to-POV distance occurred or
- For the POV decelerating to stop case, 1 second after the velocity of the SV became less than or equal to that of the POV.

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the POV and the center of the travel lane could not deviate more than ±1 ft (0.3 m) during the validity period.
- The lateral distance between the centerline of the SV and the center of the travel lane could not deviate more than ±1 ft (0.3 m) during the validity period.

- The headway between the SV and POV must have been constant from the onset of the applicable validity period to the onset of POV braking.
- The SV and POV speed could not deviate more than ±1.0 mph (1.6 km/h) during an interval defined by the onset of the validity period to the onset of POV braking.
- The SV- POV headway distance could not deviate more than ±8 ft (2.4 m) during an interval defined by the onset of the validity period to the onset of POV braking.
- The average POV deceleration could not deviate by more than ±0.03 g from the nominal 0.3 g deceleration during the interval beginning at 1.5 seconds after the onset of POV braking and ending either 250 ms prior to the POV coming to a stop or the SV coming into contact with the POV.

#### b. Criteria

In order to pass the decelerating POV test series, the magnitude of the SV speed reduction attributable to CIB intervention must have been ≥ 10.5 mph (16.9 km/h) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range becomes zero) from the average SV speed calculated from t<sub>FCW</sub> - 100 ms to t<sub>FCW</sub>.
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevents the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-to-POV range during the applicable validity period from the SV speed at t<sub>FCW</sub>.

### 4. TEST 4 – FALSE POSITIVE SUPPRESSION

The false positive suppression test series evaluates the ability of a CIB system to differentiate a steel trench plate (STP) from an object presenting a genuine safety risk to the SV. Although the STP is large and metallic, it is designed to be driven over without risk of injury to the driver or damage to the SV. Therefore, in this scenario, the automatic braking available from CIB is not necessary and should be suppressed. The test condition is nearly equivalent to that previously defined for Test 1, the stopped POV condition, but with an STP in the SV forward path in lieu of a POV.

#### a. Procedure

This test was conducted at two speeds, 25 mph (40.2 km/h) and 45 mph (72.4 km/h). The SV was driven directly towards, and over, the STP, which was positioned in the center of a travel lane, with its longest sides parallel to the road edge.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The SV speed could not deviate from the nominal speed by more than 1.0 mph (1.6 km/h) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to t<sub>FCW</sub> where:
  - For SV test speed of 25 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 187 ft (57 m).
  - For SV test speed of 45 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 337 ft (106 m).
- If the SV did not present an FCW alert before the end of the validity period, SV speed could not deviate more than ±1.0 mph (±1.6 km/h) from TTC = 5.1 s to the end of the validity period.

If an FCW alert was presented, the driver released the throttle pedal within 500 ms of the alert. If no alert was presented, the driver did not release the throttle pedal until the end of the validity period. The SV driver then braked to a stop.

#### b. Criteria

In order to pass the False Positive test series, the magnitude of the SV deceleration reduction attributable to CIB intervention must have been  $\leq 0.50$  g for at least five of seven valid test trials.

#### **B.** General Information

### 1. <u>T</u>FCW

The time at which the Forward Collision Warning (FCW) activation flag indicates that the system has issued an alert to the SV driver is designated as t<sub>FCW</sub>. FCW alerts are typically either visual, haptic or audible, and the onset of the alert was determined by post-processing the test data.

For systems that implement audible or haptic alerts, part of the pre-test instrumentation verification process was to determine the tonal frequency of the audible warning or the vibration frequency of the tactile warning through use of the PSD (Power Spectral Density) function in Matlab. This was accomplished in order to identify the center frequency around which a band-pass filter was applied to subsequent audible or tactile warning data so that the beginning of such warnings can be programmatically determined. The band-pass filter used for these warning signal types was a phaseless, forward-reverse pass, elliptical (Cauer) digital filter, with filter parameters as listed in Table 1.

**Table 1. Audible and Tactile Warning Filter Parameters** 

Warning Type	Filter Order	Peak-to- Peak Ripple	Minimum Stop Band Attenuation	Passband Frequency Range
Audible	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency ± 5%
Tactile	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency ± 20%

## 2. GENERAL VALIDITY CRITERIA

In addition to any validity criteria described above for the individual test scenarios, for an individual trial to be valid, it must have met the following criteria throughout the test:

- The SV driver seatbelt was latched.
- If any load had been placed on the SV front passenger seat (e.g., for instrumentation), the vehicle's front passenger seatbelt was latched.
- The SV was driven at the nominal speed in the center of the travel lane, toward the POV or STP.
- The driver used the least amount of steering input necessary to maintain SV position in the center of the travel lane during the validity period; use of abrupt steering inputs or corrections was avoided.
- The yaw rate of the SV did not exceed ±1.0 deg/s from the onset of the validity period to the instant SV deceleration exceeded 0.25 g.
- The SV driver did not apply any force to the brake pedal during the applicable validity period.
- The lateral distance between the centerline of the SV and the centerline of the POV or STP did not deviate more than ±1 ft (0.3 m) during the applicable validity period.

### 3. VALIDITY PERIOD

The valid test interval began:

Test 1: When the SV-to-POV TTC = 5.1 seconds

Test 2: When the SV-to-POV TTC = 5.0 seconds

Test 3: 3 seconds before the onset of POV braking

Test 4: When the SV-to-STP TTC = 5.1 seconds

The valid test interval ended:

Test 1: When either of the following occurred:

- The SV came into contact with the POV (SVto-POV contact was assessed by using GPS-based range data or by measurement of direct contact sensor output); or
- The SV came to a stop before making contact with the POV.

Tests 2 and 3: When either of the following occurred:

- The SV came into contact with the POV; or
- 1 second after the velocity of the SV became less than or equal to that of the POV.
- 1 second after minimal longitudinal SV-to-POV distance occurred.

Test 4: At the instant the front-most part of SV reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it was driven onto the STP).

### 4. STATIC INSTRUMENTATION CALIBRATION

To assist in resolving uncertain test data, static calibration data was collected prior to each of the test series.

For Tests 1, 2, and 3, the SV, POV, POV moving platform, and tow vehicle were centered in the same travel lane with the same orientation (i.e., facing the same direction). For Test 4, the SV and STP were centered in the same travel lane.

For Tests 1, 2, and 3, the SV was positioned such that it just contacted a vertical plane that defines the rearmost location of the POV. For Test 4, the front-most location of the SV was positioned such that it just reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it is driven onto the STP). This is the "zero position."

The zero position was documented prior to, and immediately after, conduct of each test series.

If the zero position reported by the data acquisition system was found to differ by more than ±2 in (±5 cm) from that measured during collection of the pre-test static calibration data file, the pre-test longitudinal offset was adjusted to output zero and another pre-test static calibration data file was collected. If the zero position reported by the data acquisition system was found to differ by more than ±2 in (±5 cm) from that measured during collection of the post-test static calibration data file, the test trials performed between collection of that post-test static calibration data file and the last valid pre-test static calibration data file were repeated.

Static data files were collected prior to, and immediately after, conducting each of the test series. The pre-test static files were reviewed prior to test conduct to confirm that all data channels were operational and were properly configured.

## 5. NUMBER OF TRIALS

A target total of seven (7) valid trials were performed for each scenario. In cases where the test driver performed more than seven trials, the first seven trials satisfying all test tolerances were used to assess the SV performance.

### 6. TRANSMISSION

All trials were performed with SV automatic transmissions in "Drive" or with manual transmissions in the highest gear capable of sustaining the desired test speed. Manual transmission clutches remained engaged during all maneuvers. The brake lights of the POV were not illuminated.

### C. Principal Other Vehicle

CIB testing requires a POV that realistically represents typical vehicles, does not suffer damage or cause damage to a test vehicle in the event of collision, and can be accurately positioned and moved during the tests. The tests reported herein made use of the NHTSA developed Strikeable Surrogate Vehicle (SSV).

This SSV system was designed specifically for common rear-end crash scenarios which AEB systems address. The key components of the SSV system are:

- A POV shell which is a visually and dimensionally accurate representation of a passenger car.
- A slider and load frame assembly to which the shell is attached.
- A two-rail track on which the slider operates.
- A road-based lateral restraint track.
- A tow vehicle.

The key requirements of the POV element are to:

- Provide an accurate representation of a real vehicle to CIB sensors, including cameras and radar.
- Be resistant to damage and inflict little or no damage to the SV as a result of repeated SV-to-POV impacts.

The key requirements of the POV delivery system are to:

- Accurately control the nominal POV speed up to 35 mph (56 km/h).
- Accurately control the lateral position of the POV within the travel lane.
- Allow the POV to move away from the SV after an impact occurs.

Operationally, the POV shell is attached to the slider and load frame which includes rollers that allows the entire assembly to move longitudinally along the guide rail. The guide rail is coupled to a tow vehicle and guided by the lateral restraint track secured to the test track surface. The rail includes a provision for restraining the shell and roller assembly in the ward direction. In operation, the shell and roller assembly engage the rail assembly through detents to prevent relative motion during run-up to test speeds and deceleration of the tow vehicle. The combination of rearward stops and forward motion detents allows the test conditions, such as relative SV-to-POV headway distance, speed, etc., to be achieved and adjusted as needed in the preliminary part of a test. If during the test, the SV strikes the rear of the POV shell, the detents are overcome and the entire shell/roller assembly moves forward in a two-stage manner along the rail and away from the SV. The forward end of the rail has a cushioned stop to restrain forward motion of the shell/roller assembly. After impacting the SSV, the SV driver uses the steering wheel to maintain SV position in the center of the travel lane, thereby straddling the two-rail track. The SV driver must manually apply the SV brakes after impact. The SSV system is shown in Figures A6 through A8 and a detailed description can be found in the NHTSA report: NHTSA'S STRIKEABLE SURROGATE VEHICLE PRELIMINARY DESIGN+OVERVIEW, May 2013.

### D. Automatic Braking System

The POV was equipped with an automatic braking system, which was used in Test 3. The braking system consisted of the following components:

- Electronically controlled linear actuator, mounted on the seat rail and attached to the brake pedal. The actuator can be programmed for control of stroke and rate.
- PC module programmed for control of the stroke and rate of the linear actuator.
- Switch to activate actuator.

In some cases, the SV is also equipped with an automatic braking system (E-brake) for the purpose of slowing the SV before impact with the SSV in cases where the SV is likely to fail a test. The system fires when TTC is below 0.7 sec. It is typically enabled when an SV has already impacted the SSV one or two times.

## E. Instrumentation

Table 2 lists the sensors, signal conditioning, and data acquisition equipment used for these tests.

Table 2. Test Instrumentation and Equipment

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Tire Pressure Gauge	Vehicle Tire Pressure	0-100 psi 0-690 kPa	< 1% error between 20 and 100 psi	Omega DPG8001	17042707002	By: DRI Date: 8/18/2020 Due: 8/18/2021
Platform Scales	Vehicle Total, Wheel, and Axle Load	2200 lb/platform	0.1% of reading	Intercomp SW wireless	0410MN20001	By: DRI Date: 4/20/2020 Due: 4/20/2021
Linear (string) encoder	Throttle pedal travel	10 in 254 mm	0.1 in 2.54 mm	UniMeasure LX-EP	49041189	By: DRI Date: 5/22/2020 Due: 5/22/2021
Differential Global Positioning System	Position, Velocity	Latitude: ±90 deg Longitude: ±180 deg Altitude: 0-18 km Velocity: 0-1000 knots	Horizontal Position: ±1 cm Vertical Position: ±2 cm Velocity: 0.05 km/h	Trimble GPS Receiver, 5700 (base station and in-vehicle)	00440100989	N/A
	Position; Longitudinal, Lateral, and Vertical					By: Oxford Technical Solutions
Multi-Axis Inertial Sensing System	Accels; Lateral, Longitudinal and Vertical Velocities;	and Vertical deg/s, Angle >45 Velocities; deg, Velocity >200	Accels .01g, Angular Rate 0.05 deg/s, Angle 0.05 deg, Velocity 0.1 km/h	Oxford Inertial +	2258	Date: 5/3/2019 Due: 5/3/2021
	Roll, Pitch, Yaw Rates; Roll, Pitch, Yaw Angles			2182	Date: 9/16/2019 Due: 9/16/2021	

Table 2. Test Instrumentation and Equipment (continued)

Туре	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Real-Time Calculation of Position and Velocity Relative to Lane Markings (LDW) and POV (FCW)	Distance and Velocity to lane markings (LDW) and POV (FCW)	Lateral Lane Dist: ±30 m Lateral Lane Velocity: ±20 m/sec Longitudinal Range to POV: ±200 m Longitudinal Range Rate: ±50 m/sec	Lateral Distance to Lane Marking: ±2 cm Lateral Velocity to Lane Marking: ±0.02m/sec Longitudinal Range: ±3 cm Longitudinal Range Rate: ±0.02 m/sec	Oxford Technical Solutions (OXTS), RT-Range	97	N/A
Microphone	Sound (to measure time at alert)	Frequency Response: 80 Hz – 20 kHz	Signal-to-noise: 64 dB, 1 kHz at 1 Pa	Audio-Technica AT899	N/A	N/A
Light Sensor	Light intensity (to measure time at alert)	Spectral Bandwidth: 440-800 nm	Rise time < 10 msec	DRI designed and developed Light Sensor	N/A	N/A
Accelerometer	Acceleration (to measure time at alert)	±5g	≤ 3% of full range	Silicon Designs, 2210-005	N/A	N/A
Coordinate Measurement Machine	Inertial Sensing System Coordinates	0-8 ft 0-2.4 m	±.0020 in. ±.051 mm (Single point articulation accuracy)	Faro Arm, Fusion	UO8-05-08- 06636	By: DRI Date: 1/6/2021 Due: 1/6/2022
Туре	Description		Mfr, Mo	del	Serial Number	
	Data acquisition is achieved using a dSPACE MicroAutoBox II. Data		dSPACE Micro-Autobox II 1401/1513			
Data Acquisition System	from the Oxford IMU, including Longitudinal, Lateral, and Vertical Acceleration, Roll, Yaw, and Pitch Rate, Forward and Lateral Velocity, Roll and Pitch Angle are sent over Ethernet to the MicroAutoBox. The			Base Board		549068
	Oxford IMUs are calibrated per the manufacturer's recommended schedule (listed above).		I/O Board		588523	

## APPENDIX A

Photographs

## LIST OF FIGURES

		Page
Figure A1.	Front View of Subject Vehicle	A-3
Figure A2.	Rear View of Subject Vehicle	A-4
Figure A3.	Window Sticker (Monroney Label)	A-5
Figure A4.	Vehicle Certification Label	A-6
Figure A5.	Tire Placard	A-7
Figure A6.	Rear View of Principal Other Vehicle (SSV)	A-8
Figure A7.	Load Frame/Slider of SSV	A-9
Figure A8.	Two-Rail Track and Road-Based Lateral Restraint Track	A-10
Figure A9.	Steel Trench Plate	A-11
Figure A10.	DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle	A-12
Figure A11.	Sensors for Detecting Auditory and Visual Alerts	A-13
Figure A12.	Computer Installed in Subject Vehicle	A-14
Figure A13.	Brake Actuator Installed in POV System	A-15
Figure A14.	System Setup Menus (page 1 of 2)	A-16
Figure A15.	System Setup Menus (page 2 of 2)	A-17
Figure A16.	Visual Alert	A-18



Figure A1. Front View of Subject Vehicle



Figure A2. Rear View of Subject Vehicle



Figure A3. Window Sticker (Monroney Label)




Figure A4. Vehicle Certification Label




Figure A5. Tire Placard



Figure A6. Rear View of Principal Other Vehicle (SSV)



Figure A7. Load Frame/Slider of SSV




Figure A8. Two-Rail Track and Road-Based Lateral Restraint Track



Figure A9. Steel Trench Plate




Figure A10. DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle



Figure A11. Sensors for Detecting Auditory and Visual Alerts




Figure A12. Computer Installed in Subject Vehicle



Figure A13. Brake Actuator Installed in POV System





Figure A14. System Setup Menus (page 1 of 2)





Figure A15. System Setup Menus (page 2 of 2)



Figure A16. Visual Alert

# APPENDIX B

Excerpts from Owner's Manual

### Vehicle Symbol Chart

Here are some additional symbols that may be found on the vehicle and what they mean. See the features in this manual for information.

☼ : Air Conditioning System

🛎 : Air Conditioning Refrigerant Oil

☆: Airbag Readiness Light

(ABS) : Antilock Brake System (ABS)

(1): Brake System Warning Light

i: Dispose of Used Components Properly

>> : Do Not Apply High Pressure Water

🗜 : Engine Coolant Temperature

**③**: Flame/Fire Prohibited

🌢 : Flammable

**i** ⇒: Fuse Block Cover Lock Location

🗗 : Fuses

**②**: ISOFIX/LATCH System Child Restraints

: Keep Fuse Block Covers Properly

**★** : Lane Change Alert

A: Lane Departure Warning

: Lane Keep Assist

记: Malfunction Indicator Lamp

P//▲: Oil Pressure

★: Pedestrian Ahead Indicator

**්**: Power

∴ Rear Cross Traffic Alert

: Registered Technician

 $\mathbf{\Omega}$  : Remote Vehicle Start

: Risk of Electrical Fire

♣ : Seat Belt Reminders

R<sup>v</sup><sup>□</sup>: Side Blind Zone Alert

(A): Stop/Start


(!): Tire Pressure Monitor

: Under Pressure


: Vehicle Ahead Indicator

# 4 Introduction

# **Instrument Panel Overview**




## **Instrument Cluster**



Base Level Cluster English Shown, Metric Similar

- Tachometer \$\Delta\$ 105
   Engine Oil Pressure Gauge \$\Delta\$ 106
   Engine Coolant Temperature Gauge \$\Delta\$ 107
   Fuel Gauge \$\Delta\$ 105

- 5. Voltmeter Gauge \$ 107 6. Speedometer \$ 105 7. Driver Information Center (DIC) \$ 119




Uplevel Cluster English Shown, Metric Similar

- 1. Tachometer ⇒ 105
- 3. Engine Coolant Temperature Gauge

  ⇒ 107
- 4. Fuel Gauge \$ 105
  5. Voltmeter Gauge \$ 107
  6. Speedometer \$ 105
- 7. Driver Information Center (DIC) ⇒ 119

### Cluster Menu

There is an interactive display area in the center of the instrument cluster.



Use the right steering wheel control to open and scroll through the different items and displays.

Press < or > to access the cluster applications. Use the thumbwheel to scroll through the list of available features. Press the thumbwheel to select. Not all applications will be available on all vehicles.

Home

If the ABS warning light stays on, or comes on again while driving, the vehicle needs service. A chime may also sound when the light stays on.

If the ABS warning light is the only light on, the vehicle has regular brakes, but ABS is not functioning.

If both the ABS warning light and the brake system warning light are on, ABS is not functioning and there is a problem with the regular brakes. See your dealer for service.

See Brake System Warning Light ⇒ 111.

### Four-Wheel-Drive Light



### Auto Mode Shown, Other Modes Similar

If equipped, the four-wheel-drive light displays what mode the vehicle is in. The light will show each mode: 2WD, 4HI, AUTO (all transfer cases); 4LOW and N (two-speed transfer case only).

The light will flash when a shift is in progress. Once the shift is complete the light will be steady.

If the light turns amber, there may be a malfunction with the four-wheel-drive system. See your dealer.

### Hill Descent Control Light



If equipped, the Hill Descent Control light comes on when the system is ready for use. When the light flashes, the system is active.

See Hill Descent Control (HDC) ⇒ 244.

## Lane Keep Assist (LKA) Light



After the vehicle is started, this light turns off and stays off if LKA has not been turned on or is unavailable.

If equipped, this light is white if LKA is turned on, but not ready to assist.

This light is green if LKA is turned on and is ready to assist.

LKA may assist by gently turning the steering wheel if the vehicle approaches a detected lane marking. The LKA light is amber when assisting.

This light flashes amber as a Lane Departure Warning (LDW) alert, to indicate that the lane marking has been crossed.

LKA will not assist or alert if the turn signal is active in the direction of lane departure, or if LKA detects that you are accelerating, braking or actively steering.

See Lane Keep Assist (LKA) ⇒ 275.

### Vehicle Ahead Indicator



- 4. Touch O or to turn a feature off or on.
- 5. Touch X to go to the top level of the Settings menu.

The menu may contain the following:

### Rear Seat Reminder

This allows for a chime and a message when the rear door has been opened before or during operation of the vehicle.

Touch Off or On.

### Climate and Air Quality

Touch and the following may display:

- Auto Fan Speed
- Auto Cooled Seats
- Auto Heated Seats
- Auto Defog
- Auto Rear Defog

### **Auto Fan Speed**

This setting specifies the amount of airflow when the climate control fan setting is Auto Fan.

Touch Low, Medium, or High.

### **Auto Cooled Seats**

This setting automatically turns on and regulates the ventilated seats when the cabin temperature is warm. See *Heated and Ventilated Front Seats* \$\dip 43\$.

Touch Off or On.

### **Auto Heated Seats**

This setting automatically turns on and regulates the heated seats when the cabin temperature is cool. The auto heated seats can be turned off by using the heated seat buttons on the center stack. See Heated and Ventilated Front Seats  $\Rightarrow$  43.

If equipped with the auto heated steering wheel, this feature will turn on when the auto heated seats turn on.

Touch Off or On.

### **Auto Defog**

This setting automatically directs air to the windshield to assist in defogging, based on temperature and humidity conditions.

Touch Off or On.

### Auto Rear Defog

This setting automatically turns the rear defogger on based on temperature and humidity conditions.

Touch Off or On.

### Collision/Detection Systems

Touch and the following may display:

- Alert Type
- Forward Collision System
- Front Pedestrian Detection
- · Adaptive Cruise Go Notifier
- · Lane Change Alert
- Park Assist
- Rear Camera Park Assist Symbols
- Rear Cross Traffic Alert
- Rear Pedestrian Detection

### Alert Type

This feature sets the type of alert from the driver assistance systems to help avoid crashes.

Touch Beeps or Safety Alert Seat.

### Forward Collision System

This setting can alert of a potential crash with a detected vehicle ahead and can apply brakes to help reduce a collision's severity.

Touch Off, Alert, or Alert and Brake.

### 126 Instruments and Controls

#### Front Pedestrian Detection

This feature may help avoid or reduce the harm caused by front-end crashes with nearby pedestrians. See Front Pedestrian Braking (FPB) System 

→ 270.

Touch Off. Alert, or Alert and Brake.

### **Adaptive Cruise Go Notifier**

Touch Off or On.

### Lane Change Alert

Touch Off or On.

### Park Assist

This allows the feature to be turned on or off. See Assistance Systems for Parking or Backing  $\Rightarrow$  262.

Select Off or On.

### Rear Camera Park Assist Symbols

Touch Off or On.

### **Rear Cross Traffic Alert**

This allows the Rear Cross Traffic Alert feature to be turned on or off. See Assistance Systems for Parking or Backing 

⇒ 262.

Touch Off or On.

### Rear Pedestrian Detection

Touch Off, Alert, or Alert and Brake.

### **Comfort and Convenience**

Touch and the following may display:

- Automatic Entry/Egress Assist
- Chime Volume
- Hands Free Liftgate/Trunk Control
- Reverse Tilt Mirror
- Remote Mirror Folding
- Rain Sense Wipers

• Auto Wipe in Reverse Gear

### Automatic Entry/Egress Assist

This feature specifies if the vehicle will automatically lower to make it easier to enter or exit the vehicle.

Touch Off or On.

### Chime Volume

This determines the chime volume level.

Touch the controls on the infotainment display to adjust the volume.

### Hands Free Liftgate/Trunk Control

The liftgate may be operated with a kicking motion under the left corner of the rear bumper. See *Liftgate* ⇔ 18.

Touch Off, On-Open and Close, or On-Open Only.

### Reverse Tilt Mirror

When on, the driver, passenger, or both driver and passenger outside mirrors will tilt downward when the vehicle is shifted into R (Reverse) to improve visibility of the ground near the rear wheels. They may move from their tilted position when the vehicle is shifted out of R (Reverse) or turned off. See Reverse Tilt Mirrors \$\rightarrow\$ 29.

### Warning (Continued)

To help avoid death or injury, always check for pedestrians around the vehicle before backing up. Be ready to take action and apply the brakes. See *Defensive Driving* ⇒ 214. Keep the RVC, taillamps, and back-up lamps clean and in good repair.

Rear Pedestrian Alert can be set to Off or Alert. See "Rear Pedestrian Detection" in "Collision/Detection Systems" under Vehicle Personalization ⇒ 124. If equipped, alerts can be set to beeps or seat pulses. See "Alert Type" in "Collision/Detection Systems" under Vehicle Personalization ⇒ 124.

### **Assistance Systems for Driving**

If equipped, when driving the vehicle in a forward gear, Forward Collision Alert (FCA), Front Pedestrian Braking (FPB), Lane Keep Assist (LKA), Side Blind Zone Alert (SEZA), Lane Change Alert (LCA), and/or Automatic Emergency Braking (AEB) can help to avoid a crash or reduce crash damage.

# Forward Collision Alert (FCA) System

If equipped, the FCA system may help to avoid or reduce the harm caused by front-end crashes. When approaching a vehicle ahead too quickly, FCA provides a red flashing alert on the windshield and rapidly beeps or pulses the driver seat. FCA also lights an amber visual alert if following another vehicle much too closely.

FCA detects vehicles within a distance of approximately 60 m (197 ft) and operates at speeds above 8 km/h (5 mph). If the vehicle has Adaptive Cruise Control (ACC), it can detect vehicles to distances of approximately 110 m (360 ft) and operates at all speeds. See Adaptive Cruise Control (Advanced) 

⇒ 253.

### ⚠ Warning

FCA is a warning system and does not apply the brakes. When approaching a slower-moving or stopped vehicle ahead too rapidly, or when following a vehicle too closely, FCA may not provide a warning with enough time to help avoid a crash. It also may not provide any

### Warning (Continued)

warning at all. FCA does not warn of pedestrians, animals, signs, guardrails, bridges, construction barrels, or other objects. Be ready to take action and apply the brakes. See *Defensive Driving* \$\dip 214.

FCA can be disabled with either the FCA steering wheel control or, if equipped, through vehicle personalization. See "Collision/Detection Systems" under Vehicle Personalization 

⇒ 124.

### **Detecting the Vehicle Ahead**



FCA warnings will not occur unless the FCA system detects a vehicle ahead. When a vehicle is detected, the vehicle ahead indicator will display green. Vehicles may not be detected on curves, highway exit ramps, or hills, due to poor visibility; or if a vehicle ahead is partially blocked by


### 268 Driving and Operating

pedestrians or other objects. FCA will not detect another vehicle ahead until it is completely in the driving lane.

### **⚠** Warning

FCA does not provide a warning to help avoid a crash, unless it detects a vehicle. FCA may not detect a vehicle ahead if the FCA sensor is blocked by dirt, snow, or ice, or if the windshield is damaged. It may also not detect a vehicle on winding or hilly roads, or in conditions that can limit visibility such as fog, rain, or snow, or if the headlamps or windshield are not cleaned or in proper condition. Keep the windshield, headlamps, and FCA sensors clean and in good repair.

### **Collision Alert**



With Head-Up Display



### Without Head-Up Display

When your vehicle approaches another detected vehicle too rapidly, the red FCA display will flash on the windshield. Also, eight rapid high-pitched beeps will sound from the front, or both sides of the Safety Alert Seat will pulse five times. When this Collision Alert occurs, the brake system may prepare for driver braking to occur more rapidly which can cause a brief, mild deceleration. Continue to apply the brake pedal as needed. Cruise control may be disengaged when the Collision Alert occurs.

### **Tailgating Alert**



The vehicle-ahead indicator will display amber when you are following a vehicle ahead much too closely.

### Selecting the Alert Timing

The Collision Alert control is on the steering wheel. Press 🥞 / ॐ to set the FCA timing to Far, Medium, Near, or on some vehicles, Off. The first button press shows the current setting on the DIC. Additional button presses will change this setting. The chosen setting will remain until it is changed and will affect the timing of both the Collision Alert and the Tailgating Alert features. The timing of both alerts will vary based on vehicle speed. The faster the vehicle speed, the farther away the alert will occur. Consider traffic and weather conditions when selecting the alert timing. The range of selectable alert timing may not be appropriate for all drivers and driving conditions.

If your vehicle is equipped with Adaptive Cruise Control (ACC), changing the FCA timing setting automatically changes the ACC following gap setting (Far, Medium, or Near).

### Following Distance Indicator

The following distance to a moving vehicle ahead in your path is indicated in following time in seconds on the Driver Information Center (DIC). See *Driver Information Center (DIC)* ⇒ 119. The minimum following time is 0.5 seconds away. If there is no vehicle detected ahead, or the vehicle ahead is out of sensor range, dashes will be displayed.

### **Unnecessary Alerts**

FCA may provide unnecessary alerts for turning vehicles, vehicles in other lanes, objects that are not vehicles, or shadows. These alerts are normal operation and the vehicle does not need service.

### Cleaning the System

If the FCA system does not seem to operate properly, this may correct the issue:

- Clean the outside of the windshield in front of the rearview mirror.
- · Clean the entire front of the vehicle.
- · Clean the headlamps.

System operation may also be limited under snow, heavy rain, or road spray conditions.

### Automatic Emergency Braking (AEB)

If the vehicle has Forward Collision Alert (FCA), it also has AEB, which includes Intelligent Brake Assist (IBA). When the system detects a vehicle ahead in your path that is traveling in the same direction that you may be about to crash into, it can provide a boost to braking or automatically brake the vehicle. This can help avoid or lessen the severity of crashes when driving in a forward gear. Depending on the situation, the vehicle may automatically brake moderately or hard. This automatic emergency braking can only occur if a vehicle is detected. This is shown by the FCA vehicle ahead indicator being lit. See 

The system works when driving in a forward gear between 8 km/h (5 mph) and 80 km/h (50 mph), or on vehicles with Adaptive Cruise Control (ACC), above 4 km/h (2 mph). It can detect vehicles up to approximately 60 m (197 ft).

### ⚠ Warning

AEB is an emergency crash preparation feature and is not designed to avoid crashes. Do not rely on AEB to brake the vehicle. AEB will not brake outside of its operating speed range and only responds to detected vehicles.

### AEB may not:

- Detect a vehicle ahead on winding or hilly roads.
- Detect all vehicles, especially vehicles with a trailer, tractors, muddy vehicles, etc.
- Detect a vehicle when weather limits visibility, such as in fog, rain, or snow.
- Detect a vehicle ahead if it is partially blocked by pedestrians or other objects.

Complete attention is always required while driving, and you should be ready to take action and apply the brakes and/or steer the vehicle to avoid crashes.

### 270 Driving and Operating

AEB may slow the vehicle to a complete stop to try to avoid a potential crash. The vehicle will only hold at a stop briefly. A firm press of the accelerator pedal will also release AEB.

### ⚠ Warning

AEB may automatically brake the vehicle suddenly in situations where it is unexpected and undesired. It could respond to a turning vehicle ahead, guardrails, signs, and other non-moving objects. To override AEB, firmly press the accelerator pedal, if it is safe to do so.

### Intelligent Brake Assist (IBA)

IBA may activate when the brake pedal is applied quickly by providing a boost to braking based on the speed of approach and distance to a vehicle ahead.

Minor brake pedal pulsations or pedal movement during this time is normal and the brake pedal should continue to be applied as needed. IBA will automatically disengage only when the brake pedal is released.

## **⚠** Warning

IBA may increase vehicle braking in situations when it may not be necessary. You could block the flow of traffic. If this occurs, take your foot off the brake pedal and then apply the brakes as needed.

### **⚠** Warning

Using AEB or IBA while towing a trailer could cause you to lose control of the vehicle and crash. Turn the system to Alert or Off when towing a trailer.

A system unavailable message may display if:

- The front of the vehicle or windshield is not clean.
- Heavy rain or snow is interfering with object detection.
- There is a problem with the StabiliTrak/ Electronic Stability Control (ESC) system.

The AEB system does not need service.

## Front Pedestrian Braking (FPB) System

If equipped, the FPB system may help avoid or reduce the harm caused by front-end crashes with nearby pedestrians when driving in a forward gear. FPB displays an amber indicator,  $\frac{1}{3}\fra$ pedestrian is detected ahead. When approaching a detected pedestrian too quickly, FPB provides a red flashing alert on the windshield and rapidly beeps or pulses the driver seat. FPB can provide a boost to braking or automatically brake the vehicle. This system includes Intelligent Brake Assist (IBA), and the Automatic Emergency Braking (AEB) system may also respond to pedestrians. See Automatic Emergency Braking (AEB) ⇒ 269.

The FPB system can detect and alert to pedestrians in a forward gear at speeds between 8 km/h (5 mph) and 80 km/h (50 mph). During daytime driving, the system detects pedestrians up to a distance of approximately 40 m (131 ft). During nighttime driving, system performance is very limited.

# APPENDIX C

Run Log

Subject Vehicle: 2021 Chevrolet Tahoe 2WD High Country Test Date: 2/10/2021

Principal Other Vehicle: **SSV** 

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
1	Static Run								Zero SV front bumper to SSV rear
									bumper and collect data
2		Υ	2.51	4.09	25.1	1.07	0.76	Pass	
3		Υ	2.38	3.25	25.0	1.13	0.71	Pass	
4	01	Υ	2.29	3.94	25.3	1.08	0.75	Pass	
5	Stopped POV	Y	2.27	3.55	25.5	1.03	0.78	Pass	
6		Y	2.37	3.97	25.2	1.04	0.76	Pass	
7		Υ	2.28	3.69	24.7	1.04	0.74	Pass	
8		Υ	2.27	3.87	24.8	1.04	0.75	Pass	
9	Static Run								
10		Υ	2.46	5.29	15.4	1.09	0.63	Pass	
11		Υ	2.47	5.37	15.4	1.08	0.63	Pass	
12		Υ	2.44	5.11	14.9	1.08	0.61	Pass	
13	Slower POV, 25 vs 10	Υ	2.50	5.38	15.1	1.09	0.62	Pass	
14	- 23 VS 10	Υ	2.38	4.82	14.6	1.07	0.61	Pass	
15		Υ	2.44	4.96	15.4	1.08	0.62	Pass	
16		Υ	2.46	5.56	14.9	1.05	0.64	Pass	
17	Static Run								Check zero data is within ± 0.167 ft (±0.05m)

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
18		Υ	3.06	0.00	18.7	0.58	0.95	Pass	
19		Υ	2.91	0.00	20.1	0.61	0.96	Pass	
20	01	Y	3.05	0.00	22.8	0.62	1.02	Pass	
21	Slower POV, 45 vs 20	Y	3.20	0.00	21.1	0.61	0.98	Pass	
22	40 10 20	Υ	3.05	0.00	22.2	0.65	0.97	Pass	
23		Υ	3.04	0.00	23.9	0.66	0.95	Pass	
24		Υ	3.04	0.00	24.5	0.67	1.00	Pass	
25	Static run								Check zero data is within ± 0.167 ft (±0.05m)
26	Static run								
27		N							SV Speed
28		N							SV Speed
29		N							SV Speed
30		Υ	2.04	3.05	22.7	1.12	0.94	Pass	
31	Decelerations	Υ	2.00	2.15	23.0	1.11	0.88	Pass	
32	Decelerating POV	Υ	2.13	0.58	24.7	1.11	0.86	Pass	
33		Υ	2.18	2.37	24.6	1.11	0.89	Pass	
34		N							SV yaw
35		Y	2.14	1.30	23.4	1.10	0.84	Pass	
36		Y	2.29	3.01	26.2	1.12	0.97	Pass	
37		Υ	2.13	1.27	25.2	1.09	0.88	Pass	
38	Static run								

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
39	STP - Static Run								Zero SV front bumper to rear edge of steel plate and collect data
40		Υ				0.01		Pass	
41		Υ				0.02		Pass	
42	]	Υ				0.01		Pass	
43	STP False Positive, 25	Υ				0.01		Pass	
44	1 0311176, 23	Υ				0.01		Pass	
45		Υ				0.01		Pass	
46		Υ				0.01		Pass	
47	STP - Static Run								
48		Υ				0.02		Pass	
49	1	Υ				0.02		Pass	
50	1	Υ				0.03		Pass	
51	STP False Positive, 45	Υ				0.05		Pass	
52		Υ				0.01		Pass	
53		Υ				0.02		Pass	
54		Υ				0.02		Pass	
55	STP- Static Run								

# APPENDIX D

Time History Plots

# LIST OF FIGURES

	Page
Figure D1. Example Time History for Stopped POV, Passing	D-9
Figure D2. Example Time History for Slower POV 25 vs. 10, Passing	D-10
Figure D3. Example Time History for Slower POV 45 vs. 20, Passing	D-11
Figure D4. Example Time History for Decelerating POV 35, Passing	D-12
Figure D5. Example Time History for False Positive STP 25, Passing	D-13
Figure D6. Example Time History for False Positive STP 45, Passing	D-14
Figure D7. Example Time History Displaying Invalid Headway Criteria	D-15
Figure D8. Example Time History Displaying Various Invalid Criteria	D-16
Figure D9. Example Time History for a Failed Run	D-17
Figure D10. Time History for CIB Run 2, SV Encounters Stopped POV	D-18
Figure D11. Time History for CIB Run 3, SV Encounters Stopped POV	D-19
Figure D12. Time History for CIB Run 4, SV Encounters Stopped POV	D-20
Figure D13. Time History for CIB Run 5, SV Encounters Stopped POV	D-21
Figure D14. Time History for CIB Run 6, SV Encounters Stopped POV	
Figure D15. Time History for CIB Run 7, SV Encounters Stopped POV	D-23
Figure D16. Time History for CIB Run 8, SV Encounters Stopped POV	D-24
Figure D17. Time History for CIB Run 10, SV Encounters Slower POV, SV 25 mph,	
POV 10 mph	D-25
Figure D18. Time History for CIB Run 11, SV Encounters Slower POV, SV 25 mph,	D-26
POV 10 mph	D-20
POV 10 mph	D-27
Figure D20. Time History for CIB Run 13, SV Encounters Slower POV, SV 25 mph,	
POV 10 mph	D-28
Figure D21. Time History for CIB Run 14, SV Encounters Slower POV, SV 25 mph,	
POV 10 mph	D-29
Figure D22. Time History for CIB Run 15, SV Encounters Slower POV, SV 25 mph,	
POV 10 mph	D-30
Figure D23. Time History for CIB Run 16, SV Encounters Slower POV, SV 25 mph,	<b>D</b> 04
POV 10 mph	
Figure D24. Time History for CIB Run 18, SV Encounters Slower POV, SV 45 mph, POV 20 mph	
Figure D25. Time History for CIB Run 19, SV Encounters Slower POV, SV 45 mph,	D-32
POV 20 mph	D-33
Figure D26. Time History for CIB Run 20, SV Encounters Slower POV, SV 45 mph,	
POV 20 mph	D-34
Figure D27. Time History for CIB Run 21, SV Encounters Slower POV, SV 45 mph,	
	D-35
Figure D28. Time History for CIB Run 22, SV Encounters Slower POV, SV 45 mph,	
POV 20 mph	D-36
Figure D29. Time History for CIB Run 23, SV Encounters Slower POV, SV 45 mph,	
POV 20 mph	D-37

Figure D30.	Time History for CIB Run 24, SV Encounters Slower POV, SV 45 mph, POV 20 mph	D-38
Figure D31.	Time History for CIB Run 30, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-39
Figure D32.	Time History for CIB Run 31, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-40
Figure D33.		D-41
Figure D34.	Time History for CIB Run 33, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-42
Figure D35.	Time History for CIB Run 35, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-43
Figure D36.	Time History for CIB Run 36, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-44
Figure D37.	Time History for CIB Run 37, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph	D-45
Figure D38.	Time History for CIB Run 40, SV Encounters Steel Trench Plate, SV 25 mph	D-46
Figure D39.	Time History for CIB Run 41, SV Encounters Steel Trench Plate, SV 25 mph	D-47
Figure D40.		D-48
Figure D41.	•	D-49
Figure D42.	Time History for CIB Run 44, SV Encounters Steel Trench Plate, SV 25 mph	D-50
Figure D43.	Time History for CIB Run 45, SV Encounters Steel Trench Plate, SV 25 mph	D-51
Figure D44.	Time History for CIB Run 46, SV Encounters Steel Trench Plate, SV 25 mph	D-52
Figure D45.	Time History for CIB Run 48, SV Encounters Steel Trench Plate, SV 45 mph	
Figure D46.	Time History for CIB Run 49, SV Encounters Steel Trench Plate, SV 45 mph	
Figure D47.	Time History for CIB Run 50, SV Encounters Steel Trench Plate, SV 45 mph	D-55
Figure D48.	Time History for CIB Run 51, SV Encounters Steel Trench Plate, SV 45 mph	D-56
Figure D49.	Time History for CIB Run 52, SV Encounters Steel Trench Plate, SV 45 mph	D-57
Figure D50.	Time History for CIB Run 53, SV Encounters Steel Trench Plate, SV 45 mph	D-57
Figure D51.	Time History for CIB Run 54, SV Encounters Steel Trench Plate, SV 45	D-56
	IIIVII	ローいご

# **Description of Time History Plots**

A set of time history plots is provided for each valid run in the test series. Each set of plots comprises time varying data from both the Subject Vehicle (SV) and the Principal Other Vehicle (POV), as well as pass/fail envelopes and thresholds. The following is a description of data types shown in the time history plots, as well as a description of the color codes indicating to which vehicle the data pertain.

# **Time History Plot Description**

Each time history plot consists of data relevant to the test type under consideration, and therefore the data channels plotted vary according to test type. The test types (shown in the plot titles) include:

- Stopped POV (SV at 25 mph)
- Slower POV, 25/10 (SV at 25 mph, POV at 10 mph)
- Slower POV, 45/20 (SV at 45 mph, POV at 20 mph)
- Decelerating POV 35 mph (Both vehicles at 35 mph with 13.8 m gap, POV brakes at 0.3 g)
- False Positive STP 25 mph (Steel trench plate run over at 25 mph)
- False Positive STP 45 mph (Steel trench plate run over at 45 mph)

Time history figures include the following sub-plots:

- FCW Warning Displays the Forward Collision Warning alert (which can be audible, visual, or haptic).
   Depending on the type of FCW alert or instrumentation used to measure the alert, this can be any combination of the following:
  - o Filtered, rectified, and normalized sound signal. The vertical scale is 0 to 1.
  - Filtered, rectified, and normalized acceleration (i.e., haptic alert, such as steering wheel vibration). The vertical scale is 0 to 1.
  - Normalized light sensor signal. The vertical scale is 0 to 1.

As only the audible or haptic alert is perceptible by the driver during a test run, the earliest of either of these alerts is used to define the onset of the FCW alert. A vertical black bar on the plot indicates the TTC (sec) at the first moment of the warning issued by the FCW system. The FCW TTC is displayed to the right of the subplot in green. For False Positive tests, when the FCW presents a warning "FCW" is shown in red at the right edge of the FCW plot.

- Headway (ft) Longitudinal separation (gap) between the frontmost point of the Subject Vehicle and the
  rearmost point of the Strikeable Surrogate Vehicle (SSV) towed by the Principal Other Vehicle. The minimum
  headway during the run is displayed to the right of the subplot.
- SV/POV Speed (mph) Speed of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the speed reduction experienced by the Subject Vehicle is displayed to the right of the subplot.
- Yaw Rate (deg/sec) Yaw rate of the Subject Vehicle and Principal Other Vehicle (if any).
- Lateral Offset (ft) Lateral offset within the lane of the Subject Vehicle to the center of the lane of travel. Note that for tests involving the Strikeable Surrogate Vehicle (SSV), the associated lateral restraint track is defined to be the center of the lane of travel. If testing is done with a different POV which does not have a lateral restraint track, lateral offset is defined to be the lateral offset between the SV and POV.
- Ax (g) Longitudinal acceleration of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the TTC (sec) at the moment of first CIB activation is displayed to the right of the subplot in green. Also, the peak value of Ax for the SV is shown on the subplot.
- Accelerator Pedal Position (0-1) Normalized position of the accelerator pedal.

# **Envelopes and Thresholds**

Some of the time history plot figures contain either green or yellow envelopes and/or black threshold lines. These envelopes and thresholds are used to programmatically and visually determine the validity of a given test run. Envelope and threshold exceedances are indicated with either red shading or red asterisks, and red text is placed to the right side of the plot indicating the type of exceedance. Such exceedances indicate either that the test was invalid or that the requirements of the test were not met (i.e., failure of the AEB system).

For plots with green envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope boundaries at any time. Exceedances of a green envelope are indicated by red shading in the area between the measured time-varying data and the envelope boundaries.

For plots with yellow envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope at the beginning (left edge of the boundary) and/or end (right edge), but may exceed the boundary during the time

between the left and right edges. Exceedances at the left or right extent of a yellow envelope are indicated by red asterisks.

For the headway plot, a dashed black threshold line indicating a relative headway of zero is displayed. If no impact occurs, a green circle is displayed at the moment of minimum distance. If impact occurs, a red asterisk is displayed at the moment of impact.

For the Ax plot, if the scenario is an AEB brake-to-stop scenario, a vertical dashed black line is displayed for all plots indicating the moment of first POV braking. The yellow envelope in this case is relevant to the POV braking only. The left edge of the envelope is at 1.5 seconds after the first POV braking. A solid black threshold line extends horizontally 0.5 seconds to the left of the envelope. This threshold line represents the time during which the Ax of the Principal Other Vehicle must first achieve 0.27 g (the upper edge of the envelope). A green circle or red asterisk is displayed at the moment the POV brake level achieves 0.27 g. A green circle indicates that the test was valid (the threshold was crossed during the appropriate interval) and a red asterisk indicates that the test was invalid (the threshold was crossed outside of the appropriate interval). Additionally, for the CIB tests, a dashed black threshold line indicating an Ax of -0.15 g is given to define the onset of CIB activation. When the Subject Vehicle's Ax crosses this threshold, the CIB TTC is calculated and displayed.

For the accelerator pedal position plot, a green envelope is given starting 500 ms after the onset of the FCW warning to ensure that the accelerator pedal was released at the correct time and remained off for the duration of the CIB event. For false positive runs a green dot, rather than a green envelope is displayed. The green dot indicates that at the end of the run the accelerator pedal had not been released. If the accelerator had been released a red asterisk would appear.

## **Color Codes**

Color codes have been adopted to easily identify which data correspond to which vehicle, as well as to indicate the types of envelopes and thresholds used in the plots.

Color codes can be broken into four categories:

- 1. Time-varying data
- 2. Validation envelopes and thresholds
- 3. Individual data points
- 4. Text
- 1. Time-varying data color codes:
  - Blue = Subject Vehicle data
  - Magenta = Principal Other Vehicle data
  - Brown = Relative data between SV and POV (i.e., TTC, lateral offset and headway distance)
- 2. Validation envelope and threshold color codes:
  - Green envelope = time varying data must be within the envelope at all times in order to be valid
  - Yellow envelope = time varying data must be within limits at left and/or right ends
  - Black threshold (Solid) = time varying data must cross this threshold in the time period shown in order to be valid
  - Black threshold (Dashed) = for reference only this can include warning level thresholds, TTC thresholds, and acceleration thresholds
- 3. Individual data point color codes:
  - Green circle = passing or valid value at a given moment in time
  - Red asterisk = failing or invalid value at a given moment in time
- 4. Text color codes:
  - Green = passing or valid value
  - Red = failing or invalid value

## **Other Notations**

- NG Indicates that the value for that variable was outside of bounds and therefore "No Good".
- No Wng No warning was detected.
- POV Indicates that the value for the Principal Other Vehicle was out of bounds.
- SV Indicates that the value for the Subject Vehicle was out of bounds.
- SR Shows the speed reduction value.
- Thr Indicates that the requirements for the throttle were not met.

The minimum (worst) GPS fix type is displayed in the lower right corner of each page. The only valid fix type is RTK fixed (displayed in green). If the fix type during any portion of the test was anything other than RTK fixed, then "RTK Fixed OR LESS!" is displayed in red.

Examples of time history plots for each test type (including passing, failing and invalid runs) are shown in Figure D1 through Figure D9. Figures D1 through D6 show passing runs for each of the 6 test types. Figures D7 and D8 show examples of invalid runs. Figure D9 shows an example of a valid test that failed the CIB requirements.

Time history data plots for the tests of the vehicle under consideration herein are provided beginning with Figure D10.




Figure D1. Example Time History for Stopped POV, Passing




Figure D2. Example Time History for Slower POV 25 vs. 10, Passing




Figure D3. Example Time History for Slower POV 45 vs. 20, Passing




Figure D4. Example Time History for Decelerating POV 35, Passing




Figure D5. Example Time History for False Positive STP 25, Passing




Figure D6. Example Time History for False Positive STP 45, Passing




Figure D7. Example Time History Displaying Invalid Headway Criteria




Figure D8. Example Time History Displaying Various Invalid Criteria




Figure D9. Example Time History for a Failed Run




Figure D10. Time History for CIB Run 2, SV Encounters Stopped POV




Figure D11. Time History for CIB Run 3, SV Encounters Stopped POV




Figure D12. Time History for CIB Run 4, SV Encounters Stopped POV




Figure D13. Time History for CIB Run 5, SV Encounters Stopped POV




Figure D14. Time History for CIB Run 6, SV Encounters Stopped POV




Figure D15. Time History for CIB Run 7, SV Encounters Stopped POV




Figure D16. Time History for CIB Run 8, SV Encounters Stopped POV




Figure D17. Time History for CIB Run 10, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D18. Time History for CIB Run 11, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D19. Time History for CIB Run 12, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D20. Time History for CIB Run 13, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D21. Time History for CIB Run 14, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D22. Time History for CIB Run 15, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D23. Time History for CIB Run 16, SV Encounters Slower POV, SV 25 mph, POV 10 mph




Figure D24. Time History for CIB Run 18, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D25. Time History for CIB Run 19, SV Encounters Slower POV, SV 45 mph, POV 20 mph



Figure D26. Time History for CIB Run 20, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D27. Time History for CIB Run 21, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D28. Time History for CIB Run 22, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D29. Time History for CIB Run 23, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D30. Time History for CIB Run 24, SV Encounters Slower POV, SV 45 mph, POV 20 mph




Figure D31. Time History for CIB Run 30, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D32. Time History for CIB Run 31, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D33. Time History for CIB Run 32, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D34. Time History for CIB Run 33, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D35. Time History for CIB Run 35, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D36. Time History for CIB Run 36, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D37. Time History for CIB Run 37, SV Encounters Decelerating POV, SV 35 mph, POV 35 mph




Figure D38. Time History for CIB Run 40, SV Encounters Steel Trench Plate, SV 25 mph




Figure D39. Time History for CIB Run 41, SV Encounters Steel Trench Plate, SV 25 mph




Figure D40. Time History for CIB Run 42, SV Encounters Steel Trench Plate, SV 25 mph




Figure D41. Time History for CIB Run 43, SV Encounters Steel Trench Plate, SV 25 mph




Figure D42. Time History for CIB Run 44, SV Encounters Steel Trench Plate, SV 25 mph




Figure D43. Time History for CIB Run 45, SV Encounters Steel Trench Plate, SV 25 mph




Figure D44. Time History for CIB Run 46, SV Encounters Steel Trench Plate, SV 25 mph




Figure D45. Time History for CIB Run 48, SV Encounters Steel Trench Plate, SV 45 mph




Figure D46. Time History for CIB Run 49, SV Encounters Steel Trench Plate, SV 45 mph




Figure D47. Time History for CIB Run 50, SV Encounters Steel Trench Plate, SV 45 mph




Figure D48. Time History for CIB Run 51, SV Encounters Steel Trench Plate, SV 45 mph




Figure D49. Time History for CIB Run 52, SV Encounters Steel Trench Plate, SV 45 mph




Figure D50. Time History for CIB Run 53, SV Encounters Steel Trench Plate, SV 45 mph




Figure D51. Time History for CIB Run 54, SV Encounters Steel Trench Plate, SV 45 mph