

**NEW CAR ASSESSMENT PROGRAM  
CRASH IMMINENT BRAKING SYSTEM CONFIRMATION TEST  
NCAP-DRI-CIB-22-04**

**2022 Ford Escape PHEV FWD**

**DYNAMIC RESEARCH, INC.**  
355 Van Ness Avenue, STE 200  
Torrance, California 90501



**1 June 2022**

**Final Report**

**Prepared Under Contract No. DTNH22-14-D-00333**

**U.S. DEPARTMENT OF TRANSPORTATION  
National Highway Traffic Safety Administration  
New Car Assessment Program  
1200 New Jersey Avenue, SE  
West Building, 4<sup>th</sup> Floor (NRM-110)  
Washington, DC 20590**

Prepared for the Department of Transportation, National Highway Traffic Safety Administration, under Contract No. DTNH22-14-D-00333.

This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings, and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturer's names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products of manufacturers.

Prepared By: Stephen Rhim

Senior Engineer

Date: 1 June 2022

Anthony Saldana

Staff Engineer

1. Report No. NCAP-DRI-CIB-22-04	2. Government Accession No.	3. Recipient's Catalog No.	
4. Title and Subtitle Final Report of Crash Imminent Braking System Confirmation Test of a 2022 Ford Escape PHEV FWD.		5. Report Date 1 June 2022	
		6. Performing Organization Code DRI	
7. Author(s) Stephen Rhim, Senior Engineer Anthony Saldana, Staff Engineer		8. Performing Organization Report No. DRI-TM-21-79	
9. Performing Organization Name and Address Dynamic Research, Inc. 355 Van Ness Ave, STE 200 Torrance, CA 90501		10. Work Unit No.	
		11. Contract or Grant No. DTNH22-14-D-00333	
12. Sponsoring Agency Name and Address U.S. Department of Transportation National Highway Traffic Safety Administration New Car Assessment Program 1200 New Jersey Avenue, SE, West Building, 4th Floor (NRM-110) Washington, DC 20590		13. Type of Report and Period Covered Final Test Report June 2022	
		14. Sponsoring Agency Code NRM-110	
15. Supplementary Notes			
16. Abstract These tests were conducted on the subject 2022 Ford Escape PHEV FWD in accordance with the specifications of the New Car Assessment Program's (NCAP's) most current Test Procedure in docket NHTSA-2015-0006-0025; CRASH IMMINENT BRAKE SYSTEM PERFORMANCE EVALUATION FOR THE NEW CAR ASSESSMENT PROGRAM, October 2015. The vehicle passed the requirements of the test for all four CIB test scenarios and all speeds.			
17. Key Words Crash Imminent Braking, CIB, AEB, New Car Assessment Program, NCAP		18. Distribution Statement Copies of this report are available from the following: NHTSA Technical Reference Division National Highway Traffic Safety Administration 1200 New Jersey Avenue, SE Washington, DC 20590	
19. Security Classif. (of this report) Unclassified	20. Security Classif. (of this page) Unclassified	21. No. of Pages 114	22. Price

## TABLE OF CONTENTS

<u>SECTION</u>	<u>PAGE</u>
I. INTRODUCTION .....	1
II. DATA SHEETS.....	2
Data Sheet 1: Test Results Summary .....	3
Data Sheet 2: Vehicle Data.....	4
Data Sheet 3: Test Conditions .....	5
Data Sheet 4: Crash Imminent Braking System Operation .....	7
III. TEST PROCEDURES .....	10
A. Test Procedure Overview.....	10
B. General Information .....	15
C. Principal Other Vehicle.....	18
D. Automatic Braking System .....	19
E. Instrumentation .....	19
APPENDIX A Photographs.....	A-1
APPENDIX B Excerpts from Owner's Manual .....	B-1
APPENDIX C Run Log.....	C-1
APPENDIX D Time Histories .....	D-1

## Section I

### INTRODUCTION

Crash Imminent Braking (CIB) systems are a subset of Automatic Emergency Braking (AEB) systems. CIB systems are designed to avoid, or mitigate rear-end crashes, by automatically applying subject vehicle brakes when the system determines that, without intervention, a rear-end crash will occur. CIB systems typically work as an extension of Forward Collision Warning (FCW) systems, which alert the driver to the possibility of a collision unless driver action is taken. CIB systems employ sensors capable of detecting vehicles in the forward path. Current CIB technology typically involves RADAR, LIDAR, or vision-based (camera) sensors, and measurement of vehicle operating conditions such as speed, driver steering and brake application, etc. Algorithms in the system's Central Processing Unit (CPU) use this information to continuously monitor the likelihood of a rear-end crash and command a brake actuator to apply the brakes when necessary.

The method prescribed by the National Highway Traffic Safety Administration (NHTSA) to evaluate CIB performance on the test track<sup>1</sup> involves three rear-end type crash configurations and a "false positive" test. In the rear-end scenarios, a subject vehicle (SV) approaches a stopped, slower-moving, or decelerating principal other vehicle (POV) in the same lane of travel. For these tests, the POV is a strikeable object with the characteristics of a compact passenger car. The false positive scenarios are used to evaluate the propensity of a CIB system to inappropriately activate in a non-critical driving scenario that does not involve a forward vehicle or present a safety risk to the SV occupant(s).

The purpose of the testing reported herein was to objectively quantify the performance of a Crash Imminent Braking system installed on a 2022 Ford Escape PHEV FWD. This test is part of the New Car Assessment Program to assess Crash Imminent Braking Systems sponsored by the National Highway Traffic Safety Administration under Contract No. DTNH22-14-D-00333.

---

<sup>1</sup> NHTSA-2015-0006-0025; Crash Imminent Brake System Performance Evaluation for the New Car Assessment Program, October 2015.

Section II  
**DATA SHEETS**

**CRASH IMMINENT BRAKING**  
**DATA SHEET 1: TEST RESULTS SUMMARY**

(Page 1 of 1)

**2022 Ford Escape PHEV FWD**

---

VIN: 1FMCU0KZ8NUA2xxxx

Test start date: 5/23/2022

Test end date: 5/23/2022

Crash Imminent Braking System setting: High (FCW sensitivity only)

**Test 1 – Subject Vehicle Encounters  
Stopped Principal Other Vehicle**

SV 25 mph: Pass

**Test 2 – Subject Vehicle Encounters  
Slower Principal Other Vehicle**

SV 25 mph POV 10 mph: Pass

SV 45 mph POV 20 mph: Pass

**Test 3 – Subject Vehicle Encounters  
Decelerating Principal Other Vehicle**

SV 35 mph POV 35 mph: Pass

**Test 4 – Subject Vehicle Encounters  
Steel Trench Plate**

SV 25 mph: Pass

SV 45 mph: Pass

**Overall: Pass**

Notes:

**CRASH IMMINENT BRAKING**  
**DATA SHEET 2: VEHICLE DATA**

(Page 1 of 1)

**2022 Ford Escape PHEV FWD**

---

**TEST VEHICLE INFORMATION**

VIN: 1FMCU0KZ8NUA2xxxx

Body Style: SUV

Color: Agate Black Metallic

Date Received: 5/13/2022

Odometer Reading: 38 mi

**DATA FROM VEHICLE'S CERTIFICATON LABEL**

Vehicle manufactured by: Ford Motor Co.

Date of manufacture: 03/22

Vehicle Type: MPV

**DATA FROM TIRE PLACARD**

Tires size as stated on Tire Placard: Front: 225/60R18 100H

Rear: 225/60R18 100H

Recommended cold tire pressure: Front: 230 kPa (33 psi)

Rear: 230 kPa (33 psi)

**TIRES**

Tire manufacturer and model: Michelin Primacy A/S

Front tire designation: 225/60R18 100H

Rear tire designation: 225/60R18 100H

Front tire DOT prefix: DOT 03L14 027X

Rear tire DOT prefix: DOT 03L14 027X



**CRASH IMMINENT BRAKING**  
**DATA SHEET 3: TEST CONDITIONS**

(Page 1 of 2)

**2022 Ford Escape PHEV FWD**

---

**GENERAL INFORMATION**

Test start date: 5/23/2022

Test end date: 5/23/2022

**AMBIENT CONDITIONS**

Air temperature: 30.6 C (87 F)

Wind speed: 1.0 m/s (2.3 mph)

X Windspeed ≤ 10 m/s (22 mph)

X Tests were not performed during periods of inclement weather. This includes, but is not limited to, rain, snow, hail, fog, smoke, or ash.

X Tests were conducted during daylight hours with good atmospheric visibility (defined as an absence of fog and the ability to see clearly for more than 5000 meters). The tests were not conducted with the vehicle oriented into the sun during very low sun angle conditions, where the sun is oriented 15 degrees or less from horizontal, and camera “washout” or system inoperability results.

**VEHICLE PREPARATION**

**Verify the following:**

All non-consumable fluids at 100% capacity: X

Fuel tank is full: X

Tire pressures are set to manufacturer's recommended cold tire pressure: X

Front: 230 kPa (33 psi)

Rear: 230 kPa (33 psi)

**CRASH IMMINENT BRAKING**  
**DATA SHEET 3: TEST CONDITIONS**

(Page 2 of 2)

**2022 Ford Escape PHEV FWD**

---

**WEIGHT**

Weight of vehicle as tested including driver and instrumentation

Left Front: 573.8 kg (1265 lb)

Right Front: 545.2 kg (1202 lb)

Left Rear: 422.3 kg (931 lb)

Right Rear: 414.6 kg (914 lb)

Total: 1955.9 kg (4312 lb)

## **CRASH IMMINENT BRAKING**

### **DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION**

(Page 1 of 3)

**2022 Ford Escape PHEV FWD**

---

Name of the CIB option, option package, etc.:

Pre-Collision Assist w/ AEB comes standard on the vehicle as part of the Ford Co-Pilot360 package. The optional Ford Co-Pilot360 Assist+ package is needed for the vehicle to be equipped with the radar and camera sensors. The test vehicle is equipped with the Ford Co-Pilot360 Assist+ package.

Type and location of sensors the system uses:

The front radar is located in the lower grille and the front view camera is located in the upper center windshield.

System setting used for test (if applicable):

High (FCW sensitivity only)

Over what speed range is the system operational?

The AEB system is operational from 5 km/h (3 mph) up to the maximum speed of the vehicle. (Per manufacturer supplied information)

Does the vehicle system require an initialization sequence/procedure?  Yes  
 No

If yes, please provide a full description.

The vehicle must be driven above 35 mph for 40 to 50 miles on a roadway with moving and stationary targets to confirm the sensors are fully aligned.

Will the system deactivate due to repeated CIB activations, impacts, or near-misses?  Yes  
 No

If yes, please provide a full description.

The system will deactivate due to three consecutive AEB activations within a short (approximately 1 minute) timeframe. This is indicated to the driver via a visual message that reads "Pre-Collision Assist Not Available" displayed in yellow text within the instrument panel cluster. If the system is deactivated due to consecutive activations within the short timeframe, it can be reactivated via an ignition cycle.

**CRASH IMMINENT BRAKING**

**DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION**

(Page 2 of 3)

**2022 Ford Escape PHEV FWD**

---

How is the Forward Collision Warning system alert presented to the driver?  Warning light  
(Check all that apply)  Buzzer or auditory alarm  
 Vibration  
 Other \_\_\_\_\_

---

Describe the method by which the driver is alerted. For example, if the warning is a light, where is it located, its color, size, words, or symbol, does it flash on and off, etc. If it is a sound, describe if it is a constant beep or a repeated beep. If it is a vibration, describe where it is felt (e.g., pedals, steering wheel), the dominant frequency (and possibly magnitude), the type of warning (light, auditory, vibration, or combination), etc.

The AEB system alerts the driver with a visual and auditory alert. The visual alert is displayed in the instrument panel and consists of a red flashing box with the words "Pre-Collision Assist" and an image of two vehicles. The auditory alert consists of repeated beeps with a primary frequency of 1800 Hz.

Is there a way to deactivate the system?  Yes  
 No

If yes, please provide a full description including the switch location and method of operation, any associated instrument panel indicator, etc.

The AEB system can be turned on/off using the touch screen display on the center dash. The procedure is as follows:

1. Select "Settings" -> "Driver Assistance Settings" -> "Pre-Collision Assist".
2. Select "Active Braking" to turn the AEB system on/off.

The system is automatically enabled each time the engine switch is turned on.

**CRASH IMMINENT BRAKING**

**DATA SHEET 4: CRASH IMMINENT BRAKING SYSTEM OPERATION**

(Page 3 of 3)

**2022 Ford Escape PHEV FWD**

---

Is the vehicle equipped with a control whose purpose is to adjust the range setting or otherwise influence the operation of CIB?  Yes  
 No

If yes, please provide a full description.

The vehicle offers three FCW sensitivity settings (High, Normal, Low) using the touch screen display, however this does not affect the performance of the AEB system.

Are there other driving modes or conditions that render CIB inoperable or reduce its effectiveness?  Yes  
 No

If yes, please provide a full description.

For low-visibility conditions (e.g., fog, rain, snow, etc.), the sensing system's effectiveness will likely be degraded or potentially inoperable (particularly for the camera-only sensing variant). For low-friction conditions (e.g., icy or wet pavement), stopping distance may be adversely affected. Refer to the owner's manual pages 279 to 280 shown in Appendix B pages B-2 to B-3 for additional information.

Notes:

## Section III

### TEST PROCEDURES

#### A. Test Procedure Overview

Four test scenarios were used, as follows:

Test 1. Subject Vehicle (SV) Encounters Stopped Principal Other Vehicle (POV)

Test 2. Subject Vehicle Encounters Slower Principal Other Vehicle

Test 3. Subject Vehicle Encounters Decelerating Principal Other Vehicle

Test 4. Subject Vehicle Encounters Steel Trench Plate

An overview of each of the test procedures follows.

#### 1. TEST 1 – SUBJECT VEHICLE ENCOUNTERS STOPPED PRINCIPAL OTHER VEHICLE ON A STRAIGHT ROAD

This test evaluates the ability of the CIB system to detect and respond to a stopped lead vehicle in the immediate forward path of the SV, as depicted in Figure 1.




Figure 1. Depiction of Test 1

##### a. Procedure

The POV was parked in the center of a travel lane, with its longitudinal axis oriented parallel to the roadway edge and facing the same direction as the SV so that the SV approached the rear of the POV.

The SV ignition was cycled prior to each test run. The SV was driven at a nominal speed of 25 mph (40.2 km/h) in the center of the lane of travel, toward the parked POV. The SV throttle pedal was released within 500 ms after  $t_{FCW}$ , i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- The SV came to a stop before making contact with the POV.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the SV to the center of the travel lane could not deviate more than  $\pm 1$  ft (0.3 m) during the validity period.
- The yaw rate of the SV could not deviate more than  $\pm 1$  deg/sec during the validity period.
- The SV speed could not deviate from the nominal speed by more than  $\pm 1.0$  mph ( $\pm 1.6$  km/h) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to  $t_{FCW}$  or impact if no FCW alert was given.

b. Criteria

In order to pass the test, the magnitude of the SV speed reduction attributable to CIB intervention must have been  $\geq 9.8$  mph (15.8 km/h) for at least five of seven valid test trials.

The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from  $t_{FCW} - 100$  ms to  $t_{FCW}$ .
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevented the crash), the SV speed at a time of SV-to-POV contact was taken to be zero. The speed reduction is therefore equal to the SV speed at  $t_{FCW}$ .

2. TEST 2 – SUBJECT VEHICLE ENCOUNTERS SLOWER PRINCIPAL OTHER VEHICLE

- This test evaluates the ability of the CIB system to detect and respond to a slower-moving lead vehicle traveling at a constant speed in the immediate forward path of the SV, as depicted in Figure 2.




Figure 2. Depiction of Test 2

a. Procedure

The SV ignition was cycled prior to each test run. The tests were conducted two ways. In the first, the POV was driven at a constant 10.0 mph (16.1 km/h) in the center of the lane of travel while the SV was driven at 25.0 mph (40.2 km/h), in the center lane of travel, toward the slower-moving POV. In the second, the POV was driven at a constant 20.0 mph (32.2 km/h) in the center of the lane of travel while the SV was driven at 45.0 mph (72.4 km/h), in the center lane of travel, toward the slower-moving POV. In both cases, the SV throttle pedal was released within 500 ms after  $t_{FCW}$ , i.e. within 500 ms of the FCW alert. The test concluded when either:

- The SV came into contact with the POV or
- 1 second after the speed of the SV becomes less than or equal to that of the POV.

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the SV and POV to the center of the travel lane could not deviate more than  $\pm 1$  ft (0.3 m) during the validity period.
- The yaw rate of the SV and POV could not deviate more than  $\pm 1$  deg/sec during the validity period.
- The SV speed could not deviate more than  $\pm 1.0$  mph ( $\pm 1.6$  km/h) during an interval defined by  $TTC = 5.0$  seconds to  $t_{FCW}$  or impact if no FCW alert was given.
- The POV speed could not deviate more than  $\pm 1.0$  mph ( $\pm 1.6$  km/h) during the validity period.

b. Criteria

For the test series in which the initial SV speed was 25 mph, the condition for passing was that there be no SV-to-POV impact for at least five of the seven valid test trials.



In order to pass the test series for which the initial speed of the SV was 45 mph, the magnitude of the SV speed reduction attributable to CIB intervention must have been  $\geq 9.8$  mph (15.8 km/h) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range became zero) from the average SV speed calculated from  $t_{FCW} - 100$  ms to  $t_{FCW}$ .
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevented the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-to-POV range during the validity period from the SV speed at  $t_{FCW}$ .

### 3. TEST 3 – SUBJECT VEHICLE ENCOUNTERS DECELERATING PRINCIPAL OTHER VEHICLE

This test evaluates the ability of the CIB system to detect and respond to a lead vehicle slowing with a constant deceleration in the immediate forward path of the SV, as depicted in Figure 3.




Figure 3. Depiction of Test 3

#### a. Procedure

The SV ignition was cycled prior to each test run. For this test scenario, both the POV and SV were driven at a constant 35.0 mph (56.3 km/h) in the center of the lane, with a headway of 45.3 ft (13.8 m)  $\pm$  8 ft (2.4 m). Once these conditions were met, the POV tow vehicle brakes were applied to achieve  $0.3 \pm 0.03$  g of deceleration within  $1.5 \pm 0.1$  sec. The test concluded when either:

- The SV came into contact with the POV or
- 1 second after minimum longitudinal SV-to-POV distance has occurred.

The SV driver then braked to a stop.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the SV and POV to the center of the travel lane could not deviate more than  $\pm 1$  ft (0.3 m) during the validity period.
- The yaw rate of the SV and POV could not deviate more than  $\pm 1$  deg/sec during the validity period.
- The SV speed could not deviate more than  $\pm 1.0$  mph (1.6 km/h) during an interval defined by 3.0 seconds before the onset of POV braking to  $t_{FCW}$  or impact if no FCW alert was given.
- The POV speed could not deviate more than  $\pm 1.0$  mph (1.6 km/h) during an interval of 3.0 seconds before the onset of POV braking.
- The SV- POV headway distance could not deviate more than  $\pm 8$  ft (2.4 m) during an interval defined by the onset of the validity period to the onset of POV braking.
- The average POV deceleration could not deviate by more than  $\pm 0.03$  g from the nominal 0.3 g deceleration during the interval beginning at 1.5 seconds after the onset of POV braking and ending either 250 ms prior to the POV coming to a stop or the SV coming into contact with the POV.

#### b. Criteria

In order to pass the decelerating POV test series, the magnitude of the SV speed reduction attributable to CIB intervention must have been  $\geq 10.5$  mph (16.9 km/h) for at least five of seven valid test trials. The magnitude of the SV speed reduction attributable to CIB intervention was calculated in one of two ways, depending on whether a test trial concluded with the SV colliding with the POV.

- If SV-to-POV contact occurred during a test trial, the CIB speed reduction was calculated by subtracting the SV speed at the time of SV-to-POV contact (i.e., when longitudinal range becomes zero) from the average SV speed calculated from  $t_{FCW} - 100$  ms to  $t_{FCW}$ .
- If SV-to-POV contact did not occur during a test trial (i.e., CIB intervention prevents the crash), the CIB speed reduction was calculated by subtracting the SV speed at the minimum longitudinal SV-to-POV range during the applicable validity period from the SV speed at  $t_{FCW}$ .

#### 4. TEST 4 – FALSE POSITIVE SUPPRESSION

The false positive suppression test series evaluates the ability of a CIB system to differentiate a steel trench plate (STP) from an object presenting a genuine safety risk to the SV. Although the STP is large and metallic, it is designed to be driven over without risk of injury to the driver or damage to the SV. Therefore, in this scenario, the automatic braking available from CIB is not necessary and should be suppressed. The test condition is nearly equivalent to that previously defined for Test 1, the stopped POV condition, but

with an STP in the SV forward path in lieu of a POV.

#### a. Procedure

This test was conducted at two speeds, 25 mph (40.2 km/h) and 45 mph (72.4 km/h). The SV was driven directly towards, and over, the STP, which was positioned in the center of a travel lane, with its longest sides parallel to the road edge.

In addition to the general test validity criteria described below, for an individual test trial to be valid, the following was required throughout the test:

- The lateral distance between the centerline of the SV to the center of the travel lane could not deviate more than  $\pm 1$  ft (0.3 m) during the validity period.
- The yaw rate of the SV could not deviate more than  $\pm 1$  deg/sec during the validity period.
- The SV speed could not deviate from the nominal speed by more than 1.0 mph (1.6 km/h) during an interval defined by a Time to Collision (TTC) = 5.1 seconds to  $t_{FCW}$  where:
  - For SV test speed of 25 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 187 ft (57 m).
  - For SV test speed of 45 mph, TTC = 5.1 seconds is taken to occur at an SV-to-STP distance of 337 ft (106 m).
- If the SV did not present an FCW alert before the end of the validity period, SV speed could not deviate more than  $\pm 1.0$  mph ( $\pm 1.6$  km/h) from TTC = 5.1 s to the end of the validity period.

If an FCW alert was presented, the driver released the throttle pedal within 500 ms of the alert. If no alert was presented, the driver did not release the throttle pedal until the end of the validity period. The SV driver then braked to a stop.

#### b. Criteria

In order to pass the False Positive test series, the magnitude of the SV deceleration reduction attributable to CIB intervention must have been  $\leq 0.50$  g for at least five of seven valid test trials.

### **B. General Information**

#### 1. $T_{FCW}$

The time at which the Forward Collision Warning (FCW) activation flag indicates that the system has issued an alert to the SV driver is designated as  $t_{FCW}$ . FCW alerts are typically either visual, haptic or auditory, and the onset of the alert was determined by post-processing the test data.

For systems that implement auditory or haptic alerts, part of the pre-test instrumentation verification process was to determine the tonal frequency of the auditory warning or the vibration frequency of the tactile warning through use of the PSD (Power Spectral Density) function in Matlab. This was accomplished in order to identify the center frequency around which a band-pass filter was applied to subsequent auditory or tactile warning data so that the beginning of such warnings can be programmatically determined. The band-pass filter used for these warning signal types was a phaseless, forward-reverse pass, elliptical (Cauer) digital filter, with filter parameters as listed in Table 1.

**Table 1. Auditory and Tactile Warning Filter Parameters**

Warning Type	Filter Order	Peak-to-Peak Ripple	Minimum Stop Band Attenuation	Passband Frequency Range
Auditory	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency $\pm$ 5%
Tactile	5 <sup>th</sup>	3 dB	60 dB	Identified Center Frequency $\pm$ 20%

## 2. GENERAL VALIDITY CRITERIA

In addition to any validity criteria described above for the individual test scenarios, for an individual trial to be valid, it must have met the following criteria throughout the test:

- The SV driver seatbelt was latched.
- If any load had been placed on the SV front passenger seat (e.g., for instrumentation), the vehicle's front passenger seatbelt was latched.
- The SV was driven at the nominal speed in the center of the travel lane, toward the POV or STP.
- The driver used the least amount of steering input necessary to maintain SV position in the center of the travel lane during the validity period; use of abrupt steering inputs or corrections was avoided.
- The yaw rate of the SV did not exceed  $\pm 1.0$  deg/s from the onset of the validity period to the instant SV deceleration exceeded 0.25 g.
- The SV driver did not apply any force to the brake pedal during the applicable validity period.
- The lateral distance between the centerline of the SV and the centerline of the POV or STP did not deviate more than  $\pm 1$  ft (0.3 m) during the applicable validity period.

### 3. VALIDITY PERIOD

The valid test interval began:

Test 1: When the SV-to-POV TTC = 5.1 seconds

Test 2: When the SV-to-POV TTC = 5.0 seconds

Test 3: 3 seconds before the onset of POV braking

Test 4: When the SV-to-STP TTC = 5.1 seconds

The valid test interval ended:

Test 1: When either of the following occurred:

- The SV came into contact with the POV (SV-to-POV contact was assessed by using GPS-based range data or by measurement of direct contact sensor output); or
- The SV came to a stop before making contact with the POV.

Tests 2 and 3: When either of the following occurred:

- The SV came into contact with the POV; or
- 1 second after minimum longitudinal SV-to-POV distance occurred.

Test 4: At the instant the front-most part of SV reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it was driven onto the STP).

### 4. STATIC INSTRUMENTATION CALIBRATION

To assist in resolving uncertain test data, static calibration data was collected prior to, and immediately after each of the test series.

For Tests 1, 2, and 3, the SV, POV, POV moving platform, and tow vehicle were centered in the same travel lane with the same orientation (i.e., facing the same direction). For Test 4, the SV and STP were centered in the same travel lane.

For Tests 1, 2, and 3, the SV was positioned such that it just contacted a vertical plane that defines the rearmost location of the POV. For Test 4, the front-most location of the SV was positioned such that it just reached a vertical plane defined by the leading edge of the STP first encountered by the SV (i.e., just before it is driven onto the STP). This is the “zero position.”

If the zero position reported by the data acquisition system was found to differ by more

than  $\pm 2$  in ( $\pm 5$  cm) from that measured during collection of the pre-test static calibration data file, the pre-test offset was adjusted to output zero, another pre-test static calibration data file was collected, and the test series was repeated.

## 5. NUMBER OF TRIALS

A target total of seven (7) valid trials were performed for each scenario. In cases where the test driver performed more than seven trials, the first seven trials satisfying all test tolerances were used to assess the SV performance.

## 6. TRANSMISSION

All trials were performed with SV automatic transmissions in “Drive” or with manual transmissions in the highest gear capable of sustaining the desired test speed. Manual transmission clutches remained engaged during all maneuvers. The brake lights of the POV were not illuminated.

### **C. Principal Other Vehicle**

CIB testing requires a POV that realistically represents typical vehicles, does not suffer damage or cause damage to a test vehicle in the event of collision, and can be accurately positioned and moved during the tests. The tests reported herein made use of the NHTSA developed Strikeable Surrogate Vehicle (SSV).

This SSV system was designed specifically for common rear-end crash scenarios which AEB systems address. The key components of the SSV system are:

- A POV shell which is a visually and dimensionally accurate representation of a passenger car.
- A slider and load frame assembly to which the shell is attached.
- A two-rail track on which the slider operates.
- A road-based lateral restraint track.
- A tow vehicle.

The key requirements of the POV element are to:

- Provide an accurate representation of a real vehicle to CIB sensors, including cameras and radar.
- Be resistant to damage and inflict little or no damage to the SV as a result of repeated SV-to-POV impacts.

The key requirements of the POV delivery system are to:

- Accurately control the nominal POV speed up to 35 mph (56 km/h).
- Accurately control the lateral position of the POV within the travel lane.

- Allow the POV to move away from the SV after an impact occurs.

Operationally, the POV shell is attached to the slider and load frame which includes rollers that allows the entire assembly to move longitudinally along the guide rail. The guide rail is coupled to a tow vehicle and guided by the lateral restraint track secured to the test track surface. The rail includes a provision for restraining the shell and roller assembly in the ward direction. In operation, the shell and roller assembly engage the rail assembly through detents to prevent relative motion during run-up to test speeds and deceleration of the tow vehicle. The combination of rearward stops and forward motion detents allows the test conditions, such as relative SV-to-POV headway distance, speed, etc., to be achieved and adjusted as needed in the preliminary part of a test. If during the test, the SV strikes the rear of the POV shell, the detents are overcome and the entire shell/roller assembly moves forward in a two-stage manner along the rail and away from the SV. The forward end of the rail has a cushioned stop to restrain forward motion of the shell/roller assembly. After impacting the SSV, the SV driver uses the steering wheel to maintain SV position in the center of the travel lane, thereby straddling the two-rail track. The SV driver must manually apply the SV brakes after impact. The SSV system is shown in Figures A6 through A8 and a detailed description can be found in the NHTSA report: NHTSA'S STRIKEABLE SURROGATE VEHICLE PRELIMINARY DESIGN+OVERVIEW, May 2013.

#### **D. Automatic Braking System**

The POV was equipped with an automatic braking system, which was used in Test 3. The braking system consisted of the following components:

- Electronically controlled linear actuator, mounted on the seat rail and attached to the brake pedal. The actuator can be programmed for control of stroke and rate.
- PC module programmed for control of the stroke and rate of the linear actuator.
- Switch to activate actuator.

In some cases, the SV is also equipped with an automatic braking system (E-brake) for the purpose of slowing the SV before impact with the SSV in cases where the SV is likely to fail a test. The system fires when TTC is below 0.7 sec. It is typically enabled when an SV has already impacted the SSV one or two times.

#### **E. Instrumentation**

Table 2 lists the sensors, signal conditioning, and data acquisition equipment used for these tests.

**Table 2. Test Instrumentation and Equipment**

Type	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Tire Pressure Gauge	Vehicle Tire Pressure	0-100 psi 0-690 kPa	< 1% error between 20 and 100 psi	Omega DPG8001	17042707002	By: DRI Date: 10/5/2021 Due: 10/5/2022
Platform Scales	Vehicle Total, Wheel, and Axle Load	2200 lb/platform	0.1% of reading	Intercomp SW wireless	0410MN20001	By: DRI Date: 2/11/2022 Due: 2/11/2023
Linear (string) encoder	Throttle pedal travel	50 in	0.05 in	TE Connectivity SE1-50	K3161858	By: DRI Date: 1/18/2022 Due: 1/18/2023
Differential Global Positioning System	Position, Velocity	Latitude: ±90 deg Longitude: ±180 deg Altitude: 0-18 km Velocity: 0-1000 knots	Horizontal Position: ±1 cm Vertical Position: ±2 cm Velocity: 0.05 km/h	Trimble GPS Receiver, 5700 (base station and in-vehicle)	00440100989	N/A
Multi-Axis Inertial Sensing System	Position; Longitudinal, Lateral, and Vertical Accels; Lateral, Longitudinal and Vertical Velocities; Roll, Pitch, Yaw Rates; Roll, Pitch, Yaw Angles	Accels ± 10g, Angular Rate ±100 deg/s, Angle >45 deg, Velocity >200 km/h	Accels .01g, Angular Rate 0.05 deg/s, Angle 0.05 deg, Velocity 0.1 km/h	Oxford Inertial +		By: Oxford Technical Solutions
					2176	Date: 6/26/2020 Due: 6/26/2022
					2258	Date: 4/28/2021 Due: 4/28/2023



**Table 2. Test Instrumentation and Equipment (continued)**

Type	Output	Range	Accuracy, Other Primary Specs	Mfr, Model	Serial Number	Calibration Dates Last Due
Real-Time Calculation of Position and Velocity Relative to POV	Distance and Velocity to lane markings (LDW) and POV (FCW)	Lateral Lane Dist: ±30 m Lateral Lane Velocity: ±20 m/sec Longitudinal Range to POV: ±200 m Longitudinal Range Rate: ±50 m/sec	Lateral Distance to Lane Marking: ±2 cm Lateral Velocity to Lane Marking: ±0.02m/sec Longitudinal Range: ±3 cm Longitudinal Range Rate: ±0.02 m/sec	Oxford Technical Solutions (OXTS), RT-Range	97	N/A
Microphone	Sound (to measure time at alert)	Frequency Response: 80 Hz – 20 kHz	Signal-to-noise: 64 dB, 1 kHz at 1 Pa	Audio-Technica AT899	N/A	N/A
Light Sensor	Light intensity (to measure time at alert)	Spectral Bandwidth: 440-800 nm	Rise time < 10 msec	DRI designed and developed Light Sensor	N/A	N/A
Accelerometer	Acceleration (to measure time at alert)	±5g	≤ 3% of full range	Silicon Designs, 2210-005	N/A	N/A
Coordinate Measurement Machine	Inertial Sensing System Coordinates	0-8 ft 0-2.4 m	±.0020 in. ±.051 mm (Single point articulation accuracy)	Faro Arm, Fusion	UO8-05-08-06636	By: DRI Date: 1/6/2022 Due: 1/6/2023
Type	Description			Mfr, Model	Serial Number	
Data Acquisition System	Data acquisition is achieved using a dSPACE MicroAutoBox II. Data from the Oxford IMU, including Longitudinal, Lateral, and Vertical Acceleration, Roll, Yaw, and Pitch Rate, Forward and Lateral Velocity, Roll and Pitch Angle are sent over Ethernet to the MicroAutoBox. The Oxford IMUs are calibrated per the manufacturer's recommended schedule (listed above).			dSPACE Micro-Autobox II 1401/1513		
				Base Board		549068
				I/O Board		588523

## APPENDIX A

### Photographs

## LIST OF FIGURES

	Page
Figure A1. Front View of Subject Vehicle .....	A-3
Figure A2. Rear View of Subject Vehicle .....	A-4
Figure A3. Window Sticker (Monroney Label).....	A-5
Figure A4. Vehicle Certification Label.....	A-6
Figure A5. Tire Placard.....	A-7
Figure A6. Rear View of Principal Other Vehicle (SSV).....	A-8
Figure A7. Load Frame/Slider of SSV.....	A-9
Figure A8. Two-Rail Track and Road-Based Lateral Restraint Track .....	A-10
Figure A9. Steel Trench Plate.....	A-11
Figure A10. DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle.....	A-12
Figure A11. Sensors for Detecting Auditory and Visual Alerts .....	A-13
Figure A12. Computer Installed in Subject Vehicle.....	A-14
Figure A13. Brake Actuator Installed in POV System.....	A-15
Figure A14. AEB System On/Off Menu.....	A-16
Figure A15. Visual Alert.....	A-17



Figure A1. Front View of Subject Vehicle



Figure A2. Rear View of Subject Vehicle

**Ford**  
Go Further  
ford.com

VEHICLE DESCRIPTION  
**ESCAPE FWD**  
2022 ESCAPE SEL PHEV FWD  
106.7" WHEELBASE  
2.5L I-VCT ATK 1-4 HYB ENG  
ECVT TRANSMISSION

EXTERIOR  
AGATE BLACK METALLIC  
INTERIOR  
EBONY ACTIVEV TRIM SEATS

NU A2

STANDARD EQUIPMENT INCLUDED AT NO EXTRA CHARGE

**EXTERIOR**

- ACTIVE GRILLE SHUTTERS
- DUAL EXHAUST CHROME TIPS
- ELECTR FUEL DOOR RELEASE
- FOG LAMPS
- HEADLAMP COURTESY DELAY
- HEADLAMPS - AUTO HALOGEN
- HEADLAMPS - AUTO HIGH BEAM
- LED SIGNATURE LIGHTING
- MIRRORS-HTD/POWER GLASS, MANUAL FOLD
- PRIVACY GLASS - REAR DOORS
- REAR INT WIPER/WASH/DFRST
- REAR SPOILER
- TAILLAMPS-LED

**INTERIOR**

- 1 TOUCH UP/DOWN FRN/RR WIN
- DUAL ILLUM VIS VANITY MIRR
- DUAL ZONE AUTO CLIMATE CTL
- HTD DRVR
- FRNT PASS SEATS
- ILLUMINATED ENTRY SYSTEM
- MAP POCKETS-PASSENGER
- POWERPOINTS - 12V
- REAR SEAT CUPHOLDERS AND ARMREST
- ROTARY GEAR SHIFT DIAL
- SPLIT FOLD/SLIDE REAR SEAT
- STR WHL-HTD & PREMIUM WRPD
- USB A (1) AND C (1)

**FUNCTIONAL**

- BLIS W/CROSS-TRAFFIC ALERT
- FORD CO-PILOT360™
- FORDPASS™ CONNECT 4GWI-FI HOTSPOT TELEMATICS MODEM
- INTELLIGENT ACCESS W/PUSH BUTTON START
- LANE-KEEPING SYSTEM/ALERT
- PEDESTRIAN ALERT SOUNDER
- PRE-COLLISION ASSIST W/AEB
- REAR VIEW CAMERA
- REFRESH85
- REVERSE SENSING SYSTEM
- SECURICODE KEYLESS KEYPAD
- SIRIUSXM® - SVC N/A AK&HI
- SYNCS® 8" SCR N W/APPLINK®

**SAFETY/SECURITY**

- ADVANCETRACT™ WITH RSC®
- AIRBAG - DRIVER KNEE
- AIRBAGS - DUAL STAGE FRONT
- AIRBAGS - FRONT SEAT MOUNTED SIDE IMPACT
- AIRBAGS - SAFETY CANOPY®
- LATCH CHLD SAFETY SYSTEM
- PERSONAL SAFETY SYSTEM™
- SOS POST-CRASH ALERT SYS™
- TIRE PRESSURE MONIT SYS

**WARRANTY**

- 3YR/36,000 BUMPER / BUMPER
- 5YR/60,000 ROADSIDE ASSIST
- 8YR/100,000 HYBRID UNIQUE COMPONENTS

**INCLUDED ON THIS VEHICLE EQUIPMENT GROUP #25A** (MSRP)

**OPTIONAL EQUIPMENT/OTHER**

- .18" MACHINED EBONY ALUM WHL 4,110.00
- .225/60R18 100H A/S BSW TIRES 1,595.00
- PANORAMIC VISTA ROOF 160.00
- FLR LINERS FR-RR W/O CRPT MTS 110.00
- MINI SPARE WHEEL/TIRE 995.00
- FORD CO-PILOT360 ASSIST+ ADP CRZ CTRL W/STOP N GO SEL TECHNOLOGY PACKAGE 1,250.00
- .POWER LIFTGATE W/HANDS FREE B&O SOUND SYSTEM, 10-SPK MEMORY PACKAGE
- .WIRELESS CHARGING
- .10-WAY POWER DRIVER SEAT
- FRONT LICENSE PLATE BRACKET NO CHARGE

**PRICE INFORMATION**

BASE PRICE \$36,675.00  
TOTAL OPTIONS/OTHER 4,110.00  
TOTAL VEHICLE & OPTIONS/OTHER 40,785.00  
DESTINATION & DELIVERY 1,245.00

**TOTAL MSRP \$42,030.00**

Whether you decide to lease or finance your vehicle, you'll find the choices that are right for you. See your dealer for details or visit [www.ford.com/finance](http://www.ford.com/finance).

SHIP TO (IF OTHER THAN SOLD TO):

SHIP THROUGH:

Information Disclosure Act, Gasoline, License, and Title Fees, State and Local taxes are not included. Dealer installed options or accessories are not included unless listed above.

NC172 N RB 2X 230 004362 03 17 22

**EPA DOT Fuel Economy and Environment**

Small SUVs range from 14 to 129 MPG. The best vehicle rates 142 MPG.

**Fuel Economy**

Electricity + Gasoline (Charge Time: 3.5 hours (240V))  
**105** MPG  
combined city/highway

Gasoline Only  
**40** MPG  
combined city/highway

**You save \$3,000** in fuel costs over 5 years compared to the average new vehicle.

**Annual fuel cost \$700**

**Fuel Economy & Greenhouse Gas Rating** (tailpipe only) Smog Rating (tailpipe only)

10 Best 7 Best

This vehicle emits 77 grams CO<sub>2</sub> per mile. The best emits 0 grams per mile (tailpipe only). Producing and distributing fuel and electricity also create emissions; learn more at [fuelconomy.gov](http://fuelconomy.gov).

Actual results will vary for many reasons, including driving conditions and how you drive and maintain your vehicle. The average new vehicle gets 27 MPG and costs \$6,500 to fuel over 5 years. Cost estimates are based on 15,000 miles per year at \$2.35 per gallon and \$1.15 per kWh. This is a dual fueled automobile. MPGe is miles per gasoline gallon equivalent. Vehicle emissions are a significant cause of climate change and smog.

**fuelconomy.gov**  
Calculate personalized estimates and compare vehicles

**GOVERNMENT 5-STAR SAFETY RATINGS**

**Overall Vehicle Score Not Rated**  
Based on the combined ratings of frontal, side and rollover. Should ONLY be compared to other vehicles of similar size and weight.

**Frontal Crash** Driver Not Rated  
Passenger Not Rated

**Side Crash** Front seat Not Rated  
Rear seat Not Rated

**Rollover Not Rated**  
Based on the risk of rollover in a single-vehicle crash.

Star ratings range from 1 to 5 stars (★★★★★), with 5 being the highest.  
Source: National Highway Traffic Safety Administration (NHTSA).  
[www.safercar.gov](http://www.safercar.gov) or 1-888-327-4236

**FordPass Connect™**

Download the FordPass™ app\* and you can:

**Access Vehicle Control Features**

- Remotely start, lock and unlock your vehicle.
- Locate your vehicle and check approximate fuel range.
- Receive vehicle health alerts.

**Activate 4G LTE Wi-Fi Hotspot**

- New vehicles include a 3-month or 3GB data (whichever comes first) Wi-Fi trial.
- Connect up to ten Wi-Fi-equipped devices.

The FordPass Connect™ modem is active and sending vehicle data (e.g., diagnostics) to Ford. See in-vehicle Settings for connectivity options.

**Ford | FORD PROTECT™**

Insist on Ford Protect! The only extended service plan fully backed by Ford and honored at every Ford dealership in the U.S., Canada and Mexico. See your Ford dealer or visit [www.FordOwner.com](http://www.FordOwner.com).

1FMCU0KZ8NUA2

**WARNING:** Operating, servicing and maintaining a passenger vehicle, pickup truck, van, or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to [www.P65Warnings.ca.gov/passenger-vehicle](http://www.P65Warnings.ca.gov/passenger-vehicle).

SCAN OR TEXT: 1FNIAZ588E TO 48028

Aug 8 Data rates may apply. Text HELP for help.

[www.ford.com/help/privacy-180718/](http://www.ford.com/help/privacy-180718/)

Figure A3. Window Sticker (Monroney Label)

MFD. BY FORD MOTOR CO.  
FRONT GAWR: 1175 KG ( 2590 LB)  
WITH 225/60R18 100H  
18x7.5J

DATE: 03/22

GVWR: 2232 KG ( 4920 LB)

TIRES  
RIMS

REAR GAWR: 1093 KG ( 2410 LB)  
WITH 225/60R18 100H  
18x7.5J

TIRES  
RIMS

AT 230 kPa/ 33 PSI COLD

AT 230 kPa/ 33 PSI COLD

THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND THEFT PREVENTION STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.

VIN: 1FMCU0KZ8NUA2

TYPE: MPV



EXT PNT: UM

RC: 71 DSO:

WB	INT TR	TP/PS	R	AXLE	TR	SPR
----	--------	-------	---	------	----	-----

106	6H		2	91	5	CCCC
-----	----	--	---	----	---	------

1202203241109

ULC

▽ 5U5A-3520472-AA

F0045  
T0051

Figure A4. Vehicle Certification Label



# TIRE AND LOADING INFORMATION

SEATING CAPACITY    TOTAL : 5    FRONT: 2    REAR: 3

The combined weight of occupants and cargo should never exceed : **377 kg or 832 lbs.**

▽ 5U5A-1532-AA (TLU) FoMoCo

TIRE	SIZE	COLD TIRE PRESSURE
FRONT	225/60R18 100H	230 KPA, 33 PSI
REAR	225/60R18 100H	230 KPA, 33 PSI
SPARE	T155/70D17 110M	420 KPA, 60 PSI

**SEE OWNERS  
MANUAL FOR  
ADDITIONAL  
INFORMATION**

1FMCU0KZ8NUA2



Figure A5. Tire Placard





Figure A6. Rear View of Principal Other Vehicle (SSV)



Figure A7. Load Frame/Slider of SSV




Figure A8. Two-Rail Track and Road-Based Lateral Restraint Track



Figure A9. Steel Trench Plate



Figure A10. DGPS, Inertial Measurement Unit, and MicroAutoBox Installed in Subject Vehicle




Figure A11. Sensors for Detecting Auditory and Visual Alerts



Figure A12. Computer Installed in Subject Vehicle



Figure A13. Brake Actuator Installed in POV System






Figure A14. AEB System On/Off Menu




Figure A15. Visual Alert

## APPENDIX B

Excerpts from Owner's Manual

# Pre-Collision Assist

## WHAT IS PRE-COLLISION ASSIST

Pre-collision assist detects and warns of approaching hazards in the roadway. If your vehicle is rapidly approaching another stationary vehicle, a vehicle traveling in the same direction as yours, or a pedestrian within your driving path, the system provides multiple levels of assistance to help avoid a collision.

## HOW DOES PRE-COLLISION ASSIST WORK

The system warns the driver of potential hazards by providing three levels of assistance.

If your vehicle is rapidly approaching potential hazards the system provides the following levels of functionality:

1. Alert.
2. Brake Support.
3. Automatic Emergency Braking.



**Alert:** When active, a flashing visual warning appears and an audible warning tone sounds.


**Brake Support:** The system is designed to help reduce the impact speed by preparing the brakes for rapid braking. The system does not automatically apply the brakes. If you press the brake pedal, the system could apply additional braking up to maximum braking force, even if you lightly press the brake pedal.


**Automatic Emergency Braking:** Automatic emergency braking may activate if the system determines that a collision is imminent.


**Note:** If you perceive pre-collision assist alerts as being too frequent or disturbing, then you can reduce the alert sensitivity, although the manufacturer recommends using the highest sensitivity setting where possible. Setting lower sensitivity would lead to fewer and later system warnings.


Each system has various levels of detection capabilities. See **Pre-Collision Assist Limitations** (page 280).

## PRE-COLLISION ASSIST PRECAUTIONS


 **WARNING:** You are responsible for controlling your vehicle at all times. The system is designed to be an aid and does not relieve you of your responsibility to drive with due care and attention. Failure to follow this instruction could result in the loss of control of your vehicle, personal injury or death.


 **WARNING:** The system does not detect vehicles that are driving in a different direction, cyclists or animals. Apply the brakes when necessary. Failure to follow this instruction could result in the loss of control of your vehicle, personal injury or death.


 **WARNING:** The system does not operate during hard acceleration or steering. Failure to take care may lead to a crash or personal injury.

 **WARNING:** The system may fail or operate with reduced function during cold and severe weather conditions. Snow, ice, rain, spray and fog can adversely affect the system. Keep the front camera and radar free of snow and ice. Failure to take care may result in the loss of control of your vehicle, serious personal injury or death.

## Pre-Collision Assist

 **WARNING:** Take additional care if your vehicle is heavily loaded or you are towing a trailer. These conditions could result in reduced performance of this system. Failure to follow this instruction could result in the loss of control of your vehicle, personal injury or death.

 **WARNING:** The system cannot help prevent all crashes. Do not rely on this system to replace driver judgment and the need to maintain a safe distance and speed.

 **WARNING:** In situations where the vehicle camera has limited detection capability, this may reduce system performance. These situations include but are not limited to direct or low sunlight, vehicles at night without tail lights, unconventional vehicle types, pedestrians with complex backgrounds, running pedestrians, partly obscured pedestrians, or pedestrians that the system cannot distinguish from a group. Failure to take care may result in the loss of control of your vehicle, serious personal injury or death.

### PRE-COLLISION ASSIST LIMITATIONS

Pre-collision assist depends on the detection ability of its camera and sensors. Any obstructions or damage to these areas can limit detection or prevent the system from functioning. See **Locating the Pre-Collision Assist Sensors** (page 281).

The system is active at speeds above 3 mph (5 km/h)

**Note:** The pre-collision assist system disables when you select four-wheel drive low or manually disable AdvanceTrac™.

**Note:** Brake support and automatic emergency braking are active at speeds up to 75 mph (120 km/h). If the vehicle has a radar sensor included with adaptive cruise control, then brake support and automatic emergency braking are active up to the maximum speed of the vehicle.

### Pedestrian Detection Limitations

Pedestrian detection is active at speeds up to 50 mph (80 km/h).

Pedestrian detection functions optimally when detected hazards are clearly identifiable. System performance may reduce in situations where pedestrians are running, partly obscured, have a complex background, or cannot be distinguished from a group.

### SWITCHING PRE-COLLISION ASSIST ON AND OFF

You cannot switch the system off.

### Adjusting the Pre-Collision Assist Settings

You can adjust the following settings by using the touchscreen controls in the pre-collision assist menu:


- Change alert and distance alert sensitivity to one of three possible settings.
- Switch distance indication and alert on or off.
- If required, switch automatic emergency braking on or off.
- If required, switch evasive steering assist on or off.

**Note:** Automatic emergency braking and evasive steering automatically turns on every time you switch the ignition on.

## Pre-Collision Assist

**Note:** If you switch automatic emergency braking off, evasive steering assist switches off.

### LOCATING THE PRE-COLLISION ASSIST SENSORS



1. Camera.
2. Radar sensor (if equipped).

If a message regarding a blocked sensor or camera appears in the information display, something is obstructing the radar signals or camera images. The radar sensor is behind the fascia cover in the center of the lower grille. With a blocked sensor or camera, the system may not function, or performance may reduce. See **Pre-Collision Assist – Information Messages** (page 285).

**Note:** Proper system operation requires a clear view of the road by the camera. Repair any windshield damage in the area of the camera's field of view.

**Note:** If something hits the front end of your vehicle or damage occurs and your vehicle has a radar sensor, the radar sensing zone could change. This could cause missed or false vehicle detections. Have your vehicle serviced to have the radar checked for proper coverage and operation.

**Note:** If your vehicle detects excessive heat at the camera or a potential misalignment condition, a message could display in the information display indicating temporary sensor unavailability. When operational conditions are correct, the message deactivates. For example, when the ambient temperature around the sensor decreases or the sensor recalibrates successfully.

### DISTANCE INDICATION

#### What Is Distance Indication

Distance indication displays the gap between your vehicle and the vehicle ahead of you.

**Note:** The graphic does not display if you switch on cruise control or adaptive cruise control.

## Pre-Collision Assist

---

<b>Vehicle Speed</b>	<b>System Sensitivity</b>	<b>Distance Indicator Color</b>	<b>Distance Gap</b>	<b>Time Gap</b>
62 mph (100 km/h).	Normal.	Gray.	Greater than 82 ft (25 m).	Greater than 0.9 seconds.
		Yellow.	56–82 ft (17–25 m).	0.6-0.9 seconds.
		Red.	Less than 56 ft (17 m).	Less than 0.6 seconds.

## Pre-Collision Assist

### Switching Distance Indication On and Off

To switch the system on or off, use the touchscreen:

1. Press **Settings** on the touchscreen.
2. Press **Driver Assistance**.
3. Press **Pre-Collision Assist**.
4. Press **Distance Indication**.

### Distance Indication Indicator

The indicator displays the time gap between your vehicle and vehicles traveling in the same direction ahead of you.



### DISTANCE ALERT

#### What Is Distance Alert

The system alerts you with a warning lamp if the distance to the vehicle ahead is small.

**Note:** *The warning lamp does not illuminate if cruise control or adaptive cruise control is active.*

#### Adjusting the Sensitivity of Distance Alert

To adjust the sensitivity of the system, use the touchscreen:

1. Press **Settings** on the touchscreen.
2. Press **Driver Assistance**.
3. Press **Pre-Collision Assist**.
4. Press **Alert Sensitivity**.
5. Press a setting.

### AUTOMATIC EMERGENCY BRAKING

#### What Is Automatic Emergency Braking

Automatic emergency braking may activate if the system determines that a collision is imminent. The system may help reduce impact damage to avoid the crash completely.

Automatic emergency braking is only available up to certain speeds. See **Pre-Collision Assist Limitations** (page 280).



## Pre-Collision Assist

---

### Switching Automatic Emergency Braking On and Off

To switch the system on or off, use the touchscreen:

1. Press **Settings** on the touchscreen.
2. Press **Driver Assistance**.
3. Press **Pre-Collision Assist**.
4. Press **Active Braking**.
5. Switch the feature on or off.

### EVASIVE STEERING ASSIST (If Equipped)

#### What Is Evasive Steering Assist

If your vehicle is rapidly approaching a road user, evasive steering assist helps you steer around the road user.

After you turn the steering wheel in an attempt to avoid a crash with the road user, the system applies additional steering torque to help you steer around the road user. After you pass the road user, the system applies steering torque when you turn the steering wheel to steer back into the lane. The system deactivates after you fully pass the road user.

**Note:** Road users are defined as obstacles encountered on the road that the system is able to detect. See **Pre-Collision Assist Precautions** (page 279).

### Evasive Steering Assist Limitations

Evasive steering assist only activates when all the following occur:

- Automatic emergency braking and evasive steering assist are on.
- The system detects a road user ahead and starts to apply the brakes.
- You significantly turn the steering wheel to steer around a road user.

**Note:** The system does not automatically steer around a road user. If you do not turn the steering wheel, the system does not activate.

**Note:** The system does not activate if the distance to the road user ahead is too small and the system cannot avoid a crash.

### Switching Evasive Steering Assist On and Off

To switch the system on or off, use the touchscreen:

1. Press **Settings** on the touchscreen.
2. Press **Driver Assistance**.
3. Press **Pre-Collision Assist**.
4. Press **Evasive Steering**.
5. Switch the feature on or off.

**Note:** If you switch automatic emergency braking off, evasive steering assist turns off.

**Note:** Automatic emergency braking and evasive steering assist turn on every time you switch the ignition on.

# Pre-Collision Assist

---

## PRE-COLLISION ASSIST – TROUBLESHOOTING

### Pre-Collision Assist – Information Messages

<b>Message</b>	<b>Action</b>
Pre-Collision Assist Not Available Sensor Blocked	You have a blocked sensor due to bad weather, ice, mud or water in front of the radar sensor. You can typically clean the sensor to resolve.
Pre-Collision Assist Not Available	A fault with the system has occurred. Have your vehicle checked as soon as possible.

## Pre-Collision Assist

---

### **Pre-Collision Assist – Frequently Asked Questions**

#### **Camera Troubleshooting**

##### **The windshield in front of the camera is dirty or obstructed.**

Clean the outside of the windshield in front of the camera.

##### **The windshield in front of the camera is clean, but the message remains in the instrument cluster display.**

Wait a short time. It could take several minutes for the camera to detect that there is no obstruction.

#### **Radar Troubleshooting (If Equipped)**

##### **The surface of the radar in the grille is dirty or obstructed.**

Clean the grille surface in front of the radar or remove the object causing the obstruction.

##### **The surface of the radar in the grille is clean, but the message remains in the instrument cluster display.**

Wait a short time. It could take several minutes for the radar to detect that there is no obstruction.

##### **Heavy rain, spray or fog is interfering with the radar signals.**

The pre-collision assist system is temporarily disabled. Pre-collision assist reactivates a short time after the weather conditions improve.

##### **Swirling water or snow or ice on the surface of the road could interfere with the radar signals.**

The pre-collision assist system is temporarily disabled. Pre-collision assist reactivates a short time after the weather conditions improve.

##### **Radar is out of alignment due to a front end impact.**

Have your vehicle serviced to have the radar checked for proper coverage and operation.

## APPENDIX C

### Run Log

Subject Vehicle: **2022 Ford Escape PHEV FWD**

Test start date: **5/23/2022**

Principal Other Vehicle: **SSV**

Test end date: **5/23/2022**

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
18	Static Run								
19	<b>Stopped POV</b>	Y	1.99	1.83	25.3	0.74	1.36	Pass	
20		Y	2.00	2.00	24.8	0.77	1.37	Pass	
21		Y	1.98	1.65	24.8	0.73	1.35	Pass	
22		Y	1.99	1.61	24.7	0.75	1.38	Pass	
23		Y	2.00	2.10	24.9	0.76	1.37	Pass	
24		Y	1.94	1.41	25.0	0.68	1.43	Pass	
25		Y	2.02	1.32	24.7	0.69	1.43	Pass	
26	Static Run								
27	<b>Slower POV, 25 vs 10</b>	Y	1.82	6.75	14.7	0.79	0.89	Pass	
28		Y	1.82	5.90	14.3	0.74	0.93	Pass	
29		Y	1.83	5.78	15.1	0.68	1.03	Pass	
30		Y	1.78	7.59	15.0	0.82	0.88	Pass	
31		Y	1.75	6.54	15.1	0.82	0.89	Pass	
32		Y	1.89	6.25	15.3	0.77	0.98	Pass	
33		Y	1.77	5.49	15.2	0.74	0.94	Pass	
34	Static Run								

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
35	<b>Slower POV, 45 vs 20</b>	Y	2.45	1.38	24.2	0.98	1.14	Pass	
36		Y	2.47	0.00	22.3	0.93	1.13	Pass	
37		Y	2.52	0.89	25.3	0.97	1.14	Pass	
38		Y	2.41	1.96	25.4	0.95	1.16	Pass	
39		Y	2.40	2.12	25.2	0.98	1.02	Pass	
40		Y	2.49	2.60	24.9	0.96	1.07	Pass	
41		Y	2.49	1.59	24.7	0.97	1.14	Pass	
42	Static run								
43	<b>Decelerating POV, 35</b>	Y	1.69	3.46	24.8	0.88	1.13	Pass	
44		Y	1.75	0.00	29.2	0.82	1.21	Pass	
45		Y	1.76	3.07	24.9	0.92	1.13	Pass	
46		Y	1.83	2.64	24.8	0.95	1.12	Pass	
47		Y	1.79	3.53	23.8	0.90	1.14	Pass	
48		Y	1.79	3.46	25.0	0.94	1.18	Pass	
49		Y	1.81	3.96	24.5	0.91	1.14	Pass	
50	Static Run								
1	STP - Static Run								
2	<b>STP False Positive, 25</b>	Y				0.01		Pass	
3		Y				0.00		Pass	

Run	Test Type	Valid Run?	FCW TTC (s)	Min. Distance (ft)	Speed Reduction (mph)	Peak Decel. (g)	CIB TTC (s)	Pass/Fail	Notes
4		Y				0.01		Pass	
5		Y				0.01		Pass	
6		Y				0.01		Pass	
7		Y				0.01		Pass	
8		Y				0.00		Pass	
9	STP - Static Run								
10	<b>STP False Positive, 45</b>	Y				0.01		Pass	
11		Y				0.00		Pass	
12		Y				0.01		Pass	
13		Y				0.01		Pass	
14		Y				0.00		Pass	
15		Y				0.01		Pass	
16		Y				0.01		Pass	
17	STP - Static Run								

## APPENDIX D

### Time History Plots



## LIST OF FIGURES

	Page
Figure D1. Example Time History for Stopped POV, Passing.....	D-9
Figure D2. Example Time History for Slower POV 25 vs. 10, Passing.....	D-10
Figure D3. Example Time History for Slower POV 45 vs. 20, Passing.....	D-11
Figure D4. Example Time History for Decelerating POV 35, Passing .....	D-12
Figure D5. Example Time History for False Positive STP 25, Passing .....	D-13
Figure D6. Example Time History for False Positive STP 45, Passing .....	D-14
Figure D7. Example Time History Displaying Invalid Headway Criteria .....	D-15
Figure D8. Example Time History Displaying Various Invalid Criteria .....	D-16
Figure D9. Example Time History for a Failed Run .....	D-17
Figure D10. Time History for CIB Run 19, Test 1 - Stopped POV .....	D-18
Figure D11. Time History for CIB Run 20, Test 1 - Stopped POV .....	D-19
Figure D12. Time History for CIB Run 21, Test 1 - Stopped POV .....	D-20
Figure D13. Time History for CIB Run 22, Test 1 - Stopped POV .....	D-21
Figure D14. Time History for CIB Run 23, Test 1 - Stopped POV .....	D-22
Figure D15. Time History for CIB Run 24, Test 1 - Stopped POV .....	D-23
Figure D16. Time History for CIB Run 25, Test 1 - Stopped POV .....	D-24
Figure D17. Time History for CIB Run 27, Test 2 - Slower Moving POV, 25/10 mph .....	D-25
Figure D18. Time History for CIB Run 28, Test 2 - Slower Moving POV, 25/10 mph .....	D-26
Figure D19. Time History for CIB Run 29, Test 2 - Slower Moving POV, 25/10 mph .....	D-27
Figure D20. Time History for CIB Run 30, Test 2 - Slower Moving POV, 25/10 mph .....	D-28
Figure D21. Time History for CIB Run 31, Test 2 - Slower Moving POV, 25/10 mph .....	D-29
Figure D22. Time History for CIB Run 32, Test 2 - Slower Moving POV, 25/10 mph .....	D-30
Figure D23. Time History for CIB Run 33, Test 2 - Slower Moving POV, 25/10 mph .....	D-31
Figure D24. Time History for CIB Run 35, Test 2 - Slower Moving POV, 45/20 mph .....	D-32
Figure D25. Time History for CIB Run 36, Test 2 - Slower Moving POV, 45/20 mph .....	D-33
Figure D26. Time History for CIB Run 37, Test 2 - Slower Moving POV, 45/20 mph .....	D-34
Figure D27. Time History for CIB Run 38, Test 2 - Slower Moving POV, 45/20 mph .....	D-35
Figure D28. Time History for CIB Run 39, Test 2 - Slower Moving POV, 45/20 mph .....	D-36
Figure D29. Time History for CIB Run 40, Test 2 - Slower Moving POV, 45/20 mph .....	D-37
Figure D30. Time History for CIB Run 41, Test 2 - Slower Moving POV, 45/20 mph .....	D-38
Figure D31. Time History for CIB Run 43, Test 3 - Decelerating POV 35 mph .....	D-39
Figure D32. Time History for CIB Run 44, Test 3 - Decelerating POV 35 mph .....	D-40
Figure D33. Time History for CIB Run 45, Test 3 - Decelerating POV 35 mph .....	D-41
Figure D34. Time History for CIB Run 46, Test 3 - Decelerating POV 35 mph .....	D-42
Figure D35. Time History for CIB Run 47, Test 3 - Decelerating POV 35 mph .....	D-43
Figure D36. Time History for CIB Run 48, Test 3 - Decelerating POV 35 mph .....	D-44
Figure D37. Time History for CIB Run 49, Test 3 - Decelerating POV 35 mph .....	D-45
Figure D38. Time History for CIB Run 2, Test 4 - False Positive STP, 25 mph.....	D-46
Figure D39. Time History for CIB Run 3, Test 4 - False Positive STP, 25 mph.....	D-47
Figure D40. Time History for CIB Run 4, Test 4 - False Positive STP, 25 mph.....	D-48
Figure D41. Time History for CIB Run 5, Test 4 - False Positive STP, 25 mph.....	D-49

Figure D42. Time History for CIB Run 6, Test 4 - False Positive STP, 25 mph.....	D-50
Figure D43. Time History for CIB Run 7, Test 4 - False Positive STP, 25 mph.....	D-51
Figure D44. Time History for CIB Run 8, Test 4 - False Positive STP, 25 mph.....	D-52
Figure D45. Time History for CIB Run 10, Test 4 - False Positive STP, 45 mph.....	D-53
Figure D46. Time History for CIB Run 11, Test 4 - False Positive STP, 45 mph.....	D-54
Figure D47. Time History for CIB Run 12, Test 4 - False Positive STP, 45 mph.....	D-55
Figure D48. Time History for CIB Run 13, Test 4 - False Positive STP, 45 mph.....	D-56
Figure D49. Time History for CIB Run 14, Test 4 - False Positive STP, 45 mph.....	D-57
Figure D50. Time History for CIB Run 15, Test 4 - False Positive STP, 45 mph.....	D-58
Figure D51. Time History for CIB Run 16, Test 4 - False Positive STP, 45 mph.....	D-59

## Description of Time History Plots

A set of time history plots is provided for each valid run in the test series. Each set of plots comprises time varying data from both the Subject Vehicle (SV) and the Principal Other Vehicle (POV), as well as pass/fail envelopes and thresholds. The following is a description of data types shown in the time history plots, as well as a description of the color codes indicating to which vehicle the data pertain.

### Time History Plot Description

Each time history plot consists of data relevant to the test type under consideration, and therefore the data channels plotted vary according to test type. The test types (shown in the plot titles) include:

- Stopped POV (SV at 25 mph)
- Slower POV, 25/10 (SV at 25 mph, POV at 10 mph)
- Slower POV, 45/20 (SV at 45 mph, POV at 20 mph)
- Decelerating POV 35 mph (Both vehicles at 35 mph with 13.8 m gap, POV brakes at 0.3 g)
- False Positive STP 25 mph (Steel trench plate run over at 25 mph)
- False Positive STP 45 mph (Steel trench plate run over at 45 mph)

Time history figures include the following sub-plots:

- FCW Warning – Displays the Forward Collision Warning alert (which can be auditory, visual, or haptic). Depending on the type of FCW alert or instrumentation used to measure the alert, this can be any combination of the following:
  - Filtered, rectified, and normalized sound signal. The vertical scale is 0 to 1.
  - Filtered, rectified, and normalized acceleration (i.e., haptic alert, such as steering wheel vibration). The vertical scale is 0 to 1.
  - Normalized light sensor signal. The vertical scale is 0 to 1.

As only the auditory or haptic alert is perceptible by the driver during a test run, the earliest of either of these alerts is used to define the onset of the FCW alert. A vertical black bar on the plot indicates the TTC (sec) at the first moment of the warning issued by the FCW system. The FCW TTC is displayed to the right of the subplot in green. For False Positive tests, when the FCW presents a warning “FCW” is shown in red at the right edge of the FCW plot.

- Headway (ft) – Longitudinal separation (gap) between the frontmost point of the Subject Vehicle and the rearmost point of the Strikeable Surrogate Vehicle (SSV) towed by the Principal Other Vehicle. The minimum headway during the run is displayed to the right of the subplot.
- SV/POV Speed (mph) – Speed of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the speed reduction experienced by the Subject Vehicle is displayed to the right of the subplot.
- Yaw Rate (deg/sec) – Yaw rate of the Subject Vehicle and Principal Other Vehicle (if any).
- Lateral Offset (ft) – Lateral offset within the lane of the Subject Vehicle to the center of the lane of travel. Note that for tests involving the Strikeable Surrogate Vehicle (SSV), the associated lateral restraint track is defined to be the center of the lane of travel. If testing is done with a different POV which does not have a lateral restraint track, lateral offset is defined to be the lateral offset between the SV and POV.
- Ax (g) – Longitudinal acceleration of the Subject Vehicle and Principal Other Vehicle (if any). For CIB tests, the TTC (sec) at the moment of first CIB activation is displayed to the right of the subplot in green. Also, the peak value of Ax for the SV is shown on the subplot.
- Accelerator Pedal Position (0-1) – Normalized position of the accelerator pedal.

## Envelopes and Thresholds

Some of the time history plot figures contain either green or yellow envelopes and/or black threshold lines. These envelopes and thresholds are used to programmatically and visually determine the validity of a given test run. Envelope and threshold exceedances are indicated with either red shading or red asterisks, and red text is placed to the right side of the plot indicating the type of exceedance. Such exceedances indicate either that the test was invalid or that the requirements of the test were not met (i.e., failure of the AEB system).

For plots with green envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope boundaries at any time. Exceedances of a green envelope are indicated by red shading in the area between the measured time-varying data and the envelope boundaries.

For plots with yellow envelopes, in order for the test to be valid, the time-varying data must not exceed the envelope at the beginning (left edge of the boundary) and/or end (right edge), but may exceed the boundary during the time

between the left and right edges. Exceedances at the left or right extent of a yellow envelope are indicated by red asterisks.

For the headway plot, a dashed black threshold line indicating a relative headway of zero is displayed. If no impact occurs, a green circle is displayed at the moment of minimum distance. If impact occurs, a red asterisk is displayed at the moment of impact.

For the Ax plot, if the scenario is an AEB brake-to-stop scenario, a vertical dashed black line is displayed for all plots indicating the moment of first POV braking. The yellow envelope in this case is relevant to the POV braking only. The left edge of the envelope is at 1.5 seconds after the first POV braking. A solid black threshold line extends horizontally 0.5 seconds to the left of the envelope. This threshold line represents the time during which the Ax of the Principal Other Vehicle must first achieve 0.27 g (the upper edge of the envelope). A green circle or red asterisk is displayed at the moment the POV brake level achieves 0.27 g. A green circle indicates that the test was valid (the threshold was crossed during the appropriate interval) and a red asterisk indicates that the test was invalid (the threshold was crossed outside of the appropriate interval). Additionally, for the CIB tests, a dashed black threshold line indicating an Ax of -0.15 g is given to define the onset of CIB activation. When the Subject Vehicle's Ax crosses this threshold, the CIB TTC is calculated and displayed.

For the accelerator pedal position plot, a green envelope is given starting 500 ms after the onset of the FCW warning to ensure that the accelerator pedal was released at the correct time and remained off for the duration of the CIB event. For false positive runs a green dot, rather than a green envelope is displayed. The green dot indicates that at the end of the run the accelerator pedal had not been released. If the accelerator had been released a red asterisk would appear.

## Color Codes

Color codes have been adopted to easily identify which data correspond to which vehicle, as well as to indicate the types of envelopes and thresholds used in the plots.

Color codes can be broken into four categories:

1. Time-varying data
2. Validation envelopes and thresholds
3. Individual data points
4. Text

1. Time-varying data color codes:

- Blue = Subject Vehicle data
- Magenta = Principal Other Vehicle data
- Brown = Relative data between SV and POV (i.e., TTC, lateral offset and headway distance)

2. Validation envelope and threshold color codes:

- Green envelope = time varying data must be within the envelope at all times in order to be valid
- Yellow envelope = time varying data must be within limits at left and/or right ends
- Black threshold (Solid) = time varying data must cross this threshold in the time period shown in order to be valid
- Black threshold (Dashed) = for reference only – this can include warning level thresholds, TTC thresholds, and acceleration thresholds

3. Individual data point color codes:

- Green circle = passing or valid value at a given moment in time
- Red asterisk = failing or invalid value at a given moment in time

4. Text color codes:

- Green = passing or valid value
- Red = failing or invalid value

## Other Notations

- NG – Indicates that the value for that variable was outside of bounds and therefore “No Good”.
- No Wng – No warning was detected.
- POV – Indicates that the value for the Principal Other Vehicle was out of bounds.
- SV – Indicates that the value for the Subject Vehicle was out of bounds.
- SR – Shows the speed reduction value.
- Thr – Indicates that the requirements for the throttle were not met.

The minimum (worst) GPS fix type is displayed in the lower right corner of each page. The only valid fix type is RTK fixed (displayed in green). If the fix type during any portion of the test was anything other than RTK fixed, then “RTK Fixed OR LESS!!” is displayed in red.

Examples of time history plots for each test type (including passing, failing and invalid runs) are shown in Figure D1 through Figure D9. Figures D1 through D6 show passing runs for each of the 6 test types. Figures D7 and D8 show examples of invalid runs. Figure D9 shows an example of a valid test that failed the CIB requirements.

Time history data plots for the tests of the vehicle under consideration herein are provided beginning with Figure D10.




Figure D1. Example Time History for Stopped POV, Passing






Figure D2. Example Time History for Slower POV 25 vs. 10, Passing




Figure D3. Example Time History for Slower POV 45 vs. 20, Passing




Figure D4. Example Time History for Decelerating POV 35, Passing




Figure D5. Example Time History for False Positive STP 25, Passing




Figure D6. Example Time History for False Positive STP 45, Passing




Figure D7. Example Time History Displaying Invalid Headway Criteria




Figure D8. Example Time History Displaying Various Invalid Criteria




Figure D9. Example Time History for a Failed Run






Figure D10. Time History for CIB Run 19, Test 1 - Stopped POV




Figure D11. Time History for CIB Run 20, Test 1 - Stopped POV




Figure D12. Time History for CIB Run 21, Test 1 - Stopped POV




Figure D13. Time History for CIB Run 22, Test 1 - Stopped POV




Figure D14. Time History for CIB Run 23, Test 1 - Stopped POV




Figure D15. Time History for CIB Run 24, Test 1 - Stopped POV




Figure D16. Time History for CIB Run 25, Test 1 - Stopped POV




Figure D17. Time History for CIB Run 27, Test 2 - Slower Moving POV, 25/10 mph






Figure D18. Time History for CIB Run 28, Test 2 - Slower Moving POV, 25/10 mph




Figure D19. Time History for CIB Run 29, Test 2 - Slower Moving POV, 25/10 mph




Figure D20. Time History for CIB Run 30, Test 2 - Slower Moving POV, 25/10 mph




Figure D21. Time History for CIB Run 31, Test 2 - Slower Moving POV, 25/10 mph




Figure D22. Time History for CIB Run 32, Test 2 - Slower Moving POV, 25/10 mph




Figure D23. Time History for CIB Run 33, Test 2 - Slower Moving POV, 25/10 mph




Figure D24. Time History for CIB Run 35, Test 2 - Slower Moving POV, 45/20 mph




Figure D25. Time History for CIB Run 36, Test 2 - Slower Moving POV, 45/20 mph






Figure D26. Time History for CIB Run 37, Test 2 - Slower Moving POV, 45/20 mph




Figure D27. Time History for CIB Run 38, Test 2 - Slower Moving POV, 45/20 mph




Figure D28. Time History for CIB Run 39, Test 2 - Slower Moving POV, 45/20 mph




Figure D29. Time History for CIB Run 40, Test 2 - Slower Moving POV, 45/20 mph




Figure D30. Time History for CIB Run 41, Test 2 - Slower Moving POV, 45/20 mph




Figure D31. Time History for CIB Run 43, Test 3 - Decelerating POV 35 mph




Figure D32. Time History for CIB Run 44, Test 3 - Decelerating POV 35 mph




Figure D33. Time History for CIB Run 45, Test 3 - Decelerating POV 35 mph






Figure D34. Time History for CIB Run 46, Test 3 - Decelerating POV 35 mph




Figure D35. Time History for CIB Run 47, Test 3 - Decelerating POV 35 mph




Figure D36. Time History for CIB Run 48, Test 3 - Decelerating POV 35 mph




Figure D37. Time History for CIB Run 49, Test 3 - Decelerating POV 35 mph




Figure D38. Time History for CIB Run 2, Test 4 - False Positive STP, 25 mph




Figure D39. Time History for CIB Run 3, Test 4 - False Positive STP, 25 mph




Figure D40. Time History for CIB Run 4, Test 4 - False Positive STP, 25 mph




Figure D41. Time History for CIB Run 5, Test 4 - False Positive STP, 25 mph






Figure D42. Time History for CIB Run 6, Test 4 - False Positive STP, 25 mph




Figure D43. Time History for CIB Run 7, Test 4 - False Positive STP, 25 mph




Figure D44. Time History for CIB Run 8, Test 4 - False Positive STP, 25 mph




Figure D45. Time History for CIB Run 10, Test 4 - False Positive STP, 45 mph




Figure D46. Time History for CIB Run 11, Test 4 - False Positive STP, 45 mph




Figure D47. Time History for CIB Run 12, Test 4 - False Positive STP, 45 mph




Figure D48. Time History for CIB Run 13, Test 4 - False Positive STP, 45 mph




Figure D49. Time History for CIB Run 14, Test 4 - False Positive STP, 45 mph






Figure D50. Time History for CIB Run 15, Test 4 - False Positive STP, 45 mph




Figure D51. Time History for CIB Run 16, Test 4 - False Positive STP, 45 mph